

DOCUMENT RESUME

ED 185 288

CE 024 545

TITLE Power Trains. FOS: Fundamentals of Service.
 INSTITUTION John Deere Co., Moline, Ill.
 PUB DATE 79
 NOTE 399p.; For related documents see CE 024 540-544 and CE 024 546, CE 024 797-798, and CE 025 209-214.
 AVAILABLE FROM John Deere Distribution Service Center, Service Publications, Dept. 333, 1400-3rd Ave., Moline, IL 61265 (manual, Order No. FOS-4004B, \$6.50; 10 or more--\$4.88 each; masters, Order No. FOS-40, \$15.75; supplementary slide set--\$70.00)
 EDRS PRICE MF01 Plus Postage. PC Not Available from EDRS.
 DESCRIPTORS *Agricultural Education: Agricultural Engineering; Auto Mechanics: Equipment Maintenance; Postsecondary Education: *Power Technology: Secondary Education; *Tractors: *Vocational Education
 IDENTIFIERS *Power Trains

ABSTRACT

This power trains manual is one of a series of power mechanics for training in the servicing of transmissions, etc., on farm and industrial machines. Materials provide basic information and illustrations for use by vocational students and teachers as well as shop servicemen and laymen. The ten chapters focus on (1) Power Trains: How They Work; (2) Clutches; (3) Mechanical Transmissions; (4) Hydraulic Assist Transmissions; (5) Hydrostatic Drives; (6) Torque Converters; (7) Differentials; (8) Final Drives; (9) Power Take-Offs; and (10) Special Drives. Each chapter concludes with test questions. Answers to the test questions are appended along with a glossary of terms and 130 transparency masters. (A supplementary set of 35mm color slides is also available--see availability note.)
 (LRA)


 * Reproductions supplied by EDRS are the best that can be made *
 * from the original document. *

ED185288

Power Trains



FOS
FUNDAMENTALS
OF SERVICE



CE 024 545

U.S. DEPARTMENT OF HEALTH,
EDUCATION & WELFARE
NATIONAL INSTITUTE OF
EDUCATION

THIS DOCUMENT HAS BEEN REPRODUCED EXACTLY AS RECEIVED FROM THE PERSON OR ORGANIZATION ORIGINATING IT. POINTS OF VIEW OR OPINIONS STATED DO NOT NECESSARILY REPRESENT OFFICIAL NATIONAL INSTITUTE OF EDUCATION POSITION OR POLICY.

"PERMISSION TO REPRODUCE THIS MATERIAL IN MICROFICHE ONLY HAS BEEN GRANTED BY

L. R. Hathaway

TO THE EDUCATIONAL RESOURCES INFORMATION CENTER (ERIC)."

TO THE READER

PURPOSE OF THIS MANUAL

The main purpose of this manual is to train the reader so that he can understand and service power trains with speed and skill. Starting with "how it works," we build up to "why it fails" and "what to do about it." This manual is also an excellent reference for the trained mechanic who wants to refresh his memory on power trains. It is written in a simple form using many illustrations so that it can be easily understood.

APPLICATION OF POWER TRAINS IN THIS MANUAL

"Power Trains" is a broad field. But in this manual, the prime interest is in transmissions, etc., as they are commonly used to transmit power on farm and industrial machines.

HOW TO USE THIS MANUAL

This manual can be used by anyone—experienced mechanics and shop trainees, as well as vocational students and interested laymen.

By starting with the basics, build your knowledge step by step. Chapter 1 covers the basics—"how it works;" Chapter 2 covers Clutches, while Chapters 3 through 6 explain the various Transmissions. The remaining Chapters cover Differentials, Final Drives, PTO's, and Special Drives.

Persons not familiar with basic power trains should start at Chapter 1 and study the chapters in sequence. The experienced man can find what he needs on the "Contents" page.

Answers to "Test Yourself" questions, at the end of each chapter, appear at the end of this manual on pages 9 and 10 following the index.

ACKNOWLEDGMENTS

John Deere gratefully acknowledges help from the following groups: Allison Division, General Motors Corp.; American Gear Manufacturers Assn.; American Oil Co.; American Society of Agricultural Engineers; American Society of Mechanical Engineers; Bendix Corp.; Borg-Warner Corp., Rockford Clutch Division; Cessna Aircraft Co.; Clark Equipment Co.; Dana Corporation, Spicer Axle Division; Dayco Corp.; Detroit Automotive Products Corp.; Eaton, Yale and Towne Inc., Eaton Axle Div.; Gates Rubber Co.; General Motors Corp.; Goodyear Tire and Rubber Co.; Link-Belt/FMC; Lipe-Rollway Corp.; National Fluid Power Assn.; Nuday Co.; Owatonna Tool Co.; Purolator Products Inc.; Rex Chainbelt Inc.; Rockwell-Standard Co.; Rubber Manufacturers Assn.; Society of Automotive Engineers; Sundstrand Corp.; Twin Disc Inc.; Vickers Inc., Division of Sperry Rand Corp.; Warner Electric Brake and Clutch Co.

OTHER MANUALS IN THIS SERIES

We, at John Deere, are preparing a series of these manuals called "Fundamentals of Service," or "FOS."

Other manuals in the FOS series are:

- Hydraulics
- Engines
- Electrical Systems
- Shop Tools
- Welding
- Air Conditioning
- Bearings and Seals
- Belts and Chains
- Fuels, Lubricants, and Coolants
- Mowing and Spraying Equipment
- Tires and Tracks
- Fiber Glass/Plastics
- Fasteners
- Identification of Parts Failures

Each manual is backed up by a set of 35 mm color slides for classroom use.

FOR MORE INFORMATION

Write for a free *FOS Catalog of Manuals and Slides*. Send your request to:

*John Deere Fundamental Writing Services, Dept. F
John Deere Road
Moline, Illinois 61265*

JOHN DEERE FUNDAMENTAL WRITING SERVICES

*Managing Editor: Louis R. Hathaway
Editor: Michael H. Johanning
Graphics Coordinator: Alton E. Miller
Promotion: Annette LaCour*

CONTENTS

Chapter 1—POWER TRAINS—How They Work

How A Power Train Works.....	1-2
How Power Is Transmitted.....	1-6
Friction Drives.....	1-6
Gear Drives.....	1-7
Fluid Drives.....	1-7
Gears.....	1-8
Gear Types.....	1-9
How Planetary Gears Work.....	1-12
Gear Wear.....	1-14
Bearings.....	1-17
Adjusting the Gear Train.....	1-20

Chapter 2—CLUTCHES

Types of Clutches.....	2-1
Disk- and Plate-Type Clutches.....	2-2
Band-Type Clutches.....	2-7
Overrunning Clutches.....	2-7
Magnetic Clutches.....	2-9
Cone-Type Clutches.....	2-9
Expanding Shoe Clutches.....	2-10
Pneumatic Clutches.....	2-10
Hydraulic Clutches.....	2-10
Clutch Operating Mechanisms.....	2-11
Dampeners.....	2-15
General Maintenance.....	2-15
Trouble Shooting.....	2-17

Chapter 3—MECHANICAL TRANSMISSIONS

Sliding Gear Transmissions.....	3-1
Collar Shift Transmissions.....	3-3
Synchromesh Transmissions.....	3-5
Shift Controls.....	3-10
Adjustments.....	3-11
General Maintenance.....	3-12
Trouble Shooting.....	3-12

Chapter 4—HYDRAULIC ASSIST TRANSMISSIONS

Countershaft Transmissions.....	4-2
Planetary Transmissions.....	4-3
Hydraulic Shift Controls.....	4-9
Trouble Shooting.....	4-11

Chapter 5—HYDROSTATIC DRIVES

How It Works.....	5-1
Theory of Hydrostatic Drives.....	5-2
Types of Hydrostatic Drives.....	5-4

Operation of Hydrostatic Drives.....	5-6
Hydrostatic Drive Axles.....	5-9
Other Types of Hydrostatic Drives.....	5-11
Maintenance.....	5-12
Testing.....	5-12
Trouble Shooting.....	5-13

Chapter 6—TORQUE CONVERTERS

How It Works.....	6-1
Oil Flow In Converter.....	6-3
Torque Converter Transmissions.....	6-6
Trouble Shooting.....	6-9
Testing.....	6-12

Chapter 7—DIFFERENTIALS

Operation.....	7-1
Differential Locks.....	7-2
Adjustments.....	7-4
Trouble Shooting.....	7-5

Chapter 8—FINAL DRIVES

Straight Axle Drives.....	8-2
Pinion Drives.....	8-3
Planetary Drives.....	8-4
Chain Final Drives.....	8-6
Maintenance.....	8-6
Adjustments.....	8-7

Chapter 9—POWER TAKE-OFFS

Types of PTO's.....	9-1
Operation of PTO's.....	9-2
PTO Drives.....	9-3
Standards For PTO Drives.....	9-5
Servicing.....	9-6
Safety Rules.....	9-6
Trouble Shooting.....	9-7

Chapter 10—SPECIAL DRIVES

Belt Drives.....	10-1
Chain Drives.....	10-8
Gear Drives.....	10-13
Reciprocating Drives.....	10-14
Safety Release Mechanisms.....	10-17
Slip Clutches.....	10-17
Jump Clutches.....	10-18
Shear Pins.....	10-18

DEFINITIONS OF TERMS AND SYMBOLS

INDEX

POWER TRAINS—How They Work / CHAPTER 1




Fig. 1—Power Trains For Automobile and Tractor

INTRODUCTION

Engine power is transmitted to the drive wheels or output shaft of a machine by the **power train**. It does four basic jobs:

- 1) *Connects and disconnects power*
- 2) *Selects speed ratios*
- 3) *Provides a means of reversing*
- 4) *Equalizes power to the drive wheels for turning*

To do these jobs, five basic parts are needed:

- **Clutch**—to connect and disconnect power
- **Transmission**—to select speeds and direction
- **Differential**—to equalize power for turning
- **Final Drives**—to reduce speed and increase torque to axle
- **Drive Wheels**—to propel the machine


Other parts are also used to help drive the machine as we'll see later.

Now let's follow the flow of power through a simple power train.


HOW A POWER TRAIN WORKS

The first part of a power train is the **clutch**.

Its job is to disconnect the engine from the power train, allowing the engine to run while the machine is standing still. The clutch also engages this power to start up the machine.



ONLY ONE DISK IS TURNING



BOTH DISKS ARE TURNING

X2019

Fig. 2—How The Clutch Works

Think of a clutch as two disks, each on a shaft (Fig. 2).

As long as the disks are not touching, we can spin one as fast as we want to without affecting the other.

But if we move them together when one is spinning, the other will begin to turn and then both shafts will turn as one unit.

This is the principle of the disk clutch as used on many machines.

In an actual disk clutch (Fig. 3), the disks are forced together by strong springs, and are separated by pushing down on the clutch pedal.


Some machines have automatic drives in which the clutch is eliminated. We will discuss these later.

The **transmission** allows us to change the speed of the drive wheels in relation to the engine.

This allows slower speeds when starting up the machine, and faster speeds to match various loads and conditions.

In automobiles, we need more turning force on the rear wheels to start moving than we need for cruising along a good highway. The transmission gives us this increased turning force and also allows the engine to accelerate. The latter is important because the engine does not develop very much power at low rpms. When the car has picked up speed, the transmission is shifted to change the speed ratio between the engine and the wheels, and eventually is shifted into direct drive.

In tractors and other field machines, there is an even greater speed reduction to give more turning force for traction and for pulling loads.




X2020

CLUTCH DISENGAGED

CLUTCH ENGAGED

Fig. 3—Disk Clutch In Operation



X2021

SMALL GEAR ALWAYS
TURNS FASTER

Fig. 4—How The Transmission Selects A Speed

The transmission is a system of **gears**.

Suppose we have a small gear with 12 teeth driving a larger gear with 24 teeth (Fig. 4).

When the first gear has made one complete revolution, it has gone around the equivalent of 12 teeth. The second one has gone around the same distance—12 teeth—but this means only *one-half* a revolution for the larger gear.

As a result, the second gear and its shaft always turn at one-half the speed of the first gear and its shaft.

The point to remember is that **smaller gears always turn at a faster rate**.

This is the principle of the transmission—several combinations of gears are arranged so that we can select the speed we want to use at any moment.

For **low or first gear**, a small gear on the input shaft drives a large gear on another shaft (Fig. 5).


This reduces the speed and increases the turning force.

Then a small gear on the second shaft drives a large gear on the drive shaft which goes to the driving axle.

This reduces the speed and increases the turning still more, giving a higher gear ratio for starting up or heavy pulling.


For **second gear**, we can use the same first pair of gears as in low.

However, we disconnect the second pair of gears and drive through two other gears (Fig. 6).



X2022

Fig. 5—Transmission In Low or First Gear




X2023

Fig. 6—Transmission In Second Gear

These gears are arranged so that the larger one drives the smaller, so there is less overall speed reduction than in first gear.

For higher gears, the gear ratio is cut further by using other gear combinations. In fact, high gear for an automobile is normally a direct drive with no reduction (a 1 to 1 ratio).



X2024

Fig. 7—Transmission in Reverse Gear

Reverse gear is very much like first, giving about the same ratio and using the same four gears. However, it also uses an extra gear called a reverse idler (Fig. 7) which causes the drive shaft to turn in the opposite direction.

All the gears are mounted in a metal case filled with oil to lubricate the gears and bearings.

The various speeds are selected by moving a shift lever in the driver's compartment.

Other types of transmissions, covered later in this manual, are automatic drives which use hydraulic power to aid in controlling the power train.

Now let's complete the power train from the transmission to the drive wheels.

In the rear axle we have two sets of gears. The first—the **ring gear and pinion**—simply transmits the power around the corner to the axles as shown in Fig. 8.


This allows the propeller shaft to drive the axles which are at right angles to it.

If we never turned a corner, that is all the gearing we would need at the rear axle. But when we turn a corner, the outside wheel has to travel farther than the inside wheel and has to turn faster.

The **differential** (Fig. 9) allows each wheel to travel at a different speed and still prop. its own load.

When the machine is moving straight ahead, *both wheels are free to rotate* as shown at left.

Engine power comes in on the pinion gear and rotates the ring gear. The four bevel pinions and



X3307

Fig. 8—Ring Gear and Pinion For Rear Axle

the two bevel gears are carried around by the ring gear and all gears rotate as one unit. Each axle receives the same rotation and so each wheel turns at the same speed.

When the machine turns a sharp corner, only *one wheel is free to rotate* as shown at right in Fig. 9.

Again, engine power comes in on the pinion gear and rotates the ring gear, carrying the bevel pinions around with it. However, the right-hand axle is held stationary and so the bevel pinions are forced to rotate on their own axes and "walk around" the right-hand bevel gear.

Since the bevel pinions are in constant mesh with both bevel gears, the left-hand bevel gear is forced to rotate because it is subjected to the turning force of the ring gear which is transmitted through the bevel pinions.

During one revolution of the ring gear, the left-hand bevel gear makes *two revolutions*—one with the ring gear and another as the bevel pinions "walk around" the other bevel gear.

As a result, when the drive wheels have unequal resistance applied to them, the wheel with the least resistance turns more revolutions. As one wheel turns faster, the other turns slower by the same amount.




Fig. 9—Differential

Differential action can be a disadvantage when a farm tractor is plowing, for example. One wheel may lose resistance on slick ground and start spinning. To prevent a loss of power, a differential **lock** is often used to lock the two axles together until the slippery spot is passed, when they are released.

Some machines have **final drives** on the axles to further reduce speed and increase torque. They are most common on large machines which handle very big loads. Bull gears and planetary gears are the main types of gearing.

The **axles**, of course, rotate the wheels to make

the machine move, which completes our basic power train.

A complete power train in a modern tractor is shown in Fig. 10. The clutch is shown at the right, the transmission in the center, and the differential at the left.

For details on actual power trains, see these chapters:

Chapter 2—Clutches

Chapters 3 and 4—Transmissions

Chapter 7—Differentials

Chapter 8—Final Drives




Fig. 10—Complete Power Train In Modern Tractor




Fig. 11—Three Ways Of Transmitting Power

HOW POWER IS TRANSMITTED

You have seen how power is transmitted in a basic power train.

The clutch uses *friction* to transmit power, while the transmission uses *gears*. A third way to transmit power is by *fluids*, as in automatic drives.

So the three basic ways of transmitting power are:

- **Friction** (*Wheels and Belts*)
- **Gears** (*In Mesh*)
- **Fluids** (*Water Wheel Principle*)

Let's take a look at each type.

FRICTION DRIVES

Friction is caused by bringing together two surfaces made from materials that will transmit motion from one to the other. Slippage between the surfaces is a matter of engineering design. For our purposes, let's assume no slippage takes place.

Friction devices include wheels and belts.

Wheel Friction

A simple form of useable friction is obtained by a rubber-tired wheel contacting the ground (Fig. 12, top). If you rotate the wheel by hand, you will feel the rotary force tend to move you forward. The friction between the tire and the ground is transmitting your force to the ground. Since you can't move the ground, the wheel and you must move.





Fig. 12—Wheel Friction

Now suppose we suspend the first wheel above ground so it is free to rotate. Let's also suspend a second wheel in contact with the first (Fig. 12, bottom). Now if you apply a rotating force to the first wheel, the second one will rotate. Observe that the two wheels rotate in opposite directions. Thus, we can transmit power from one point to another by means of friction.

The engine clutch is a prime example of transmitting power by friction.




Fig. 13—Belt Friction

Belt Friction

Another friction drive also has two wheels, called sheaves or *pulleys*. This arrangement permits the axles to be separated by some distance. The friction coupling is provided by the continuous loop of the *belt* as shown in Fig. 13.

This gives a more efficient transmission of power than two wheels because of more surface contact. When one pulley is turned, the belt transmits the power by friction to the other wheel as shown.

Belt drives are covered in detail in Chapter 10.

GEAR DRIVES

Gears are the most common way to transmit power.

When two gears are in mesh, all slippage is gone. For this reason, gears are widely used for high-power applications.

The chain drive is another variation on the gear drive. The gears (sprockets) are not in mesh but are connected by a linked chain which also eliminates slippage (see Chapter 10 for details).

Gears will be covered in detail in the next part of this chapter.

FLUID DRIVES

Fluid drives are both the oldest and most modern ways of transmitting power.




Fig. 14—Fluid Drive In Water Wheel

The old mill water wheel (Fig. 14) is turned by water falling into its buckets.




Fig. 15—Fluid Coupling Between Two Shafts

In modern automatic drives, fluid is used as a coupling for power (Fig. 15).

In A, we start with a disk which contains vanes. If we supply a fluid, the vanes fill as shown.

In B, we rotate the disk at high speed and centrifugal force causes the fluid to move out as shown.

In C, we place a second disk above and near the first disk. Fluid now flows into the second disk as shown. The force of the fluid on the second disk will cause it to rotate in the same direction as the first one, forming a fluid coupling which transmits power.

When the disks are sealed and the fluid is under pressure, a solid coupling is formed.

This is the basic principle of fluid drives such as the fluid clutch and torque converter.

In Chapter 6, we will see how these parts are modified to *increase* the torque in a torque converter.

This completes our look at the basic power transmitting devices—**friction**, **gears**, and **fluids**.

Because gears are so basic to power trains, let's take a detailed look at them now.

GEARS

The basic elements of almost all conventional power trains are **gears**.

Gears are simply a means of applying twisting force—or **torque**—to rotating parts.

The amount of torque you can get from a source of power is proportional to the distance from the center at which it is applied.




Fig. 16—How Torque Varies With Levers

In Fig. 16, the lever has more torque as the fulcrum gets closer to the object of power application (at right). But the lever must also be rotated farther to get this torque.




Fig. 17—How Torque Varies With Gears

The same principle is used for gears in mesh (Fig. 17).

A small gear will drive a large gear more slowly but with greater torque.

The gears in a transmission are selected to give the operator a choice of both *speed* and *torque*.

Lower gear range = less speed but more torque.

Higher gear range = less torque but more speed.

The final choice of gears is a compromise to give enough of each to suit the needs of the machine and its operator.

GEAR RATIOS




Fig. 18—Gear Ratios

Gear ratio is a measure of the changes in speed and torque in the gear train.

The gear ratio between the gears in Fig. 18 is the ratio of the number of teeth on the lower gear to the number of teeth on the upper gear.

TYPES OF GEARS

A variety of gear types are used to meet the demands of speed and torque.

Gears are normally used to **transmit torque from one shaft to another**. These shafts may operate in line, parallel, or at an angle to each other.

Meshing gears must also have teeth of the same size and design. And at least one pair of teeth must be engaged at all times. Some tooth designs allow for contact between more than one pair of teeth.





Fig. 19—Gear Teeth—Two Major Types

Gears are normally classified by:

- 1) *Type of teeth.*
- 2) *Surface on which teeth are cut.*

Fig. 19 shows the two major types of gear teeth—**straight cut** and **helical cut**.

The most common types of gears are shown in Fig. 20.

STRAIGHT SPUR GEARS—These gears have straight teeth cut parallel to the axis of rotation. Normally, mating gears have one to two pairs of teeth engaged at all times. These gears are noisier and so are used mainly for slow speeds to avoid excessive vibration.

Uses: Straight spur gears are used in simple devices such as hand or powered winches. Sliding gear transmissions also use them for speed changes because they can be easily shifted by sliding on the shaft from one gear to another.

HELICAL SPUR GEARS—The teeth of a helical spur gear are cut obliquely across the perimeter of the gear instead of straight. Engagement between two teeth starts at the tooth tip of one gear and rolls down the teeth to the trailing edge. This angular contact tends to cause side thrusts which the bearings must absorb. However, helical spur gears are quieter in operation and have greater strength and durability than straight spur gears—because the contacting teeth are longer.

Uses: Helical spur gears are widely used in machine transmissions today because they are quieter at high speeds, and are durable.

HERRINGBONE GEARS—Herringbone gears are really double helical gears with teeth angles reversed on opposite sides. This causes the thrust produced by one side to be counterbalanced by the thrust produced by the other side. The two sets of teeth are often separated at the center by a narrow gap for better alignment and to prevent oil from being trapped at the apex.

Uses: Herringbone gears are best suited for quiet, high-speed, low-thrust applications where heavy loads are applied. Large turbines and generators frequently use herringbone gears because of their durability.

PLAIN BEVEL GEARS—These gears permit the power flow to “turn a corner”. The gear teeth are cut straight on a line with the shaft but at some angle between perpendicular and parallel to the shaft. The two gears are commonly called the “ring gear” (larger driven gear) and “pinion gear” (smaller driving gear).

Uses: Like the straight spur gears, the plain bevel type is used in slow-speed applications which are not subject to high impact forces. Handwheel controls which must operate some remote device at an angle use straight bevel gears.

SPIRAL BEVEL GEARS—These gears were developed for use where higher speed and strength were required while changing the angle of power flow. Their teeth are cut obliquely on the angular faces of the gears. The angle is determined by the angle between the two shafts.

Uses: Farm and industrial machines use these gears in ring gear-and-pinion sets at the drive axles. They not only change the angle of power flow, but they also reduce speed and increase force.

HYPOID GEARS—The hypoid gear resembles the spiral bevel gear but the pinion drive gear (smaller) is located below the center of the ring gear (larger). Teeth and general construction are the same as the spiral bevel gear.

Uses: The most common use for hypoid gears is in modern automobile differentials. Here they allow for lower body styles by lowering the transmission drive shaft.

PLANETARY GEARS—These are gear sets in which an outer ring gear has internal teeth which mate with teeth on smaller planet gears. These gears in turn mate with a center or sun gear. Many changes in speed and torque are possible, depending on which parts are braked and which are driven. (Operation of planetaries is explained on page 1-12.)

Uses: Planetary gears are widely used in transmissions because each set is capable of more than one speed change. The gear load is spread over several gears, reducing stress and wear on any one gear. Final drives in heavy machinery can also use these gears.

WORM GEARS—The worm gear is actually a screw (inclined plane). It is capable of high speed reductions in a compact space. The mating gear has teeth which are curved at the tips to permit a greater contact area. Power is supplied to the worm gear, which drives the mating gear. Worm gears usually provide right-angle power flows.

Uses: The most common use for the worm gear is where the power source operates at high speed and the output is slow speed with high torque. Many steering mechanisms use a worm gear connected to the steering shaft and wheel and a partial (sector) gear connected to the steering linkage. Small power hand tools frequently use a high-speed motor with a worm gear drive.




Fig. 20—Types of Gears

RACK AND PINION GEARS—This set of gears converts straight-line motion into rotary motion and vice versa. Rack and pinion gears also change the angle of power flow with some degree of speed change. The teeth on the rack are cut straight while those on the pinion are curved.

Uses: The rack and pinion can provide control of arbor presses and other devices where slow speed is involved.

PLANETARY GEARS—HOW THEY WORK

Planetary gears are simple in design, but their operation is not always well understood.




Fig. 21—Simple Planetary System

Planetary gears are similar to our solar system (Fig. 21). The **planet pinion gears** each turn on their own axes while rotating around the **sun gear**. This is much like the earth and other planets rotating around the sun. The pinion gears in turn mesh with the inside of the **ring gear**.

Notice that the sun gear, the planet pinions, and the ring gear are constantly in mesh.

The planet pinions are mounted on shafts in the carrier, and can rotate on their own axes to "walk around" the sun gear or the ring gear.

When power is applied to drive the sun gear or the planet pinion carrier, the entire system will rotate as a unit unless a restraining force is applied to hold one of the other two members of the system stationary.

When power is applied to one member of the planetary system, and a brake is applied to restrain a second member from turning, the remaining part will become a power output source as illustrated by the following examples.

When The Sun Gear Is Driven





Fig. 22—Power Flow in Planetary When Sun Gear is Driven

When the sun gear is driven (Fig. 22) and a brake is applied to the ring gear, the planet pinions "walk around" the ring gear, forcing the planet pinion carrier to rotate in the same direction as the sun gear, but at a slower speed.

When Planet Pinion Carrier Is Driven


X2040

Fig. 23—Power Flow in Planetary When Planet Pinion Carrier Is Driven

When the planet pinion carrier is driven (Fig. 23) and a brake is applied to the ring gear, the planet pinions "walk around" the ring gear, forcing the sun gear to rotate in the same direction at a higher speed.

In both cases above, one member is driven, one is braked, and the third member becomes the power output.

Depending upon which member is driven and which is braked, the planetary gives different speeds.

Double Planet Pinion Set

X3073

Fig. 24—Double Planet Pinion Set Giving Reverse Speed

When a second set of planet pinions (Fig. 24) is added to the simple planetary system, so that the two sets of planet pinions are in mesh, reverse speeds can be obtained.

Now when power is applied to the planet pinion carrier and a brake is applied to the ring gear, the planet pinions in mesh with the ring gear are forced to rotate on their axes, driving the inner planet pinions which in turn force the sun gear to rotate in the reverse direction from the planet pinion carrier.

The planetary system we have described will give low, high, and reverse speed ranges.

For an example of how this works in a planetary transmission, see Chapter 4.




Fig. 25—Backlash in Gears

BACKLASH IN GEARS

Backlash is the clearance or “play” between two gears in mesh.

Too much backlash can be caused by worn gear teeth, an improper meshing of teeth, or bearings which do not support the gears properly.

Too much backlash can result in severe impact on the gear teeth from sudden stops or reverses of the gears. Broken gear teeth and gears bouncing under impact also results from too much backlash.

Too little backlash causes excessive overload wear on gear teeth. This could result in premature gear failure.

Fig. 25 shows the normal gear mesh and gear mesh which permits too much backlash.

On the *normal gears* in Fig. 25, the clearance of the teeth at the pitch diameters is very small.

However, on the worn gears with *too much backlash*, forces cause a greater movement and a higher impact which can break the teeth or at least cause the gears to bounce.

Backlash, endplay and preload on gears and shafts is covered later in this chapter under “Adjusting The Gear Train”.

GEAR WEAR

New gear teeth have slight imperfections, but they normally disappear during break-in as the teeth are oiled and polished. After that, the teeth should have a long service life.

However, when lack of lubrication or other factors cause a gear to fail, we can examine the failure and determine the cause.

The major types of gear tooth wear and failures are shown in Fig. 26.

NORMAL WEAR—This is the normal polishing of the gear teeth as they operate. The polished surface should extend the full length of the tooth from near the root (or bottom) to the tip of the tooth. Gears which are manufactured properly, well lubricated, and not overloaded or improperly installed will show this condition after many hours of service.

ABRASIVE WEAR—Surface injury caused by fine particles carried in the lubricant or embedded in the tooth surfaces. The causes are metal particles from gear teeth, abrasives left in the gear case, or sand and scale from castings.

SCRATCHING—This is often found on gears which handle heavy loads at slow speeds. It is caused by particles of metal flaking off the gears which are larger than the abrasive particles. Generally, it indicates the wrong gear design for the load. (Do not confuse this with scoring.)



Fig. 26—Gear Tooth Wear And Failures

OVERLOAD WEAR—If the contact surface is worn but smooth, the gears have been overloaded and metal has been removed by the sliding pressure causing a depression in the length of the teeth. Continuous use will result in backlash and severe peening which may be misleading as to the real cause of the wear.

ROLLING AND PEENING—*Rolling* is the result of overload and sliding which leaves a burr on the tooth edge. Too little bearing support or too ductile a metal results in plastic flow of the metal due to sliding pressure. *Peening* is the result of backlash and the force causing a tooth to hammer on another with tremendous impact. In these cases, lubricants are forced out and metal bears directly on metal.

RIPPLING—This is a wavy surface or "fish scales" on the teeth at right angles to the direction of slide. It may be caused by surface yielding due to "slipstick" friction resulting from lack of lubrication, heavy loads, or vibrations.

SCORING—This is caused by temperature rise and thinning or rupture of the lubricant film as from too heavy loads. Pressure and sliding action heats the gear and permits metal transfer from one tooth to the face of another. As the process continues, chunks of metal loosen and gouge the teeth in the direction of the sliding motion. The temperature rise here is slow and not as high as *burning wear* (below).

PITTING—Gear teeth should not show pitting. Very minute or micro-pitting can occur and would appear as a gray surface which may advance slowly to an actual pitted condition. This type of condition is sometimes associated with thin oil film, possibly due to high oil temperatures.

SPALLING — Spalling is a common wear condition which starts with fine surface cracks and eventually results in large flakes or chips leaving the tooth face. Improperly case-hardened teeth are most often subject to this kind of damage due to the brittle nature of the metal. Spalling may occur on one or two teeth but the chips may cause other damage to the remaining teeth.

CORROSION—Corrosive wear results in an erosion of the tooth surfaces by acid. The acid is formed by moisture combining with lubricant impurities and atmospheric contaminants. Generally, the surfaces become pitted, causing an uneven

surface and distribution of stresses which lead to chipping and spalling.

BURNING—Burning is usually caused by the complete failure of lubricants or a lack of lubrication. During high stress and sliding motion, friction develops rapid heating and the temperature limits of the metal are exceeded. Burned gear teeth are extremely brittle and easily broken.

INTERFERENCE WEAR—This type of wear can be caused by misalignment of gears which places heavy contact on small areas. Also, mating of two gears with teeth not designed to work together will cause interference wear. More than one wear pattern may show up, as at teeth tips and roots.

RIDGING—These are scratches appearing near one end of a tooth, especially on a hypoid pinion gear. This can be caused by excessive loads or lack of lubrication, or by gear not properly heat treated during manufacture.

BREAKAGE—Broken teeth may be the result of many defects. Make a close study of the other teeth before judging the cause. Breakage can be caused by high impact forces or defective manufacture. To determine if breakage is due to overload or fatigue, examine the broken area closely. If the break shows fresh metal all over the break, an impact overload was the cause. If the break shows an area in the center of fresh metal with the edges dark and old-looking, the breakage was due to fatigue which started with a fine surface crack.

CRACKING—These failures tend to be caused by improper heat treating during manufacture. Improperly machined tooth root dimensions can also result in cracking. Most heat treat cracks are extremely fine and do not show up until a gear has been used for some time.

SUMMARY: GEARS

Gears are very basic to the function of power trains. In general, excessive backlash or endplay, or improper lubrication can lead to gear failures in the system.

Always be aware of the forces which are at work when gears are operating under load.

Alignment and fit are very important to insure that each tooth absorbs its share of the load and that the gears are supported to resist thrust and twisting forces.




Fig. 27—Bearings—Three Types

BEARINGS

Bearings have two major jobs in a power train:

- 1) *Reduce friction*
- 2) *Support a rotating shaft*

We are mainly concerned with *anti-friction* bearings, those that give a rolling contact between mating surfaces (Fig. 27). There are three main types:

- **Ball**
- **Roller**
- **Needle**

All these bearings are made of:

- 1) *Two hardened-steel rings called races (Fig. 28).*
- 2) *Balls, rollers or needles which roll between the two races.*
- 3) *Optional separators to space the rolling elements around the bearing.*

On some bearing, the outer or inner race is omitted. Then the rolling elements are in direct contact with the shaft or other mounting (as in most needle bearings).




Fig. 28—Basic Parts Of A Bearing

When two races are used, one race is normally pressed or fixed on a shaft or in a bore, while the other race is free to turn with the rolling elements. This is part of the "anti-friction" feature of these bearings.




Fig. 29—Load Forces Acting on Bearings

BEARING LOADS

Bearing Loads (Fig. 29) may be of two types:

- 1) *Radial loads—forces perpendicular to the axis of rotation.*
- 2) *Thrust loads—forces parallel to the axis of rotation.*

Many bearings must be able to carry both radial and thrust loads.

Now let's look at each type of bearing in more detail.

BALL BEARINGS

Ball bearings support a shaft for radial forces as well as thrust forces (Fig. 29). The shaft must be aligned in the bearing bore or the bearing will bind and quickly wear out.

To withstand various radial and thrust forces, the ball bearing types shown in Fig. 30 are widely used. (Thrust forces on each bearing as shown with small blue arrows.) Ball bearings are also available in self-aligning types which compensate for shaft angles in relation to the bearing mount.




Fig. 30—Common Types of Ball Bearings




Fig. 31—Common Types of Roller Bearings

ROLLER BEARINGS

Roller bearings are basically the same as ball bearings with the balls replaced by rollers. Often the outer race can be removed without the rollers falling out. Again, the roller bearing can handle radial or thrust forces, or both.

Roller bearings can be designed to handle heavy thrust loads.

For heavy loads—both radial and thrust—*tapered* roller bearings are commonly used. A good example of this is in front wheel bearings. Tapered bearings are also used where high preloads are required on shafts or gears to support thrust.

Fig. 31 shows the common types of roller bearings.

NEEDLE BEARINGS

Needle bearings (Fig. 32) are much like roller bearings except that the rollers are thinner. Also, most needle bearings have no inner race but roll directly on the shaft. The rollers are not separated, but are tightly packed for added support of the shaft.

Needle bearings can support heavy radial loads but must not be placed under thrust loads.




Fig. 32—Needle Bearing

Needle bearings are used in compact locations where relatively high radial loads must be supported. This bearing is frequently located inside a gear which must run free on a shaft or act as an idler. The length of the rollers and their tight packing gives the gear a good support and alignment. Planetary gears are usually supported by needle bearings.

While servicing, if there is doubt about the condition of a needle bearing, replace the bearing.

For more information on bearings refer to FOS-54B Bearings and Seals.

ADJUSTING THE GEAR TRAIN

When a gear train is operated, reaction loads from gears, etc. are transmitted to the bearings and the various parts deflect.

For this reason, the gear train must normally be adjusted for the proper fit between parts.

Three kinds of adjustments are used:

- **Backlash**—clearance or “play” between gears in mesh
- **Endplay**—end-to-end movement in a gear shaft due to bearing clearances
- **Preload**—a load within the bearings set up by adjustment

Let's look at each one and then see how they all work together when adjusting an actual gear train.

BACKLASH IN GEARS

Too much **backlash** in gear trains is the result of: 1) improper mesh between gears or 2) lack of support in bearings.

The result of too much backlash can be broken gear teeth or bouncing of gears under impact forces.




Fig. 33—Checking Backlash On Gear

Backlash is often adjusted to a specified reading on assembled gears (Fig. 33). Move ring gear in toward pinion to reduce backlash, or away from pinion to increase (Fig. 35, step 4).

The dial indicator is mounted so that it registers the full rotary movement of the ring gear shown.

To adjust the backlash reading, shims are often used (see below).

ENDPLAY IN GEARS AND SHAFTS

Endplay refers to a measurable axial looseness of a bearing. Endplay is measured in an unloaded condition.

Preloading is often used to take up the slack and load the bearings (see below).




Fig. 34—Checking Endplay On Gears and Shafts

To check endplay (Fig. 34), a dial indicator is mounted against the side of a gear or the end of a shaft. The gear or shaft is then pried in both directions and the readings noted. The difference between the two readings is the endplay.

Shims or adjusting nuts are widely used to adjust endplay.

PRELOADING OF GEAR TRAINS

If the loads are heavy or the thrust too great, gear trains are often **preloaded** to reduce the deflection of parts. This preload must fit the design of the bearings and the strength of the parts.

If bearings are preloaded too tight, they will heat up and fail. If they are set too loose, the supporting parts will deflect too much, causing them to wear rapidly.

Gear trains are preloaded by shims, thrust washers, adjusting nuts, or by using double-race bearings.

Let's use all three of these adjustments—backlash, endplay, and preload—in adjusting an actual gear train.


EXAMPLE: ADJUSTING RING GEAR AND PINION

Fig. 35—Adjusting Ring Gear and Pinion
(A Typical Example)

A typical ring gear and pinion set is shown in Fig. 35. The pinion shaft at the top meshes with the ring gear at the bottom. The ring gear is supported in two quills which bolt into the sides of the transmission housing. The adjusting shims are shown in blue.

When the gear set is assembled, it is adjusted in four steps:

1. Relation of pinion to ring gear is adjusted with shims under the lower shaft bearing.
2. The pinion shaft bearings are preloaded by using shims under the upper shaft bearing. (The shaft is normally installed with extra shims, endplay is checked, and shims are removed to equal the endplay **plus** the specified preload.)
3. The ring gear bearings are preloaded by shims under the side quills. (Here again the ring gear


is normally installed with extra shims, endplay is checked, and shims are removed to equal the endplay **plus** the recommended preload for the bearings.)

4. Backlash between the ring gear and pinion is adjusted by transferring shims under the side quills. Backlash is checked at several points around the ring gear as shown in Fig. 33. To decrease the backlash, shims are transferred from the left to the right quill. To increase backlash, shims are transferred from the right to the left quill. The same shims must be added to the opposite quill as removed from the other one or the preload on the ring gear bearings will be changed.

This is a typical adjustment for a gear train but there are many variations. Consult the machine Technical Manual for the exact steps and readings.

SUMMARY: POWER TRAINS

We have seen how a basic power train works and have looked at the basic elements (Fig. 36).



X2053

Fig. 36—Parts Of A Machine Power Train

In the rest of this book, we will look at various types of power trains in detail, starting with clutches in Chapter 2.




Fig. 37—Complete Power Train In Industrial Crawler Tractor





Fig. 38—Complete Power Train In Modern Farm Tractor



X2050

Fig. 39—Complete Power Train In Four-Wheel Drive Machine

TEST YOURSELF

QUESTIONS

1. Match each item below with the correct job it performs listed at the right.
 - a. Clutch 1. Equalizes power for turning.
 - b. Transmission 2. Connects and disconnects power.
 - c. Differential 3. Selects speeds and direction.
2. Two gears are in mesh. Gear A has 12 teeth, while gear B has 24 teeth. When gear A has made one complete revolution, how far has gear B traveled?
 - 2 revolutions
 - $\frac{1}{2}$ revolution
 - 4 revolutions
3. True or false? "For speed reduction in low gears, a large gear drives a smaller gear."
4. Does reducing gear speeds increase or decrease the twisting force of the gear shaft?
5. True or false? "When a machine turns, the outside drive wheel must turn faster."
6. What are the three basic ways of transmitting power?
7. Name an example of each type of transmitting power.
8. Name one advantage of helical gear teeth over straight spur gear teeth.
9. Name the two major jobs of bearings in a power train.
10. (Fill in the blank.) "Bearings are often _____ to offset the thrust of the power train."
11. (Fill in the blank.) "Looseness in a power train from end to end is called _____."
12. (Fill in the blank.) "Clearance between gear teeth in mesh is called _____."

(Answers on page 9 at end of text.)

CLUTCHES / CHAPTER 2




Fig. 1—Clutch In Complete Power Train


INTRODUCTION

The **clutch** is a vital link in the power train. It connects and disconnects power between the source (engine) and the receiver (transmission).

Other clutches connect and disconnect power to auxiliary mechanisms in the gear train itself.

A clutch is used in all machines except some that have hydraulic assist drives or torque converters.

Chapter 1 explained the basic reasons for a clutch. Now we are going to see how the various clutches operate.



X2057

Fig. 2—Relation Of Engine Clutch To Power Train

TYPES OF CLUTCHES

Six types of clutches will be covered in this chapter:

- **Disk- and Plate-Type**—one or more plates are brought together to transmit torque.
- **Band-Type**—an outside band is tightened over a rotating part to transmit torque.
- **Overrunning-Type**—engagement is allowed in one direction, but the unit freewheels in the other.
- **Magnetic-Type**—a magnetic field holds two parts together, allowing them to rotate as a unit.
- **Cone-Type**—two cone-shaped parts are engaged to transmit torque.
- **Expanding-Shoe-Type**—an inner shoe is expanded to contact an outer part to transmit torque.

Let's look at each type in detail.

DISK- AND PLATE-TYPE CLUTCHES

Two major types of *disk* clutches are used:

- **Dry-Type Disk Clutch**—operates dry, cooled by air.
- **Wet-Type Disk Clutch**—operates in either oil bath or spray, cooled by oil.

Let's take a look at each type.

DRY-TYPE DISK CLUTCH (STANDARD)




Fig. 3—Dry-Type Disk Clutch (Standard)

The standard dry-type clutch shown in Fig. 3 has a driven disk with friction facing (red areas) molded to both sides.

The clutch pressure plate housing is bolted directly to the engine flywheel, while the driven disk is splined to the transmission input shaft.

Operation When Disengaged

When the clutch pedal is depressed, the clutch release bearing moves forward against the operating levers (Fig. 3). As the levers pivot, the clutch bolts pull the pressure plate rearward to compress the clutch springs and release the pressure applied to the clutch disk. This separates the driven disk from the flywheel and pressure plate. Power flow is now stopped between the engine flywheel (rotating) and the transmission input shaft (where the driven disk is now rotating freely).




Fig. 4—Dry-Type Clutch Disk and Pressure Plate (Standard)

Operation When Engaged

When the clutch pedal is released, the compressed clutch springs force the pressure plate to move forward to apply pressure on the clutch disk. Since the clutch bolts are secured to the pressure plate, the operating levers force the clutch release bearing rearward. This allows the plate to clamp the driven disk against the flywheel again. Now the flow of power is connected between the engine and the transmission input.

DRY-TYPE DISK CLUTCH (HEAVY DUTY)

In the heavy-duty disk clutch, both driving and driven members are used.

The **driving** parts are the flywheel, pressure plate, and possibly an intermediate plate.

The **driven** parts are the clutch disks and the clutch shaft of the transmission.

A release bearing is used to disengage the clutch, and spring pressure holds the clutch engaged.

Operation

The clutch shown in Fig. 5 is engaged. Notice that the release bearing is away from the release levers. In this position, the clutch springs exert full pressure on the clutch plate, holding the clutch disk against the flywheel.




Fig. 5—Heavy Duty Disk-Type Clutch (Engaged)

To disengage the clutch and interrupt the flow of power, the release bearing is pushed forward by the clutch fork. It contacts the release levers, causing them to pivot and pull the clutch plate

back away from the clutch disk. The driving parts now rotate without moving the clutch disk and power is interrupted.

Now let's look at the individual parts of a heavy duty disk-type clutch (Fig. 6).

Flywheel

The engine flywheel usually provides a machined surface for the clutch to contact (see Fig. 5).

In some cases a special plate is bolted to the flywheel to provide this surface.

The purpose of the flywheel is:

- 1) As a balancer for the engine, it levels out power impulses.
- 2) It provides a surface from which the clutch can pick up torque for transfer to the drive mechanisms.
- 3) It provides a ring gear for the engine starting motor to contact.




Fig. 6—Parts Of A Disk-Type Clutch (Heavy Duty)

Pressure Plate Assembly

The pressure plate engages and releases the clutch disk. A typical plate assembly has a clutch plate, bracket, release levers, and springs.




Fig. 7—Pressure Plate Assembly (Heavy-Duty)

The heavy *plate* actually engages the clutch by pressing the disk against the flywheel surface.

The *bracket* mounts the *release levers* and *springs*. The levers pivot in bosses on the plate so that when the levers are pressed down by the release bearing, the plate is lifted from the clutch disk.

The *springs* under each release lever push the plate down again when the clutch is engaged and hold the disk solid. This happens when the force on the levers is released.

Some clutches also have centrifugal weights which add extra pressure for holding the clutch plate against the clutch disk.

Intermediate Plate

The intermediate plate is used in heavy-duty clutches having two disks and is placed between the disks.

When the clutch is engaged, the first clutch disk is held between the clutch pressure plate and intermediate plate, and the second clutch disk is held between the intermediate plate and the flywheel.

When disengaged, the intermediate plate, flywheel and pressure plate assembly rotate as a unit. The clutch disks which are not in contact remain idle.

Clutch Disks

There are two kinds of clutch disks—**rigid** and **flexible** (Fig. 8).

A *rigid* or solid clutch disk is a solid circular disk fastened directly to a center splined hub.

The *flexible* clutch disk is easily recognized by the torsional dampener springs located in circles around the center hub. The purpose of the flexible-type disk will be defined more clearly under the "Dampener" section of this chapter, page 2-15.

Asbestos wire-woven material is the most common lining for these clutch disks. A more recent product is ceramic material, a clay and metal substance which is oven-baked.

A lining must be long-wearing, heat-resistant, and still able to overcome slippage.

Linings are attached to the clutch disk by bonding or riveting.




Fig. 8—Heavy Duty Clutch Disks—Two Types




Fig. 9—Clutch Shaft

Clutch Shaft

The clutch shaft projects from the front of the transmission (Fig. 9).

Most clutch shafts have a smaller shaft or pilot which projects from the front end. This pilot rides in the pilot bearing in the engine crankshaft flange.

The splined area is provided for the clutch disk. It must allow the clutch disk to move laterally along the spline but must not allow a rotary rocking motion.

A machined area between the transmission front cover and the spline mounts the release bearing carrier.

A thrust-type ball bearing is the most common release bearing. It rests on this area of the shaft when the clutch is engaged.

SERVICING OF DRY-TYPE DISK CLUTCHES

1. Always check the clutch release and pressure mechanisms. Pressure should be even all around the clutch. The release levers must be adjusted so that contact with the release bearing will be uniform and the pressure plate will release evenly.

CAUTION: Use proper equipment and methods as prescribed by your Technical Manual when dismantling the direct-pressure clutch. Spring pressure must be kept under control and released evenly to avoid personal injury.

2. After rebuilding the clutch, check the clutch pedal free travel (Fig. 10). When the clutch is engaged, a retracting spring pulls the pedal back so that the release bearing fork does not contact the release bearing. Another spring pulls the release bearing carrier back so that the bearing does not contact the clutch plate levers. Thus, in normal driving, with the clutch engaged and




Fig. 10—Clutch Pedal Free Travel Adjustment

the driver's foot removed from the clutch pedal, the clutch release bearing is not turning. This is assured by having the correct free travel on the pedal (Fig. 10).

3. Always check the clutch release setting during clutch service. As the clutch disk facings wear, the clutch disk becomes thinner. The clutch plates then move closer to the flywheel in order to engage the disk. As the pressure plate moves closer to the flywheel, the release fingers move closer to the release bearing. After long operation, these fingers will contact the release bearing and it will run all the time.

Additional wear on the clutch disk cannot be taken up by the pressure plate because the release fingers are contacting the release bearing. The clutch will then start to slip and the release bearing will wear out rapidly.

We will discuss the clutch release adjustment under "Manual Actuating Mechanisms" later in this chapter.

LUBRICATION OF DRY-TYPE DISK CLUTCHES

Do not use too much lubrication on the clutch pilot bearing, release bearing, or release fork. Excessive lubrication can lead to erratic operation of the clutch.

Some release bearings are sealed units that never need lubrication.

USES OF DRY-TYPE DISK CLUTCHES

Dry clutches are widely used on large trucks and heavy industrial units. The main advantage is in the larger contact area. They are not recommended where frequent disengaging or slipping is required because of heat build-up.

WET-TYPE DISK CLUTCH

The wet-type disk clutch operates in an oil bath or spray. Operation is similar to the dry-type clutch.

Operation

This clutch is either mechanically or hydraulically actuated.

To engage the clutch, a hydraulic or mechanical force is exerted on the rear plate of the clutch pack. As the force increases, more power is transmitted.

Operation in oil provides these advantages: *Reduced wear and cooler operation.*

Disks for Wet Clutches

One major difference between the dry- and wet-type clutch is in the disk facing material. In a wet clutch, this material must grip when soaked in oil.

Crosshatch marks are normally found on the facing surface of the wet disk. Cork was a common lining material in the past, but new materials are used now. Bi-metal plates without lining are often used for this clutch. An example of bi-metal plates is *steel driving plates and bronze driven plates.*

Servicing

Consider these points when servicing a wet-type clutch:

- *Is the oil being circulated properly?*
- *On units equipped with pumps, are the lines clogged?*
- *Is the pump handling its full capacity of oil?*
- *Is the inlet line or filter dirty?*

Before disassembly, check the oil level. Look for traces of oil leakage.

During repair, check all the oil seals—at the clutch release forks, flywheel and clutch shaft end of the housing. Replace badly worn seals. If a seal has small cracks on the lips or retainer, it should be replaced. If the seal material appears compressed and is glazed, it is wise to replace it.

The best practice with seals is, "If in doubt, replace".

Failure to keep oil in the clutch housing will cost a lot more in repairs than the price of an oil seal.

For details, see the machine Technical Manual.


Lubrication

Use the type and grade of oil specified by the manufacturer.

Add oil if necessary to retain the proper level. This will avoid clutch failure from scoring or heat warpage.

Because these clutch disks are both lubricated and cooled by oil, the proper oil supply is vital to normal service life.

BAND-TYPE CLUTCHES



X2066

Fig. 11—Band-Type Clutch

The band-type clutch is operated by a band or belt as shown in Fig. 11. This clutch is different from the others in that it receives its torque from the *outside* surface of a rotating member, not on the side or on the same axis.

OPERATION

To engage, the linkage arms (Fig. 11) are drawn closer together, causing the band to tighten. The band and rotating member then revolve as a unit, transmitting torque.

Advantages include the ability to absorb shock

loads, more uniform wear of linings, and less heat and wear. A more constant torque is provided because of the large-diameter contact. The lining materials used include leather, wood and asbestos-woven material.

USES

Band-type clutches are adaptable to large stationary equipment rather than mobile equipment because of their bulky size.

SERVICING


Servicing of the actual clutch components is easy. Watch for wear on the flywheel caused by the rivets. To insure long life of the lining, the flywheel must be concentric.

OVERRUNNING CLUTCHES

An overrunning clutch will automatically engage in one direction, but will freewheel in the other.

Fig. 12 shows a simple overrunning clutch. In the top picture, the entire shaft is revolving counter-clockwise. As long as the drive line revolves as indicated the clutch will remain **engaged**.

If we stop the source of power or reverse the rotation of either of the members, the clutch will overrun or **freewheel** as shown in the lower picture in Fig. 12. Engagement will not take place until the drive line attains more speed than the driven line.



X2067

Fig. 12—Overrunning Clutch

TYPES OF OVERRUNNING CLUTCHES

Overrunning clutches have three basic types:

- Roller
- Cam or Sprag
- Spring

Let's look at each one.



Roller-Type Overrunning Clutch

Fig. 13—Roller and Sprag-Type Overrunning Clutches

The upper part of Fig. 13 shows a side view of a roller clutch. Notice that there is an outer member and an inner member. As the center hub turns as shown, the rollers move outward on the inclined ramp until they wedge between the outer and inner members. The members then revolve as a unit to transmit torque.

If we reversed the inner member, the rollers would be free to return down the ramp against the stops. In this position, there would be no contact between the inner and outer member, and they would disengage and freewheel.

Cam- Or Sprag-Type Overrunning Clutch

The sprag-type clutch works in much the same manner as the roller.

The lower part of Fig. 13 shows a sprag- or cam-type clutch. Sprags or cams take the place of the rollers.

The clutch is shown in an engaged position.

To *disengage* the clutch or freewheel, the inner member would have to either stop or turn clockwise. This would allow the cams or sprags to lean forward. The band of material passing through the sprags prevents them from lying flat.

To *engage* the clutch, the inner member rotates counterclockwise as shown. This causes the sprags to stand upright, locking them between the inner and outer members. The members held together by the sprags then rotate as a unit, transmitting the torque.




Fig. 14—Sprag Type Clutch

Spring-Type Overrunning Clutch




Fig. 15— Spring-Type Overrunning Clutch

The spring-type clutch is restricted to smaller applications. A coil spring is wrapped lightly around a shaft or collar (Fig. 15). When the spring is rotated in one direction, it tightens on the shaft and drives it. When rotated in the other direction, it loosens and does not drive.

SERVICE OF OVERRUNNING CLUTCHES

Refer to your Technical Manual for information on servicing and lubricating these units. Failure to freewheel defeats the purpose of this clutch and can result in costly damage.

MAGNETIC CLUTCHES

There are two types of magnetic clutches:

- Direct
- Indirect

In the DIRECT TYPE a magnetic field is set up which draws the driving and driven plates together.

In the INDIRECT TYPE a magnetic field is set up between the inner and outer members, which draws fine metallic particles to form a solid connection between the members. The greater the mass of particles, the greater the transfer of torque.

OPERATION

The operation of magnetic clutches will be covered in detail under "Electrical Operating Mechanisms" later in this chapter.

USES


Magnetic clutches are used where frequent engaging and disengaging is required. This electrical clutch gives either positive drive or slippage which cushions any shock loading.

CONE-TYPE CLUTCHES

The cone-type clutch is made up of two cone-shaped members (Fig. 16).

One member provides an internal machined surface for transferring torque and serves as a drive member. The other member provides an external lined surface for picking up the torque and serves as a driven member.

The material used for lining is usually woven asbestos bonded to the cone surface.



X2071

Fig. 16—Cone-Type Clutch

OPERATION

The cone-type clutch is engaged as follows:

As the throw-out bearing moves on the driven shaft, it slides the driven member forward (Fig. 16). The outer lining of the driven member contacts the inner surface of the revolving drive member to transmit the torque.


USES

The cone clutch was at one time used in trucks and autos, but now is used more for machine auxiliary power trains.

EXPANDING SHOE CLUTCHES

The expanding shoe clutch can be operated either *mechanically* or *centrifugally* (Figs. 17 and 18).

OPERATION




X2072

Fig. 17—Expanding Shoe Clutch (Mechanical Type)

To engage the **mechanical** shoe clutch, a release bearing is pushed forward (Fig. 17). This pivots the links and expands the shoes out against the outer member.

Moving the bearing back releases the pressure on the shoes, disengaging the clutch.



X2075

Fig. 18—Expanding Shoe Clutch (Centrifugal Type)

The **centrifugal** clutch (Fig. 18) has an inner member with vanes spaced around the hub. The outer

member closes the end of the channels formed by the vanes. Shoes are placed in the channels and are *free-floating*.

When the inner member rotates at a high speed, the shoes move outward and contact the outer member. The faster the inner member rotates, the greater the centrifugal force holding the shoes against the outer members. The vanes help to hold the shoes and thus form a somewhat solid connection between the two members.

The clutch disengages automatically once the rotating drive member slows down.

OTHER TYPES OF CLUTCHES

We have discussed mechanically- and electrically-operated clutches. New clutches are available using **pneumatics** (air) or **hydraulics** (oil) for control.

PNEUMATIC CLUTCHES

The air-actuated clutch is a clutch pack which contains a small rubber tube. This tube is positioned behind a driven member and a fixed member.

To engage the clutch, a valve is opened and air is forced into the tube, causing it to expand. This expansion forces the driven plate against the drive plate. The higher the air pressure, the greater the force exerted by the tube against the driven plate. Air pressure is decreased to disengage the clutch.

This clutch provides smooth engagement because the rubber tube absorbs the shocks.

HYDRAULIC CLUTCHES

Hydraulic clutches work in much the same way as the pneumatic clutch, but use oil instead of air.

Oil is forced into a chamber between the fixed and moving driven members. A valve is then opened, allowing oil to flow into the chamber. As oil pressure builds up, the walls of the chamber are forced outward, causing contact between the driven and drive members. The amount of pressure exerted on the clutch disk is regulated by the pressure of the oil in the chamber.

These clutches are also fairly shock-proof.




Fig. 19—Standard Mechanical Linkage For Operating Clutch

SLIP CLUTCHES

Another type of clutch is the **slip clutch**. Its purpose is to allow slippage at moments of excessive demand or shock. It serves as a circuit breaker or safety device in power trains.

This clutch is covered in detail in Chapter 10 of this manual.

CLUTCH OPERATING MECHANISMS

Clutches can be operated in three major ways:

- Mechanically
- Hydraulically
- Electrically

We have also mentioned pneumatics, or air, but let's concentrate on the three controls listed above.

MECHANICAL CLUTCH CONTROLS

Mechanical operation of clutches is the using of

linkages and springs to help in manually engaging and disengaging. There are two basic types:

- 1) Standard
- 2) Over-Center

STANDARD LINKAGE is the most common; the clutch remains engaged unless a pedal is pushed and held.


OVER-CENTER LINKAGE is where mechanical advantage is used to lock the clutch engaged or disengaged.

Standard Linkage

With standard linkage (Fig. 19), foot motion on the clutch pedal moves through the linkage to the clutch release bearing fork. This pushes the release bearing against the clutch release levers, releasing or disengaging the clutch. Some clutches use springs which serve as aids in disengaging and also as return springs when the clutch is engaged.

Over-Center Linkage

Fig. 20 shows an expanding shoe clutch with an over-center linkage to lock it in place while engaged or disengaged.



X2075

Fig. 20—Over-Center Linkage For Locking The Clutch While Engaged or Disengaged

When the center collar is moved forward, the two arms attached to it move outward. An *on-center* position is obtained when the arms are in line with each other. This is the point of maximum pressure.

If we move the collar ahead still further against the stop, the arms are in an *over-center* position and some of the pressure is relaxed. The collar cannot move ahead because it is against the stop. Rearward movement is impossible unless assistance is provided to overcome the high pressure at the on-center position.

This type of mechanism has the advantage of being able to lock either engaged or disengaged without keeping a grip on the lever or pedal.

Service of Mechanical Clutch Controls

When repairing the clutch, always examine the linkage.

Worn bushings, bent rods, broken springs and damaged cotter pins can result in excessive force being required to operate the clutch.

Clutch pedal free travel is often used as a guide to conditions inside the clutch.


The actual free pedal is more easily determined if checked by hand and should be the clearance between the clutch release yoke fingers and the release bearing housing.

Clutch pedal free play varies; set it according to Technical Manual instructions.

Whenever free pedal travel falls below $\frac{1}{2}$ inch (13 mm), the clutch should be adjusted internally. If free pedal travel is not then restored to about $\frac{1}{2}$ -to $1\frac{1}{4}$ -inches (13-44 mm), readjustment of the external linkage may be necessary.

Check the release yoke movement to verify that free pedal travel is actually the release bearing clearance, and not lost motion in linkage due to worn clevis eyes and pins, or worn bushings and shafts at the clutch pedal or linkage arms.

HYDRAULIC CLUTCH CONTROLS



X2076

Fig. 21—Hydraulic Clutch Controls

A **master** cylinder similar to the brake master cylinder is attached to the clutch pedal (Fig. 21). A **slave** cylinder is connected to the master cylinder by flexible pressure hose or metal tubing. The slave cylinder is also connected to the clutch release yoke lever.

Movement of the clutch pedal actuates the clutch master cylinder. This movement is transferred by hydraulic pressure to the slave cylinder, which in turn actuates the clutch release yoke lever, disengaging the clutch.

Uses

Hydraulic clutch controls are used on large units which require high pressure to disengage.

By using hydraulics, a small force can be multiplied and used effectively to disengage the clutch.

Service

1. Adjust the clutch pedal free travel per the Technical Manual.
2. Watch for leaking seals, low fluid level, broken or kinked lines, and leaking pistons in the cylinders.
3. Always bleed the air from the system after repair or replacement of parts. In most designs, a special screw is provided to allow bleeding the air from the system.
4. Check the fluid level in the reservoir and add oil if necessary after bleeding the system.
5. Adjust the slave cylinder rod to set the clutch throwout bearing at the proper position.

ELECTRICAL CLUTCH CONTROLS

Electrical clutch controls may be one of two types:

- **Direct-Action**
- **Indirect-Action**

Let's look at each one.

Direct-Action Controls




Fig. 22—Direct-Action Electrical Control For Clutch

The direct-action clutch consists of a field coil assembly, rotor unit, face plate, condenser and operating switch (Fig. 22).

When the switch is actuated, current through the field coil inside the rotary assembly sets up a magnetic field which draws the clutch facing against the facing on the rotor assembly. (The face plate is free to slide on the drive studs of the mechanism). Power is then transmitted from the drive pulley through the face plate, rotor, and hub to the drive mechanism.

When the switch is operated again, the magnetic field is collapsed. The face plate is freed from the rotor and the transmitting of power to the mechanism is instantly stopped.

An air-conditioner compressor clutch is an example of a direct action clutch. For more information on air conditioning compressors and clutches, see FOS "Air Conditioning" and Technical Manual.




Fig. 23—Indirect-Action Electrical Control For Clutch

Indirect-Action Controls

This clutch consists of a driving member containing a coil, an inner driven member, and a mixture of magnetizable metal and dry lubricant (Fig. 23).

When the coil is energized, the fine metal particles mixed with dry lubricant are driven together in a strong bond which transmits the load. The mixture is literally "frozen" and "unfrozen" in direct proportion to the amount of current applied.

Any desired amount of slippage or solid drive can be obtained by increasing or decreasing the current flow.

Service Of Electrical Clutch Controls

If the clutch suddenly loses power and fails to function, look for a failure in the electrical circuit.

First check the electrical connections, wires, switch and the circuit breaker in the switch.

If these components are okay, check the voltage to the field and amperage of the field.




Fig. 24—Testing Field Coil In Electrical Clutch

To check the voltage to the field, the amperage of the field or the resistance of the field, use a battery eliminator (Fig. 24) or a storage battery and voltmeter. For testing details, see the FOS "Electrical Systems" manual, Chapter 8.

Check the specifications on each clutch for correct input, amperage, and resistance per the machine Technical Manual.

DAMPENERS




Fig. 25—Dampener Built Into Clutch Disk

The dampener is a shock-absorbing feature built into a flexible clutch disk (Fig. 25). The primary purpose of a flexible disk is to absorb power impulses from the engine which would otherwise be transmitted directly to the gears in the transmission.

A flexible clutch disk has torsion springs and friction disks between the plate and hub.

When the clutch is engaged, the springs cushion the sudden loading by flexing and allowing some twist between the hub and plate.

When the "surge" is past, the springs release and the disk transmits power normally.

MAINTENANCE OF CLUTCHES

Here are some things to watch for when servicing clutches:

1. Use care when disconnecting the clutch linkage. A bent rod or damaged carrier can result in lost motion, hard operation, or faster wear.
2. Don't let the full weight of the transmission rest on the clutch shaft. Use the proper hoists or jacks and keep the parts aligned when separating a machine. Failure to do so will result in damage to the clutch disk and release bearing.
3. Mark the pressure plate assembly and flywheel before removing the pressure plate. When assembled, the unit can be matched with the marks and engine balance maintained. When replacing the entire unit, clutch balance is not so critical because the new unit will be static-balanced. Rear crankshaft oil seal failure is often the result of an unbalanced clutch.
4. After removing the pressure plate assembly, check these four areas: clutch plate, clutch disk, flywheel plate and release bearing.

CAUTION: Use proper equipment and methods prescribed by the Technical Manual when dismantling the pressure plate assembly. Spring pressure must be kept under control and released evenly to avoid personal injury.

CLUTCH PLATE MAINTENANCE




Fig. 26—Checking Tension of Clutch Springs




Fig. 27—Checking Clutch Plate For Warping

The clutch plate must be free from ridges, score marks and rough spots. Check the spring tension in the pressure plate assembly (Fig. 26) to make sure the plate is contacting evenly. Watch for excessive wear on release levers. Replace weak or broken springs. If the clutch plate is warped (Fig. 27), replace it.

CLUTCH DISK MAINTENANCE

The clutch disk is actually the heart of the clutch. Check for high and low spots of wear on the friction facings (Fig. 28). On riveted linings, use the level of material above the rivet head as an indicator of wear. Replace the linings if the rivet heads are flush or just below the outer surface.




Fig. 28—Clutch Disk

Replace the disk if it appears glazed or cracked. Check any cushion springs and replace if damaged.

Make one last check of the clutch disk: Slide the disk onto the clutch shaft of the transmission. It should slide easily without restriction. If the disk will rock back and forth or from side to side, replace it. This may mean that the splines are badly worn. Try a new disk on the clutch shaft. If you get the same motion, the clutch shaft is worn and it will have to be replaced.

A good indication of clutch alignment is the clutch disk hub. If there is uniform wear along the splines, this means the clutch is aligned. If there is excessive wear on the front of the spline, this means the clutch is misaligned.

FLYWHEEL MAINTENANCE



Fig. 29—Checking The Flywheel Friction Surface For Roughness

The engine flywheel surface should be relatively free from roughness and ridges to engage the clutch correctly. Check it with a straightedge and feeler gauge (Fig. 29).

Look for heat checks on the flywheel surface. If the check markings are excessive, the flywheel must be replaced.

If the pilot bearing for the transmission input shaft appear out-of-round or badly worn, it should be replaced. Score marks on the pilot shaft indicate a bearing failure.

CLUTCH RELEASE BEARING MAINTENANCE


Check the release bearing to see if it rotates freely. If in doubt about the wear or lack of lubrication, replace this bearing.

SUMMARY: CLUTCH MAINTENANCE

When the clutch is disassembled for repair, take a few minutes to inspect all associated parts. This could prevent future problems and expense.

A rule of thumb for clutch repairs might be, "If in doubt, replace". Consider what is involved in the job. Will it be worth saving a few dollars now and having to do the entire job again in a few months?

We have given you the basic things to look for, but they are not the complete story. Remember these points and use your machine Technical Manual as a further guide for each clutch.



X2081

Fig. 30—Clutch Troubles

TROUBLE SHOOTING OF CLUTCHES

The eight basic clutch troubles are:

- **Chattering:** *especially in low or reverse speeds.*
- **Dragging:** *or failure to release promptly and fully, thus making gears hard to shift.*
- **Squeaks:** *particularly when pedal is depressed.*
- **Rattles:** *especially at low speeds or standing.*
- **Grabbing:** *violent and sudden engagement.*
- **Slipping:** *failure to transmit full power.*
- **Vibrations** *at either high or low speed or periodically.*
- **Failure to transmit power at all.**

Note that different clutch problems can have the same cause. For example, oil or grease on the clutch disk facings can cause the clutch to *slip*, but may also make it *chatter*, *drag*, or *grab*.

CHATTERING

1. Oil or grease on clutch disk facings.
2. Glazed or worn facings.
3. Worn, loose or spongy engine mountings.
4. Worn or loose splines in clutch hub or on clutch shaft.
5. Wear or looseness in universal joint, differential, or drive axles.
6. Splined disk hub sticking on splined shaft.
7. Cracked or scored pressure plate or flywheel face.
8. Warped clutch disk.
9. Warped pressure plate.
10. Pressure plate sticking on driving studs.
11. Sticking or binding release levers.
12. Unequally adjusted release levers.
13. Unequal length or strength of clutch springs.
14. Bent clutch shaft.
15. Misalignment of power train.

DRAGGING

1. Oil or grease in clutch.
2. Warped clutch disk.
3. Splined disk hub sticking on splined shaft.
4. Sticking pilot bearing or bushing.
5. Sticking release sleeve.
6. Warped pressure plate or clutch cover.
7. Broken disk facing.
8. Accumulation of dust in clutch.
9. Incorrect clutch or pedal adjustment.
10. Engine idling too fast.
11. Misalignment of parts.

SQUEAKS

1. Clutch release bearing needs lubrication.
2. Pilot bearing in flywheel needs lubrication.
3. Release sleeve needs lubrication.
4. Misalignment.

RATTLES

1. Loose hub in clutch disk.
2. Worn release bearing.
3. Worn release part.
4. Worn pilot bearing.
5. Worn splines in hub or on shaft.
6. Worn driving pins in pressure plate.
7. Wear in transmission or drive line.
8. Worn transmission bearings.
9. Bent clutch shaft.
10. Unequal adjustment of release levers.
11. Misalignment.

GRABBING

1. Oil or grease on clutch disk facings.
2. Splined hub sticking on splined shaft.
3. Pressure plate sticking on driving studs.

4. Glazed or worn facings.
5. Sticking or binding release levers.
6. Sticking or binding clutch pedal or linkage.
7. Misalignment.

SLIPPING

1. Worn clutch disk facings.
2. Weak or broken springs.
3. Improper clutch or pedal adjustment.
4. Oil or grease on facings.
5. Warped disk.
6. Warped pressure plate.
7. Sticking release levers.
8. Pressure plate sticking or binding on studs.
9. Misalignment.

VIBRATIONS

1. Bent clutch shaft.
2. Defective clutch disk.
3. Dust in clutch.
4. Improper assembly of clutch to flywheel.
5. Use of rigid disk instead of flexible type.
6. Unmatched springs in pressure plate.
7. Misalignment of parts.

FAILURE

1. Clutch disk hub torn out.
2. Friction facings on clutch disk torn off or worn out.
3. Broken springs.
4. Incorrect adjustment of pressure plate.
5. Improper adjustment of clutch or pedal.
6. Splined disk hub stuck on splined shaft.

SUMMARY: TROUBLE SHOOTING OF CLUTCHES

You can locate the basic problems using the charts here. Refer to your Technical Manual for specific problems that you might face in the servicing of a clutch.

TEST YOURSELF QUESTIONS

1. Name four types of clutches.
2. What are the two kinds of disk-type clutches?
3. What characteristics must a clutch facing have? Name two.
4. How can you tell a rigid clutch disk from a flexible disk?
5. Fill in the blanks. "An overrunning clutch will _____ in one direction, but will _____ in the other."
6. True or False? "In an overcenter linkage, it is necessary to hold your foot on the pedal to keep the clutch disengaged."

7. True or False? "The clutch release bearing should rotate all the time in a plate-type clutch."

8. Grease or oil on a dry clutch disk surface usually causes:

1. Grabbing
2. Slipping
3. Both of the above

(Answers on page 9 in back of text.)

MECHANICAL TRANSMISSIONS / CHAPTER 3




Fig. 1—Mechanical Transmission In A Complete Power Train

INTRODUCTION

A **mechanical transmission** is a train of gears that transfers and adapts the engine power to the drive wheels of the machine.

The transmission does two jobs:

- 1) *Selects speed ratios for various travel speeds.*
- 2) *Reverses the travel of the machine.*

The transmission can also power a special drive such as a PTO (Chapter 9).

Normally the transmission is located to the rear of the engine and clutch and in front of the differential or ring gear (Fig. 1).

TYPES OF MECHANICAL TRANSMISSIONS

Mechanical transmissions are of three major types:

- **Sliding Gear**
- **Collar Shift**
- **Synchromesh**

The **SLIDING GEAR** transmission has two or more shafts mounted in parallel or in line, with sliding spur gears arranged to mesh with each other and provide a change in speed or direction.

The **COLLAR SHIFT** transmission has parallel shafts with gears in constant mesh. Shifting is

done by locking free-running gears to their shafts using sliding collars.

The **SYNCHROMESH** transmission also has gears in constant mesh. However, gears can be selected without clashing, by synchronizing the speeds of mating parts *before* they engage.

In all three cases, the transmission is shifted by hand or foot. So we call them *mechanical* transmissions.

Let's look at each type of transmission in detail.

SLIDING GEAR TRANSMISSIONS

The *sliding gear* transmission is a popular transmission for use in farm and industrial machines. Made up mainly of spur gears and shafts, it is simple but gives a variety of speeds.

There are two basic designs:

- **Input and output shafts parallel**
- **Input and output shafts in line**

Let's see how each one operates.

INPUT AND OUTPUT SHAFTS PARALLEL

The input shaft drives the output shaft, which transmits the power. There is normally a third shaft which reverses or further varies the power flow. All three shafts are in parallel and interact through the shifting of their gears. The transmission in Fig. 2 provides three forward speeds and one reverse speed.




Fig. 2—Sliding Gear Transmission With Parallel Shafts

Gears D and E change the speed and direction (Fig. 2). Both of these gears slide on the output shaft, but are splined to it so as to turn it. All the other gears are fixed on their respective shafts, except gear F, which turns freely on the output shaft.

The dotted lines show how gears are shifted.

When gear D engages gear A, the transmission is in first or low gear.

When gear E engages gear B, the transmission is in second gear.

When gear E is engaged to gear F, the transmission is in third or high gear.

When gear D engages gear G, the rotation of the driven shaft is reversed. This places the idler gear shaft into the power train and feeds power in reverse. Gear G is powered by gear H, which is in constant mesh with gear A.

If neither gears D or E are engaged with another gear, the transmission is in neutral.




Fig. 3—Sliding Gear Transmission With Shafts in Line (First Gear Shown)

INPUT AND OUTPUT SHAFTS IN LINE

In this transmission (Fig. 3), input and output shafts lie in a straight line but are not connected. A third shaft, called a countershaft, "overlays" the two and transmits power between them.

The power flow in Fig. 3 is shown for low or first gear. Notice that power is flowing from gear A on the input shaft to gear D on the countershaft, which is also turning gear F. Gear F on the countershaft, in mesh with sliding gear C on the output shaft, causes that shaft to rotate and transmit power to the wheels.

A feature of this transmission is a high gear which bypasses the countershaft. It is provided by connecting gears A and B, and so locking the input and output shafts.

These two basic designs of sliding gear transmissions have many variations. They often provide as many as ten forward speeds and two reverse speeds.





Fig. 4—Sliding Gear Transmission In Crawler Tractor

COLLAR SHIFT TRANSMISSIONS

The collar shift transmission (Fig. 5) has parallel shafts with the gears in constant mesh. In neutral, the gears are free-running but when shifted they are locked to their shafts by sliding collars.



X2132




Fig. 5—Collar Shift Transmission For Wheel Tractor

The transmission shown in Fig. 5 has helical gears which remain in constant mesh. Helical gears usually provide quieter operation than the spur gears which the sliding gear transmission must use.

Since the gears are constantly in mesh and cannot slide on their shafts, one gear in each constant mesh gear set runs free on its shaft when in neutral.

When a gear is engaged, it is secured to its shaft by a collar or coupling device. The gear is disengaged when the collar is released and the gear turns freely again.




Fig. 6—Typical Shifter Collar And Mating Gear

Let's take a close look at the collar which locks a gear to the shaft. In Fig. 6, we see a typical shifter collar and its mating gear. The side of the gear will usually carry short splines. The shifter collar with internal splines is splined to a shifter gear which is, in turn, splined to the shaft. (Sometimes the shifter collar is splined directly to the shaft without a shifter gear).

Power is transmitted by shifting the collar so its internal splines are engaged with the external splines on the driven gear and the shifter gear.

The splines on the gears and collar have rounded ends for easier shifting.




Fig. 8—Collar Shift Transmission In Wheel Tractor

OPERATION




Fig. 7—Collar Shift Transmission (Power Flow In First Gear Shown)

Now let's look at a collar shift transmission in operation. Fig. 7 shows a transmission which provides eight forward speeds and four reverse speeds. (The complete unit is shown in Fig. 5).

Power flow is indicated for first gear. Notice that collars A and B are locking gears 1 and 2 to their respective shafts, transmitting power to the differential and the drive wheels. Power flows through the mating gears 3 and 4 as shown by the arrows.

All eight speeds are obtained by securing the different gears to the shafts, using the collars.




Fig. 9—Exploded View Of Block-Type Synchronizer

SYNCHROMESH TRANSMISSIONS

The *synchromesh* transmission is basically a constant mesh, collar-shift transmission with an extra device (called a synchronizer) to equalize the speed of the mating parts *before* they engage.

The synchronizer is used in all manual automotive transmissions and is common in other machines where "on-the-go" shifting is required.

Four common types of synchronizers are:

- **Block-Type Synchronizer**
- **Disk-And-Plate-Type Synchronizer**
- **Plain-Type Synchronizer**
- **Pin-Type Synchronizer**

Before we look at each of these synchronizers, remember that they have a common function—to help in engaging gears by synchronizing the speeds of the gear and the shaft *before* the connection is made. All types use friction to synchronize the mating parts.

BLOCK-TYPE SYNCHRONIZER

The parts of the block-type synchronizer are: the blocking rings, lock rings, hub, synchronizer sleeve, and shifter plates (Fig. 9).

The hub is splined to the shaft and the synchronizer sleeve is mounted on the hub. The two lock rings hold the shifter plates out against the sleeve. The bronze blocking rings each have three slots into which the ends of the shifter plates fit.






Fig. 10—Matching Cone Areas Of Gear And Blocking Ring


The inner surfaces of the blocking rings are cone-shaped and match the conical shape of the driven gear shoulders which they contact (Fig. 10). These cone-shaped surfaces provide the frictional force to synchronize the speed of the main shaft and the gear.



(A) SYNCHRONIZER IN NEUTRAL POSITION BEFORE SHIFT



(B) DURING SYNCHRONIZATION—BLOCKING RING AND GEAR SHOULDER CONTACTING



(C) SHIFT COMPLETED—COLLAR LOCKS DRIVEN GEAR TO HUB AND SHAFT

X2138

Fig. 11—Block-Type Synchronizer In Operation

Operation Of Block-Type Synchronizer

In neutral, the parts are as shown in Fig. 11A.

During synchronization (Fig. 11B), the sleeve is moved toward the selected gear, pushing the blocking ring to the right. The ring contacts the shoulder of the driven gear and begins to synchronize the speeds of the two parts.

To complete the shift (Fig. 11C), the sleeve teeth pass through the blocking ring teeth (because both are now rotating at the same speed) and mesh with the clutch teeth on the driven gear. Power then flows as shown by the dotted lines and arrows.

DISK-AND-PLATE-TYPE SYNCHRONIZER

Shown in Fig. 12 are the parts which make up the disk-and-plate-type synchronizer.

Note the relationship of the parts to each other.

This synchronizer uses friction disks and plates to bring both gears to the same speed for engaging.

The blocker (B) rides on and is driven by the synchronizer gear (A). The blocker is held in neutral on the gear by four detent balls (C) and springs (D).

The synchronizer drum (G) is driven by the output gear (H). Therefore, the drum is traveling at a different speed than the blocker.

To bring the blocker and the drum to the same speed, three synchronizer disks (E) and two separator plates (F) are housed between the drum and blocker.

The tangs on the synchronizer disks locate themselves inside the synchronizer drum slots and so travel at the same speed as the drum and gear (H).

The separator plates have internal tangs which hold them in position on the blocker, giving them the same rotating speed as the blocker and synchronizer gear.




Fig. 12—Exploded View Of Disk-And-Plate-Type Synchronizer

Operation




Fig. 13—Operation Of Disk-Type Synchronizer

Shifts are made by coupling the output gear to the synchronizer gear (Fig. 13).

When the shifter fork moves the drum forward, the synchronizer disks (which are connected to the drum) and the separator plates (which are connected to the blocker) make contact as shown. As the contact is made, the blocker tends to rotate about its gear instead of moving forward in the direction the shifter fork is moving. This action

forces the drive lugs on the blocker to engage into the outer edge of the detent ball depression cut into the synchronizer gear.

Since the blocker is now locked into the synchronizer gear, extra forward motion of the shifter tends to compress the disks and plates into proper clutching action. This action matches the speed of the synchronizer gear and blocker to the speed of the output gear.

As soon as both gears are moving at the same speed, the thrust force locking the blocker into the synchronizer gear is relieved and the blocker backs out of its locked position with the aid of the detent balls and springs.

This synchronizing action is almost instantaneous. When both gears are moving at the same speed, the drum can then be moved forward to engage both gears. A ridge on the highest teeth of the synchronizer gear limits the forward travel of the drum. This prevents the synchronizer drum from traveling too far forward and losing its contact with the output gear.

PLAIN-TYPE SYNCHRONIZER

The plain-type synchronizer is similar to the block-type synchronizer, but has fewer parts.

The hub is splined to the shaft (Fig. 14). The sleeve is mounted on the hub and connected to it by the springs and balls located radially around the hub.





Fig. 14—Plain-Type Synchronizer

Operation

To engage, the assembly is moved toward the gear to be engaged as shown at left in Fig. 14. The cone-shaped friction area of the hub contacts the cone-shaped area of the gear and accelerates or decelerates it to the same speed as the synchronizer. The small coil springs hold the balls in the groove in the center of the sleeve. This prevents the sleeve from moving off the hub and the sleeve teeth from engaging with the gear teeth until enough pressure has been put on the cone-shaped friction area to synchronize the two parts. Then further movement of the sleeve pushes the balls in, compressing the springs, and the sleeve teeth engage the teeth on the gear, completing the shift. This action is shown at right in Fig. 14.

PIN-TYPE SYNCHRONIZER

Fig. 15 illustrates a pin-type synchronizer. The actuating hub is splined to the shaft and rotates with it. The outer stop rings are splined to the ends of the gears. The stop ring and pin assemblies are loosely pinned to the actuating hub.

Operation

When the actuating hub is moved to either the right or left, the stop ring and pin assemblies hold the loose-fitting pin against the side of the holes in the actuating hub. The actuating hub is prevented from engaging the gear by the chamfered shoulder on the stop ring and the pin assembly.




Fig. 15—Pin-Type Synchronizer

When all parts are rotating at the same speed, the force between the pin and actuating hub is reduced. The hub can then move over the large base of the pins, and the internal splines on the hub can engage the splines on the gear. Slight chamfers on the pin and actuating hub, as well as rounded ends of the splines on the hub and gear, permit these parts to align themselves and mesh easily.

SYNCHROMESH TRANSMISSION IN OPERATION

Now that we've explained the different types of synchronizers, let's see how they work in an actual synchromesh transmission.


Fig. 16 shows a three-speed transmission which is synchronized in second and third gear. Notice that this transmission uses both a sliding gear, a synchronizer to change speeds, and in-line shafts.

Gear (A) is splined to the input shaft and is in constant mesh with gear (D). Gear (B) turns freely on the output shaft.

Low and reverse is provided by sliding gear (C) into mesh with gear (F) or gear (G), the reverse idler.

Second gear is provided by sliding the synchronizer towards gear (B), synchronizing it and locking it to the output shaft. Power flow in Fig. 16 is for second gear.

Third or high gear is provided by sliding the synchronizer towards gear (A), synchronizing it, and locking the input shaft to the output shaft. Power then flows directly through the transmission from input to output.



X2143

Fig. 16—Three-Speed Synchromesh Transmission
(Power Flow For Second Gear Shown)

A complete synchromesh transmission for a wheel tractor is shown in Fig. 17.




Fig. 17—Synchromesh Transmission in Modern Wheel Tractor

SHIFT CONTROLS

Now let's look at the *shift controls* which actuate the various mechanical transmissions.




Fig. 18—Shifter Forks In Collar Shift Transmission

In sliding gear, collar shift, and synchromesh transmissions, the gears or collars are moved by means of a shifter fork which fits in a groove in the collar or gear (Fig. 18). This fork is connected to and moved manually by the gearshift lever. How this connection is made varies.




Fig. 19—Direct-Type Transmission Shifting Mechanism

Let's briefly look at two popular shifter mechanisms:

1) Direct-Type Shifters

2) Cam-Type Shifters

DIRECT-TYPE SHIFTERS

In the direct shifter, the gearshift lever reaches directly into the transmission from the operator's platform (Fig. 19).

The shifter forks, which slide the gears or collars, are attached to the gearshift rails or shafts. The gearshift lever in Fig. 19 has a ball that fits into a socket in the top of the transmission cover. This permits swiveling of the gearshift lever into the various shift positions. Movement of the lever causes the finger on the lower end to select and move one of the rails, its forks, and a gear or collar.





Fig. 20—Shift Pattern On The Four-Speed Transmission Shown in Fig. 19.

For example, in a four-speed transmission (Fig. 20), as the gearshift lever is moved from neutral (N) to the left, the finger on the lower end of the lever moves into the slot in the low-and-second speed rail. This action selects the rail, forks, and gears to be moved. Then, as the lever is pushed forward into low speed, the rail assembly is pushed toward the rear, engaging the low gear.

Locking Of Direct Shifters




X2148

Fig. 21—Locking System For Shifter Rail

To hold the shift rail in position and to prevent other rails from moving, a locking system must be used. Fig. 21 illustrates a popular type.

The shift rails contain spring-loaded *detent balls* that drop down into undercuts on the rails as the rails are moved into the various shift positions. This locks the gears in mesh.



X2149

Fig. 22—Cam-Type Shifters

To prevent movement of more than one rail at a time, *interlock balls* are placed *between* the shift rails as shown. When a rail is moved, the balls are forced out of the undercuts in the side of the rail and into the undercuts on the other rails, locking them firmly into position.

CAM-TYPE SHIFTERS

Fig. 22 shows a cam-type shifter with a shifter cam for the range gearing and one for the speed gearing. The cams are operated through a linkage of rods and arms. When the shift lever is moved, the linkage moves the shifter cam about its pivot point. The cam in turn moves the shifter forks.




Fig. 23—Shifter Cam And Rail Assembly

The shifter cam (Fig. 23) is a plate with two irregular grooves. Rollers on the rail and fork assembly slide in these grooves. When the cam pivots, the rollers, sliding in the irregular grooves, move the forks to engage the selected gear.

Like the direct-type shifter, this unit has detents which lock the transmission in the desired gear. These detents are located in the cam itself as shown in Fig. 22.

ADJUSTMENTS


When a transmission is disassembled to replace bearings or gears, the shafts may require preload or endplay adjustments as explained in Chapter 1. The specific procedures and measurements are supplied by the manufacturer in his technical manual.

GENERAL MAINTENANCE

Mechanical transmissions need little maintenance other than periodic oil changes. However, when you repair a transmission, examine the whole gear train to locate worn or faulty parts and repair or replace them at that time. Thus you may prevent a breakdown and the need to disassemble the transmission once again.

Some things to look for:

1. Excessive gear tooth wear or broken teeth.
2. Worn-out bearings.
3. Broken or distorted shifter detent springs or scored or flat detent balls.
4. Damaged or plugged transmission oil lines or passages in shafts.
5. In sliding gear transmissions, badly worn splines.
6. In collar shift transmissions, excessively worn teeth in shifter collars and hubs.
7. In synchromesh transmissions, scored contact surfaces on blockers, drums, or disks.



X2151

Fig. 24—Trouble Shooting Problems With Mechanical Transmissions

TROUBLE SHOOTING

These trouble shooting charts are given as a general guide to the common transmission failures. They list what the cause might be, and the remedy.

TRANSMISSION NOISY IN NEUTRAL

Possible Cause	Remedy
1. Transmission not aligned with engine.	1. Align.
2. Bearings dry, badly worn, or broken.	2. Lubricate or replace.
3. Transmission oil level low.	3. Refill.
4. Gears worn, scuffed, or broken.	4. Replace.
5. Countershaft sprung or badly worn.	5. Replace.
6. Excessive endplay of countershaft.	6. Adjust or replace worn parts.

TRANSMISSION NOISY WHILE IN GEAR

1. All causes noted in "Transmission Noisy In Neutral."	1. Same as above.
2. Main shaft rear bearing worn or broken.	2. Replace.
3. Gear teeth worn.	3. Replace gear.
4. Engine vibration dampener defective.	4. Replace or adjust.
5. Speedometer drive gears worn.	5. Replace.
6. Clutch friction disk defective.	6. Replace.
7. Gears loose on main shaft.	7. Replace worn parts.
8. Transmission oil level low.	8. Refill.

TRANSMISSION HARD TO SHIFT

- | | |
|---|--|
| 1. Engine clutch not releasing. | 1. Adjust. |
| 2. Sliding gear tight on shaft splines. | 2. Clean splines or replace shaft or gear. |
| 3. Shift linkage out of adjustment. | 3. Adjust. |
| 4. Main shaft splines distorted. | 4. Replace or clean splines. |
| 5. Synchronizing unit damaged. | 5. Replace defective parts. |
| 6. Sliding gear teeth damaged. | 6. Replace. |

GEARS CLASH WHEN SHIFTING

- | | |
|---------------------------------|--|
| 1. Clutch not releasing. | 1. Adjust. |
| 2. Synchronizer unit defective. | 2. Replace defective parts. |
| 3. Gears sticky on main shaft. | 3. Free up gears. Replace defective parts. |

TRANSMISSION STICKS IN GEAR

- | | |
|--|---|
| 1. Clutch not releasing. | 1. Adjust. |
| 2. Detent balls stuck. | 2. Free. |
| 3. Shift linkage out of adjustment not lubricated. | 3. Adjust or lubricate. |
| 4. Sliding gears tight on shaft splines. | 4. Clean splines or replace shaft or gears. |

TRANSMISSION SLIPS OUT OF GEAR

- | | |
|-------------------------------------|---------------------------------|
| 1. Shift linkage out of adjustment. | 1. Adjust. |
| 2. Gear loose on shaft. | 2. Replace shaft or gear. |
| 3. Gear teeth worn. | 3. Replace gear. |
| 4. Excessive endplay in gears. | 4. Replace worn or loose parts. |

- | | |
|--|------------------------|
| 5. Lack of spring tension on shift lever detent. | 5. Install new spring. |
| 6. Badly worn transmission bearings. | 6. Replace. |

TRANSMISSION LEAKS OIL

- | | |
|---|--------------------------------------|
| 1. Oil level too high. | 1. Drain to proper level. |
| 2. Gaskets damaged or missing. | 2. Install new gaskets. |
| 3. Oil seals damaged or improperly installed. | 3. Install new oil seals. |
| 4. Oil throw rings damaged, improperly installed, or missing. | 4. Install oil throw rings properly. |
| 5. Drain plug loose. | 5. Tighten. |
| 6. Transmission case bolts loose, missing, or threads stripped. | 6. Tighten or replace. |
| 7. Transmission case cracked. | 7. Replace. |
| 8. Lubricant foaming excessively. | 8. Use recommended lubricant. |

TEST YOURSELF**QUESTIONS**

1. What are the three common types of mechanical transmissions?
2. (True or False?) "In some sliding gear transmissions, the input and output shafts are locked together in high gear."
3. What is one advantage of the collar shift transmission over the sliding gear?
4. Which type of transmission allows "on-the-go" shifting while the machine's wheels are still rolling?
5. What is the purpose of the countershaft?
6. Does a collar shift transmission normally have spur or helical gear teeth?
7. What is a chamfer?

(Answers on page 9 in back of text.)

HYDRAULIC ASSIST TRANSMISSIONS / CHAPTER 4




Fig. 1—Hydraulic Assist Transmission In A Complete Power Train

INTRODUCTION

The **hydraulic assist transmission** is a train of gears which can be shifted without interrupting the flow of power.

The gears are kept in constant mesh while two or more hydraulic clutches control the flow of power "on the go."

The parts work together as follows:


- **Hydraulic clutches**—control the power flow
- **Gear train**—transmits the power flow

When the operator shifts gears, hydraulic oil engages the clutches that route power to the selected gears.

A **hydraulic clutch** is normally an alternating pack of friction disks and plates (Fig. 2).

The clutch is *engaged* when pressure oil is sent to push the piston against the disks and plates, clamping them together. The disks are splined to the drum, while the plates are splined to the hub. As a result, input power through the drum is sent on through the hub to the output by the engaged clutch.

The clutch is *disengaged* when oil pressure is released and the piston moves away from the clutch pack. This frees the disks from the plates and the power flow is stopped. Spring action or oil pressure on the other side of the piston may be used to help release the disks and plates.




X2152

Fig. 2—Hydraulic Clutches Control The Power Flow In Hydraulic Assist Transmissions

The **gear train** usually takes one of two forms:


- **Countershaft**
- **Planetary**

Let's look at each one in detail.



X2153

HIGH SPEED (DIRECT DRIVE)



X2154

LOW SPEED (UNDERDRIVE)

Fig. 3—Countershaft Transmission (High-Low Speed Unit)

COUNTERSHAFT TRANSMISSIONS

Countershaft transmissions allow one set of gears to be shifted without disturbing the other gear ratios in the transmission.

Let's look at three common models—high-low speed units, reverser units, and high-low-reverse units.

HIGH-LOW SPEED UNIT

The simplest countershaft transmission is the high-low speed unit shown in Fig. 3. It has two hydraulic clutches and four gears in mesh. Whenever one clutch is engaged, the other is disengaged.

The input and output shafts are not connected unless the direct drive clutch is engaged.

When engaged, this clutch sends input power from the outer drum through to the inner hub as explained in Fig. 2.

In direct drive, both shafts are locked together and rotate at the same speed. This gives *high speed* as shown in Fig. 3.

For *low speed*, the underdrive clutch is engaged. Gear G-1 is fixed on the input shaft so power is routed through mating gear G-2, along the countershaft, out through gears G-3 and G-4 and to the underdrive clutch drum. Power then flows through the engaged clutch pack to the inner hub which is fixed to the output shaft.

The output shaft turns at a slower speed than the input shaft, giving the low speed. The actual

speed depends upon the ratio of the two gear sets.

Underdrive means that the output shaft turns *slower* than the input. In some units the output turns *faster* than the input and these are called **overdrives**.

REVERSER UNIT

To get a reverse speed from the countershaft unit, another gear (G-5) is added between gears G-1 and G-2 as shown in Fig. 4.

The countershaft will now rotate in the same direction as the input shaft.

In **forward speed**, the forward clutch is engaged and power flows straight through, bypassing the countershaft.

In **reverse speed**, the reverse clutch is engaged and locks gear G-4 to the output shaft. Power is transmitted through the countershaft as shown by the arrows, causing the output shaft to rotate in the opposite direction from the input shaft.

An actual reverser unit is shown (outlined in blue) in Fig. 5.

The engine power source is shown at right, while the transmission gear train is shown at left center.

The reverser unit gives on-the-go reversing, while the transmission gear train sets up the basic gear ratios. (The gear train is a sliding gear type—see Chapter 3.)





Fig. 4—Countershaft Transmission (Reverser Unit)

HIGH-LOW-REVERSE UNIT

If both a reverse and an underdrive countershaft are used in the same transmission with three clutches, these options are available:

- 1) High (direct drive)
- 2) Low (underdrive)
- 3) Reverse

Extra speeds can be obtained by simply adding more countershafts and more clutches.

PLANETARY TRANSMISSIONS

Planetary gears work like our solar system. The pinions or planet gears each turn on their own axis and, at the same time, rotate around the sun gear (Fig. 6). This is much like the earth and other planets rotating around the sun.

When used with hydraulic clutches and brakes, the planetary can serve as a direct coupler, a reduction gear, or a reversing gear.

A planetary gear set allows gear ratios to be changed without actually engaging or disengaging gears. As a result, there is little or no interruption of the power flow.




Fig. 5—Reverser Unit In Complete Power Train

Planetarys are compact units which allow the input and output shafts to rotate on the same axis and eliminate the countershaft.

In planetary sets, the gear load is spread over several gears, decreasing the load on each tooth.

The planetary system also spreads the load evenly around the circumference of the system, eliminating the sideways stress on the shafts.

Operation of basic planetarys is explained in Chapter 1.




Fig. 6—Parts Of The Planetary System

The basic parts of the planetary system are shown in Fig. 6. They are:


- Sun gear—center of system
- Planet pinions and carrier—rotate around sun gear
- Ring gear—surrounds the other parts

A planetary transmission uses hydraulic clutches and brakes to control the rotation of the planetary parts.

The planetarys may be simple or compound units as we'll see now.

SIMPLE PLANETARY TRANSMISSIONS

The two-speed planetary shown in Fig. 7 has one clutch and one brake. The clutch controls the



X2158

HIGH SPEED (DIRECT DRIVE) SHOWN

Fig. 7—Simple Planetary System (High-Low Speed Unit)

direct drive or high speed, while the brake controls the underdrive or low speed.

Planetarys work on the principle that **when any two parts are locked together, all three parts rotate as a unit.**

In Fig. 7, the sun gear shaft is the power input, while the output shaft is fastened to the planet pinion carrier.

For **high speed** (shown), the direct drive clutch engages and locks the sun gear to the planet pinion carrier, making the input and output shafts rotate in unison for a direct drive.

For **low speed**, the direct drive clutch is released while the underdrive brake is engaged, holding the ring gear stationary. The rotating sun gear then turns the planet pinions against the stationary ring gear and forces the pinion carrier to rotate as the planet pinions "walk" around the ring gear. As a result, the pinion carrier rotates in the same direction as the sun gear, *but at a reduced speed*. So the output shaft turns slower than the input shaft.


For **neutral**, both the clutch and brake are disengaged and the output shaft stops turning.

The unit shown in Fig. 7 is part of a shift-on-the-go transmission having high-low speed options.

ring gear. This turns the carrier somewhat faster but still much slower than the input shaft. This gives the two speed ratios both of which are underdrives when compared to the input speed.

For neutral, both B-1 and B-2 brakes are released.

In Fig. 10 we have added a second, larger sun gear on a shaft concentric with the first sun gear shaft. By bringing power into the planetary on a sun gear, two extra speed ratios are obtained by engaging first B-1 and then B-2. These two ratios are slightly faster than the ratios achieved with the small sun gear, but are still slower than the input speed. So far we have four underdrive ratios available.



X2163


Fig. 11—Compound Planetary Transmission—Speed 5 (Direct Drive)

The fifth speed ratio is a direct drive (Fig. 11). To do this, we drive *both* sun gears at input shaft speeds. (Both brakes must be released.)

Since the sun gears do not have the same number of gear teeth and are in mesh with the planet pinions, they are locked-up and the carrier speed is the same as the input shaft speed.

To direct the flow of power into the two sun gears, two clutches (C-1 and C-2) are installed at the rear of the engine (Fig. 12).

The clutches turn at engine speed whenever the engine is running, ready to transmit power to either one or both sun gears in the planetary. This power is transmitted to the sun gears through two shafts, one inside the other.




X2163

Fig. 12—Hydraulic Clutches Which Control Power To Planetaries

To complete the transmission (Fig. 13), another compound planetary unit (shown in pink) is fastened to the first unit. The planet pinion carriers are fastened together so that the output of the first planetary is the input of the second planetary. This forces the planet pinions to rotate in an orbit around the transmission centerline whenever power is being transmitted through the first planetary. The second planetary is capable of a reverse drive, a direct drive, and an overdrive.


When the B-3 or *reverse* brake is engaged (Fig. 13), the B-3 ring gear stops rotating. As the planet pinions are forced around by the carrier, the large single planet pinion gear is forced to walk around the ring gear and turns in the opposite direction of the carrier. This gear is in mesh with the smaller double planet pinions, and turns them in the same direction as the carrier. This turns the front or largest sun gear to rotate in the opposite direction as the carrier. Since the sun gear is splined to the output shaft, the output shaft turns in the same direction, giving **reverse drive**.

When the C-3 or direct drive clutch is engaged (Fig. 14), the two sun gears in the planetary are forced to rotate together. The hub of C-3 and the first or larger sun gear are both fastened to the output shaft. The C-3 drum is fastened to the second or smaller sun gear. When the two sun gears are locked together by engagement of C-3, the planet pinions cannot turn and the output shaft turns at the same speed as the carrier or input. This is **direct drive**.




X2164

Fig. 13—Compound Planetary Transmission With Second Planetary Added—Reverse Drive Shown



X2165

Fig. 14—Second Planetary Transmitting Direct Drive



X2166

Fig. 15—Second Planetary Transmitting Overdrive

When the B-4 or overdrive brake is engaged (Fig. 15), the second or smaller sun gear stops rotating, because it is tied to the transmission case through the B4 brake. As the carrier forces the planet pinions around in an orbit, the large single planet pinion is forced to walk around the stationary sun gear. This rotates the large planet pinion the same direction as the carrier, causing the smaller double planet to rotate in the opposite direction. This turns the large sun gear and the output shaft in the same direction as the carrier but at a faster rate of speed. Since the output shaft is turning faster than the input shaft, this ratio is known as **overdrive**.

Since the first planetary is capable of five different ratios and the second planetary is capable of two ratios forward, theoretically the transmission would have 10 speeds forward and five speeds in reverse. However, because of overlap in the ratios, this transmission has 8 forward speeds and 4 reverse speeds, all evenly spaced.

The clutch and brake units that are engaged in each of these ratios is shown in the table (Fig. 16).

An actual compound planetary transmission like the one we have just described is shown in Fig. 17. This unit drives a modern tractor.

1st Fwd.	C1		B1			C3
2nd Fwd.	C1			B2		C3
3rd Fwd.		C2	B1			C3
4th Fwd.		C2		B2		C3
5th Fwd.		C2	B1		B4	
6th Fwd.		C2		B2	B4	
7th Fwd.	C1	C2				C3
8th Fwd.	C1	C2			B4	
1st Rev.	C1		B1		B3	
2nd Rev.	C1			B2	B3	
3rd Rev.		C2	B1		B3	
4th Rev.		C2		B2	B3	

X2167

Fig. 16—Engagement Of Clutches (C) and Brakes (B) In Each Speed Of Compound Planetary Transmission

Summary: Compound Planetary Transmissions

By combining simple planetaries and selecting different parts of each unit as input, output, and




Fig. 17—Compound Planetary Transmission In A Modern Tractor

stationary, a variety of speed ratios can be selected. These range from a large reduction in speed (underdrive) to a large increase in speed (overdrive), plus several reverse drives.

The compound planetary is a very compact transmission for the number of speeds it provides. However, more horsepower is required to run it than a gear-type transmission because of hydraulic drag.

HYDRAULIC SHIFT CONTROLS

Oil does two jobs in a hydraulic assist transmission:

- Lubricates and cools the clutches and brakes
- Engages the clutches and brakes

Figure 18 on the next page shows an oil circuit for a hydraulic assist transmission. This circuit is an open-center type (see the FOS "Hydraulics" manual).

The transmission case is often used as a reservoir for the oil. The transmission oil pump draws oil through the reservoir screen and into the pump. From the pump, the oil is filtered to remove all contaminants. The filter is protected from rupture by the relief valve. Since an open-center pump is used, a pressure regulator valve is installed in the pump discharge line to regulate and control the pressure.

From this point the oil flows in two directions—the lubricating oil route and the control oil route.

LUBRICATING OIL ROUTE

The first route is through the pressure regulating valve to the oil cooler to remove the heat and then into the lubricating circuit of the transmission (see pink oil in Fig. 18). This oil both lubricates and cools the transmission. It flushes the clutches and brakes to cool them of the heat built up when the clutch is slipped. (Slipping occurs momentarily every time the unit is shifted, while the clutch is picking up its load.)

CONTROL OIL ROUTE

The second path taken by oil is the clutch control circuit (shown in red in Fig. 18). From the pressure regulating valve this oil flows through an adjustable orifice and fills the spring-loaded accumulator with oil at system pressure. From the outlet of the accumulator, the oil goes to the valves which direct flow to the different clutches. When a valve is shifted to engage a clutch and brake, the accumulator discharges its oil and takes up the volume behind the clutch and brake pistons necessary to remove the clearance in the plates.

Since the accumulator is discharged, the pressure on the clutch and brake pistons at the start of lockup is relatively low and builds up slowly during lockup as the accumulator refills. When the accumulator piston bottoms, the pressure in the clutch and brake jumps to system pressure and completes the clutch lockup or engagement rapidly. If the adjustable orifice is opened wider, the shift is made faster. If the orifice is closed down, the shift is made slower.




Fig. 16—Hydraulic Oil Circuit For Typical Hydraulic Assist Transmission

This system modulates the shift and prevents the violent lurch that occurs if the clutches are engaged too rapidly.


A **shift valve** is used in the hydraulic assist transmission between the accumulator and the transmission to control the flow of pressure oil to the different clutches and brakes as the operator shifts from one gear to another. The most common shift valves are either the rotary or spool type valve. The shift valve must have as many different positions as there are speed ranges in the transmission. As transmissions become more complex with more speed ranges, the shift valve becomes more complicated. It is often convenient to use two or more valves working together to obtain the necessary ports to control a transmission with many speeds.

NOTE: Operation of basic hydraulic components is covered in the FOS "Hydraulics" manual.

OTHER CONTROL FEATURES

Three extra features are common in hydraulic assist transmissions:

1. An **inching pedal** which disengages enough of the elements in the transmission to obtain a neutral in any gear ratio. This provides a pedal for emergency stops and for maneuvering the machine in close quarters or when attaching equipment.
2. A dry-type **disconnect clutch** between the engine and the transmission for cold weather starting. Cold, stiff oil between the plates causes all the clutches and brakes in the transmission to drag, causing a lockup and drag on the engine starting circuit.
3. A **tow disconnect** or **neutral** between the transmission and the final drive members is necessary if the machine is to be towed without the engine running. Since the transmission pump works only when the engine is running, no lubricating oil is available while towing. As a result, some of the shafts and clutches rotating without lubrication would be damaged—unless they can be disconnected. The tow disconnect is normally provided by a splined sliding collar which disconnects the reduction gear from the reduction gear shaft.



X8170

Fig. 19—Trouble Shooting Problems With Hydraulic Assist Transmissions

TROUBLE SHOOTING

These trouble shooting charts are given as a general guide to the common failures of hydraulic assist transmissions.

Supplement these charts with specific trouble shooting from the machine Technical Manual.

MACHINE WON'T MOVE

1. Tow disconnect disengaged.
2. Cold weather starting clutch disengaged.
3. Failed clutch.
4. Park lock engaged.
5. No oil pressure.
6. Control linkage stuck or disconnected.
7. Blown packing or gaskets.
8. Oil filter plugged.

SHIFTS ERRATICALLY

1. Wrong setting of adjustable orifice.
2. Incorrect system oil pressure.
3. Failed or stuck accumulator.
4. Shift control disconnected or binding.

CLUTCHES OR BRAKES SLIPPING

1. Low oil pressure.
2. Defective gasket or seal.
3. Burned or warped clutch facings.
4. Excessive oil leakage at shift valves.

LOW SYSTEM PRESSURE

1. Plugged oil filter.
2. Low oil level.
3. Blown O-ring or gasket.
4. Plugged reservoir oil screen.
5. Air leak in pump suction line.
6. Wrong adjustment of pressure regulating valve.
7. Inching pedal valve leaking.
8. Stuck filter bypass valve.
9. Stuck cooler relief valve.
10. Failed or worn pump.
11. Pump not turning.

TRANSMISSION OVERHEATING

1. Reservoir oil level too low or too high.
2. Plugged oil filter.
3. Plugged core in oil cooler.
4. Not enough lubricating oil flow.
5. Faulty temperature gauge.
6. Clutch or brake dragging or slipping.
7. Cooler relief valve stuck open.

TEST YOURSELF

QUESTIONS

1. (Fill in the blanks.) "In hydraulic assist transmissions, _____ control the power flow, while the _____ transmits the power flow."
2. What are the two basic types of gear sets used in hydraulic assist transmissions?
3. What does "underdrive" and "overdrive" mean?
4. Name the three main components of a planetary gear set.
5. True or false? "When any two parts of a planetary are locked together, all three parts rotate as a unit."
6. What is the gear ratio of input to output when a planetary has two parts locked together?
7. What two jobs does oil do in a hydraulic assist transmission?

(Answers on page 9 in back of text.)

HYDROSTATIC DRIVES / CHAPTER 5




Fig. 1—Hydrostatic Drive In A Complete Power Train

INTRODUCTION

The hydrostatic drive is a fluid drive which uses fluid under pressure to transmit engine power to the drive wheels of the machine.

Mechanical power from the engine is converted to hydraulic power by a pump-motor team. This power is then converted back to mechanical power for the drive wheels.

The hydrostatic drive can function as both a clutch and transmission. The final gear train can then be simplified, with the hydrostatic unit supplying infinite speed and torque ranges as well as reverse speeds.

HOW IT WORKS

There are two basic types of hydraulic transmissions:

- Hydrodynamic
- Hydrostatic


HYDRODYNAMIC TRANSMISSIONS (Fig. 2) use fluids at *high speeds* but relatively *low pressures*. Basically, a hydraulic pump (hose) forces fluid against a turbine wheel, rotating it as shown.

This type of transmission is used in **torque converters** (Chapter 6).


HYDROSTATIC TRANSMISSIONS (Fig. 2) use fluids at *high pressures* but relatively *low speeds*. Basically, energy is transferred by the fluid itself in a closed circuit between the pump and motor as shown. While the fluid does move through the lines (shown in red), it is still considered as being at rest or under *static pressure*. The rise in pressure of the fluid—which will not compress—is what transfers the energy.

This type of transmission is used in the **hydrostatic drives** we'll cover in this chapter.

5-2 Hydrostatic Drives



HYDRODYNAMIC =
Low Pressure and High Velocity



HYDROSTATIC =
High Pressure and Low Velocity


X 2212

Fig. 2—Basic Types Of Hydraulic Transmissions

THEORY OF HYDROSTATIC DRIVES

Two principles of hydraulics are required to understand a hydrostatic drive:


- Liquids have no shape of their own
- Liquids will not compress



X 1071

Fig. 3—Liquids Have No Shape Of Their Own


LIQUIDS HAVE NO SHAPE OF THEIR OWN. They acquire the shape of any container (Fig. 3). Because of this, oil in a hydraulic system will flow in any direction and into a passage of any size or shape.



X 1072

Fig. 4—Liquids Will Not Compress

LIQUIDS WILL NOT COMPRESS. Fill a plastic jug with liquid (Fig. 4). Then tightly cork it. Now let's say you pushed down on the cork and tried to compress the liquid. It wouldn't work—the jug would expand and eventually burst.



X 2213

Fig. 5—Two Cylinders Connected


Fig. 5 shows how these principles work in a hydrostatic drive.

Two cylinders, each containing a piston, are connected by a line. The cylinders and the line are filled with oil.

When a force is applied to the left piston as shown, that piston moves against the oil. The oil will not compress, so it acts as a solid and forces out the right piston.

In a hydrostatic drive, several pistons are used to transmit power—one group in the **pump** sending power to another group in the **motor**.

The pistons are in a cylinder block and revolve around a shaft. The pistons also move in and out of the block parallel to the shaft as we'll see later.



X 2214

Fig. 6—Two Connected Cylinders With Swashplates

Fig. 6 shows one piston for the pump and one for the motor. To provide a pumping action for the pistons, a plate called a **swashplate** is located in both the pump and motor. The pistons ride against the swashplates.

The angle of the swashplates (Fig. 6) can be varied so that the volume and pressure of oil pumped by the pistons can be changed or the direction of oil flow reversed.

A pump or motor with a movable swashplate is called a **variable-displacement** unit. A pump or motor with a fixed swashplate is called a **fixed displacement** unit.

Fig. 7 shows a variable displacement pump driving a fixed displacement motor.

As the pump pistons rotate, they move across the sloping face of the swashplate, sliding in and out of their cylinder bores to pump oil out. The

more the pump swashplate is tilted, the more oil it pumps with each piston stroke and the faster it drives the motor.

Pressure results whenever the flow of a fluid is resisted. The resistance may come from acceleration of the machine or normal load.

The motor swashplate is at a fixed angle so that the stroke of its pistons are always the same. Thus its speed of rotation cannot be changed except as it is driven faster or slower by the pump oil.

The point to remember now is that a given volume of oil forced out of the pump will cause the motor to turn at a given speed. More oil will speed up the motor; less oil will slow it down.


The pump is driven by the machine's engine and so is linked to the speed set by the operator. It pumps a constant stream of high-pressure oil to the motor.

Since the motor is linked to the drive wheels of the machine, it gives the machine its travel speed.

Only three factors control the operation of a hydrostatic drive:

- **Rate of oil flow**—gives the speed
- **Direction of oil flow**—gives the direction
- **Pressure of oil**—gives the power


Control of these three factors is infinite, giving endless selections of speed and torque in a hydrostatic drive.



PUMP
(VARIABLE DISPLACEMENT)

MOTOR
(FIXED DISPLACEMENT)

Fig. 7—Variable Displacement Pump Driving Fixed Displacement Motor



X6696

Fig. 8—Complete System For A Hydrostatic Drive (Closed Hydraulic Loop)

The pump-motor team is the heart of the hydrostatic drive, although the complete hydraulic system (Fig. 8) also includes a **reservoir** to supply the oil, a **filter** to remove dirt, and a **cooler** to remove excess heat from the oil.

Basically however, the pump and motor are joined in a closed hydraulic loop; the return line from the motor is joined directly to the intake of the pump, rather than to the reservoir. The charge pump simply supplies the oil, drawing it from the reservoir.

NOTE: For basic theory of hydraulic systems, see the FOS "Hydraulics" manual.

TYPES OF HYDROSTATIC DRIVES

Displacement is the quantity of fluid which a pump can move (or a motor can use) during each revolution. It is directly related to the horsepower output of the drive. (Horsepower is a combination of torque X speed.)

As you have already learned, pumps and motors can have a **fixed** displacement or **variable** displacement.

Four pump-motor combinations are possible:

- 1) **Fixed** displacement pump driving a **fixed** displacement motor.
- 2) **Variable** displacement pump driving a **fixed** displacement motor.

3) **Fixed** displacement pump driving a **variable** displacement motor.

4) **Variable** displacement pump driving a **variable** displacement motor.


The point to remember is that for each combination the output power must equal the input power minus negligible power losses. Let's look at each combination (Fig. 9).

No. 1 circuit is like a gear drive; it transmits power without altering the speed or horsepower between the engine and the load. A constant input speed and torque gives a constant output horsepower. If either the speed or torque are increased holding the other constant the output horsepower will increase.

Since the pump flow is variable in **No. 2 circuit**, output speed is variable and torque output is constant for any given pressure. This circuit gives variable speed and constant torque.

Output speed in **No. 3 circuit** is varied by changing the motor displacement. For constant power input if the motor displacement decreases, output speed increases but output torque drops.

No. 4 circuit is the most flexible and expensive of all the circuits but also the most difficult to control. It is capable of operating like any of the above combinations.



X2480

Fig. 9—Pump-Motor Combinations For Hydrostatic Drives

REVERSING IN VARIABLE PUMP-MOTOR CIRCUITS


The direction of output shaft rotation can be reversed in variable circuits by shifting either the pump or motor swashplates over center (Fig. 10).

In **neutral**, the swashplate is vertical and no oil is pumped.

In **forward**, the swashplate is tilted and oil is pumped as shown at the top.

In **reverse**, the swashplate is tilted the opposite way and the unit pumps oil in the opposite direction.

How this affects the complete drive will be seen under "Operation", which follows.




X 2219

Fig. 10—How Reversing Is Done With Variable Displacement Pumps Or Motors

OPERATION OF HYDROSTATIC DRIVES

Let's see how a typical hydrostatic drive works.


Our example is a system with an axial piston pump (Fig. 11) and motor (Fig. 12). This type of unit is most common in hydrostatic drives today.



X 1180

Fig. 11—Variable Displacement Pump—Axial Piston Type

The *pump* has a **variable** displacement, while the *motor* has a **fixed** displacement. (These units are shown connected in Fig. 7).



X 2220

Fig. 12—Fixed Displacement Motor—Axial Piston Type

Let's look at the complete system in operation in *neutral*, *forward*, and *reverse* speeds.

NEUTRAL (Fig. 13)

When the speed range control lever is in neutral, free oil flows from the reservoir through the oil filter to a charge pump. This pump (which is a gear-type to provide a constant supply of oil to the main pump) pumps the oil into the center section where it circulates through the motor housing. Oil then passes through the center section, circulates throughout the pump housing, and then returns through the oil cooler to the reservoir.

Trapped oil (shown in green) is held in the cylinder block of the pump, in the motor, and in the connecting lines between the pump and motor by two check valves (A) and (B) in the center section.

When the control lever is in neutral, the swashplate in the pump is also in neutral and the pistons in the pump are not stroking. Therefore, no oil is being pumped.

The cylinder block in the pump, driven by the machine engine rotates in a counterclockwise direction as viewed from the input end of the pump.

Because oil is not being pumped to the motor, the cylinder block in the motor is stationary and the output shaft does not move.

The hydrostatic belt tightener valve provides for pressure oil to assist a spring to keep proper tension on the belt.




Fig. 13—Hydrostatic Drive in Neutral

FORWARD (Fig. 14)

When the speed range control lever is moved forward, the spool in the displacement control valve moves out of neutral. This allows oil to flow into the lower servo cylinder forcing the swashplate (which is connected to the servo cylinder) to tilt. Oil expelled by the opposing servo cylinder (not shown) returns through the displacement control valve to the pump case.

When the swashplate reaches the tilt set by the control lever, the displacement control spool returns to neutral (as shown in Fig. 14). This traps the oil to both servo cylinders and holds the swashplate tilted as shown. The swashplate will remain in this position until the speed control lever is moved by the operator.

With the pump drive shaft and cylinder block rotating counterclockwise and the top of the swashplate tilted to the left, low pressure oil enters port A through check valve A. This forces the pistons in the pump, that align with port A, to go out against the swashplate, filling the pump cylinder block. The further the swashplate is tilted, the more oil the pump receives. As the driveshaft continues to turn the cylinder block, the pistons are forced back into the block because of the tilted position of the

swashplate. As the pistons move back into the block, oil in the cylinder becomes pressurized. Then, when the cylinder is aligned with port B, pressure oil moves through port B into the cylinder in the motor that is aligned with port B.

The distance the pistons in the pump reciprocate in and out of the cylinder block depends on the angle the pump swashplate is tilted. This determines the volume of oil displaced per revolution of the pump. The greater the angle, the greater the volume and the more oil flows from the pump. Thus, as the swashplate angle is changed, the volume of oil displaced from the pump will also change. The greater the angle, the greater the volume, hence a greater flow of oil from the pump.

As pressure oil moves from pump to motor through port B, pistons in cylinders in the motor that align with port B are pushed against the fixed swashplate. The pistons slide down the inclined surface and resulting forces cause the cylinder block to rotate which in turn rotates the output shaft. This drives the differential and transmission causing the machine to move forward.




Fig. 14—Hydrostatic Drive in Forward Operation

The cylinder block in the motor rotates in a clockwise direction (viewed from the output shaft end of the motor) when traveling forward. As the cylinder block continues to rotate, oil is forced out of port A, through the center section, to the pump.

The oil returned by the motor to the pump through the center section is recirculated through the pump cylinder block assembly and back to the motor. This is called a "closed circuit" system in that the oil continually circulates between the pump and the motor. The only oil introduced into the closed circuit from the reservoir comes from the charge pump.

If pressure exceeds the rated pressure of the high pressure relief valves, the relief valve opens and oil bypasses the cylinder block assembly in the motor, slowing or stopping the combine. The bypassing oil returns to the pump.

REVERSE (Fig. 15)

When the speed range control lever is moved to reverse, the spool in the displacement control valve moves out of neutral. This allows pressure oil to flow into the upper servo cylinder, tilting the swashplate as shown.

When the swashplate reaches its desired tilt, as set by the control lever, the displacement control spool returns to neutral (as shown in Fig. 15). This traps the oil to both servo cylinders and holds the swashplate tilted as shown. The swashplate remains in this position until the speed control lever is moved again by the operator.

With the pump drive shaft and cylinder block rotating counterclockwise and the top of the swashplate tilted to the right, port B becomes the *inlet* and port A the *outlet* (high pressure port). As the cylinder rotates past port B, check valve B opens and oil is forced by the charge pump into the piston bores, which align with port B. Then as rotation continues, the oil is pressurized and forced out of port A by each of the pistons as they align with port A. This oil flows to the motor.




Fig. 15—Hydrostatic Drive in Reverse Operation

As high pressure oil from the pump enters port A of the motor, it pushes the motor pistons against the swashplate. The pistons slide down the inclined surface of the swashplate, rotating the cylinder block which in turn rotates the drive shaft, driving the machine—but in reverse.

As the motor cylinder block continues to rotate, oil is forced out port B at low pressure and returns to the pump.

NOTE: The pump drive shaft and cylinder block always rotate clockwise, but the motor drive shaft and cylinder block can rotate in either direction, depending on the direction of oil entering from the pump.

HYDROSTATIC DRIVE AXLES

Integral pump-motor units can be used, one on each drive axle, to propel some machines (Fig. 16).

Each pump-motor is connected at right angles. Both pump and motor have a variable displacement, giving a variable torque and horsepower.

Closed-circuit oil paths between the pump and motor are built into the housing.

A charge pump is built into the unit shown, as well as pressure control and relief valves. The charge pump is a vane type with a fixed displacement.

The swashplates are controlled by linkages which fasten to the yokes above the pump and motor.

The complete system is shown in Fig. 17.




Fig. 16—Integral Pump-Motor For Hydrostatic Drive Axle

OPERATION

Fig. 17 illustrates the oil flow from the **reservoir**, to one **hydrostatic axle**, and the return to reservoir.

Oil flows from the **reservoir** to the **inlet port** of the **charge pump**. The oil passes from the charge pump to the **control valve**. If the control valve is not actuated, oil passes through the control valve into a common line with oil from the other control valve, back to the **filter**. After oil passes through the filter and **cooler**, it enters the **valve block** inlet port of both drives.

The valve block has common oil passages to allow oil to flow from the **piston pump** to the **piston motor** and return to the piston pump. This is a **closed circuit**. When any leakage occurs, the circuit is replenished by cooled oil entering the valve block.

The replenishing oil overcomes the 10 psi (69 kPa) spring setting and discharges into the inlet side (low pressure side) of the piston pump at a pressure in excess of 10 psi (69 kPa). Any excess pressure

in the common passage empties over the 25 psi (172 kPa) relief valve into the motor housing and back to the reservoir. The 25 psi (172 kPa) relief valve consists of a sleeve poppet and spring. Pressure acts directly on the poppet against the spring.

To take care of the pressure surges in the outlet passages, relief valve action is provided. The replenishing and relief valve cartridges are pre-set.

The relief valve operates when the outlet pressure on the end of the inner poppet creates a force greater than the pilot spring force (4500 psi) (31 025 kPa) and unseats the inner poppet. This reduces pressure in the spring chamber until the outer poppet moves, discharging excess pressure to the relief cavity. The inner poppet is held open by its pin until the system pressure drops below 4500 psi (31 025 kPa).

Since either port of the piston pump can be inlet or outlet, two replenishing and relief valves are required to provide relief protection.




Fig. 17—Cooling Oil Flow in Hydrostatic Drive Axle

The pump for each axle is driven by the engine, while the motor for each axle drives that axle.

The machine is steered by actuating the pump swashplate on each axle. For example, a steering wheel can be linked indirectly to the swashplates for gradual turns. For sharp turns or reversing an axle, steering levers—one for each axle—can be used.

For reversing an axle, the pump swashplate is moved overcenter, reversing the flow circuit which drives the motor.

OTHER TYPES OF HYDROSTATIC DRIVES

A variety of hydrostatic units are available for driving machines from the center drive line or from the individual wheels.

To serve these needs, a wide variety of pump-motor locations are used.

We have looked at only a few of the more common designs.

ADVANTAGES OF HYDROSTATIC DRIVES

- Variable speeds and torques
- Easy one-lever control
- Smooth shifting without "steps"
- Shifts "on the go"
- High torque available for starting up
- Flexible location—no drive lines
- Compact size for big power
- Eliminates clutches and large gear trains
- Reduces shock loads
- Low maintenance and service

MAINTENANCE OF HYDROSTATIC DRIVES

Any hydraulic system is fairly easy to maintain: the fluid provides a lubricant and protects against overload. But like any other mechanism, it must be operated properly.

You can damage a hydraulic system by too much **speed**, too much **heat**, too much **pressure**, or too much **contamination**.

Keep the hydrostatic system clean. Impurities such as dirt, lint, and chaff, cause more damage than any one other thing. Seal any openings when doing service work to prevent dirt from entering the system. Be very careful that all parts are clean before replacing them.

NOTE: Any internal service on either the pump or motor must be done under extremely clean conditions. The tolerances in these units are similar to those in diesel injection pumps and equal care must be taken.

Before removing any part of the hydrostatic system for servicing, be sure that area is clean.

Use steam cleaning equipment, if it is available. However, do not let water enter the system. Make sure all hose and line connections are tight.

If steam cleaning is not possible, fuel oil or a suitable solvent may be used. Do not use paint thinner or acetone. Be certain to remove all loose dirt and foreign material that might get into the system when it is opened.

Use a clean work bench or table when disassembling the pump or motor for servicing. Do not perform internal service work on the shop floor or the ground or where there is danger of dust or dirt being blown into parts. Be sure all tools are clean and free of grease and dirt.

Have these items available before disassembling the pump or motor:

1. Several clean plastic plugs to seal openings when removing hydraulic lines or hoses.
2. Several clean plastic bags to place over open ends of lines or hoses. Secure bags with rubber bands.
3. A clean container of solvent to wash internal parts. Use clean compressed air to dry parts after washing.




Fig. 18—A Hydrostatic Drive Propels This Grain Combine

4. A clean container of transmission fluid to lubricate internal parts as they are assembled.

5. A clean container of petroleum jelly (*petrolatum*) to lubricate surfaces where noted during reassembly.

Whenever units are serviced, always install new O-rings, seal, and gaskets during reassembly. This will provide tight seals for mating parts and eliminate leakage.

Do not service the hydrostatic drive system with the machine engine operating unless specifically required.

Never operate the hydraulic system empty. Always check the oil supply after servicing the system.

If the machine is to be stored, be sure the hydraulic system is filled and the reservoir cap is tight. The oil will prevent rust and corrosion.

Always use clean oil in the system. Be careful to use the transmission fluid recommended in the machine operator's manual.

TESTING THE SYSTEM

The only testing required for many hydrostatic drives is for charging and operating oil pressures. Other systems may also require tests for oil flow rate and oil temperature.

Use the proper test equipment and procedures as given in the machine Technical Manual.

TROUBLE SHOOTING OF HYDROSTATIC DRIVES

Follow the general guide here for major problems and remedies. For specifics, see the machine Technical Manual.

NOTE: These trouble shooting charts include some items that will not apply to simpler drives.

MACHINE WILL NOT MOVE IN EITHER DIRECTION

Cause or Symptom	Remedy
System low on oil.	Check oil level. Check for oil leaks.
Faulty control linkage.	Check linkage for binding.
Disconnected coupling	Be sure coupling from engine to pump and from motor to gear train is installed correctly and are not slipping or broken.
Low or zero charge pressure.	Check charge pressure control valve. Also look for binding pump drive shaft or oil line restrictions.
Low on fluctuating charge pressure.	Check for air in system (if noisy). Also look for damaged charge pressure control valve (stuck open) or faulty check valves.

MACHINE MOVES IN ONE DIRECTION ONLY

Faulty control linkage.	Be certain control linkage is connected properly and not binding.
High pressure relief valve stuck open.	Replace valve which is stuck open.
One faulty check valve.	Replace both check valves.
Faulty directional control valve.	Check out speed control.

NEUTRAL HARD TO FIND

Cause or Symptom	Remedy
Faulty speed control linkage.	Adjust control linkage. Be certain linkage is not binding. Also, be sure displacement control valve is adjusted properly. Check out pump servo cylinders for proper adjustment.

SYSTEM OPERATING HOT

Oil level low.	Fill with oil.
Cooler clogged.	Clean cooler air passages.
Engine fan belt slipping or broken.	Tighten or replace fan belt.
Internal leaks. (Usually shown by loss of acceleration and power).	Check for stuck high pressure relief valve. Replace relief valve. Check for internal damage in pump or motor.

SYSTEM NOISY

Air in system.	Check oil supply. Be sure all air is out of system. Check for loose fittings or damaged lines and hoses.
----------------	--

HIGH LOSS OF OIL

Loose connections or leaking lines and hoses.	Tighten connections. Replace damaged lines and hoses. Check O-rings and seats.
---	--

ACCELERATION AND DECELERATION SLUGGISH

Air in system.	Remove all air from system. Check for low oil supply.
Control orifice partially blocked.	Check orifice and spool in displacement control unit for foreign material. If orifice and spool are clean, remove charge pump and clean passage between charge and displacement control unit with compressed air.
Internal damage in pump or motor.	Repair pump or motor as necessary.

TRANSMISSION HARD TO SHIFT OR WILL NOT SHIFT

Cause or Symptom

Speed control lever not in neutral.

Gearshift linkage out of adjustment.

Remedy

Check and adjust linkage to be sure lever is in neutral.

Adjust gearshift linkage in all positions.


TEST YOURSELF

QUESTIONS

1. (Fill in each blank with "high" or "low".) Hydrostatic drives use fluids at _____ speeds but relatively _____ pressures.
2. How is a torque converter different from a hydrostatic drive as defined in Question No. 1?
3. What team of components is the heart of the hydrostatic drive?
4. Does a pump with a movable swashplate have a fixed or variable displacement?
5. What does the charge pump do for the hydrostatic drive oil circuit?

(Answers on page 9 in back of text.)

TORQUE CONVERTERS / CHAPTER 6



X 2194

Fig. 1—Torque Converter In Complete Power Train

INTRODUCTION

A **torque converter** is an automatic *fluid drive*. It transmits engine torque by means of hydraulic force, shifting smoothly through an infinite number of speeds.

The automatic transmission of an automobile automatically shifts gears in response to torque requirements in addition to the automatic response of the torque converter which is a part of the automobile's automatic transmission system.

Actually a gear train is used with the torque converter to give extra speed ranges. But no gear train could give the infinite variations in speed and torque of a torque converter.

Acting as a *clutch*, the torque converter connects and disconnects power between the engine and the gear train. As a *transmission*, the converter gives many more speed ratios than are practical with a strictly mechanical gear box.

To compare a torque converter with a hydrostatic drive (Chapter 5), use this rule of thumb:


Hydrostatic drives are driven by fluids at *high pressure* but at relatively *low velocity*, while **torque converters** are driven by fluids at *low pressure* but at *high velocity*.

Here are the formulas:

- **Hydrostatic Drive** = HIGH pressure + LOW velocity
- **Torque Converter** = LOW pressure + HIGH velocity

HOW IT WORKS

To understand a torque converter, we must first look at a basic **fluid coupling**.



X 2195

Fig. 2—Basic Principles Of A Fluid Coupling

The basic principles of all fluid couplings are shown in Fig. 2.

At the top, a fluid at high velocity strikes a turbine and forces it to turn, driving the wheel. Thus, **torque is transmitted by a fluid.**

To change this torque, the velocity of the fluid is changed. At low velocity, the fluid will not even move the turbine. At higher velocity, the turbine starts turning and the wheel picks up speed.

This is something like putting two electric fans face to face as shown in the lower part of Fig. 2. By plugging in only one fan, we can cause the other one to rotate.

This principle is used in a fluid coupling as follows:

Inside an oil-filled housing (A, (Fig. 3) are two parts: the driving half, or **pump** (impeller), and the driven half, or **turbine**.


As the pump is turned by the engine, centrifugal force causes oil to be forced radially outward, crossing over and striking the vanes of the turbine. This rotates the turbine in the same direction and so couples the power.

Drawings B, C, and D explain how the flow of oil drives the turbine.

In B, fluid is placed in a bowl and lies level.

In C, the bowl is spun rapidly and centrifugal force causes the fluid to climb up and spill over the outside edge of the bowl.

In D, another bowl is placed down over the first one. Now when the bowls are spun an axial flow or circuit is created and turning force is transmitted between the driving bowl and the driven bowl.



X 2196

Fig. 3—Operation Of A Fluid Coupling




Fig. 4—Torque Converter

Torque is thus transmitted, but it is not increased. This is where the **torque converter** goes beyond the basic fluid coupling, for the converter can **multiply torque**.


A torque converter (Fig. 4) looks much like the fluid coupling we have just described. The main difference is that the torque converter has—in addition to the driving pump and the driven turbine—a set of blades or vanes called a **stator**.

The stator vanes change the direction of oil flow after it has gone through the turbine and sends it back to the pump. This enables the pump to increase the twisting force or *multiply* the torque.

Since the converter is a closed unit, this flow is repeated continuously. Many streams of fluid act against many vanes at once and this is what gives the power to drive a heavy machine.

OIL FLOW IN CONVERTER

Let's look at the flow of oil in the converter during two cycles:



X 2199

Fig. 5—Vortex And Rotary Flow In A Fluid Coupling

- 1) Increasing the torque
- 2) Decreasing the torque

INCREASING THE TORQUE

Remember that the pump is driven by the engine, while the turbine receives fluid energy from the pump and sends it to the drive wheels.


Also remember how centrifugal force sets up a continuous circular flow in the coupling (Fig. 5).

This circular flow of oil *between* the pump and turbine is called **vortex flow**.

Another flow is set up *around* the pump and turbine to form a coupling; this is called a **rotary flow**.

The action of these combined oil flows will transmit torque *but not increase it*.

Increasing the torque is where the stator comes into play.



X 2200

Fig. 6—Oil Flow Through Pump, Turbine, And Stator


Fig. 6 shows how oil emerges from the turbine in reverse compared to pump rotation. Unless this oil flow is turned around, it will cause a loss of power.

Note in Fig. 6 that the oil passages at the rim of the turbine where the oil enters must become smaller as they approach the smaller diameter of the turbine. As the same volume of oil must squeeze through these funnel-like passages, the oil stream will speed up when it leaves the turbine. This speed is used to increase torque by directing it against the **stator**, which acts as a fluid lever or fulcrum. The stator changes the di-

rection of flow and sends the oil into the pump in the same direction as pump rotation.


Let's see how the stator does its job (Fig. 7). A stream of oil aimed at a flat surface (A) splashes off at various angles. The oil can be made to flow more smoothly by curving the entrance (B) and can be reversed by more curving (C) with a resulting increase in force as indicated by the large arrow.

The stator has curved blades (as in C) which the oil strikes as it leaves the turbine. These blades turn the oil back in the direction of pump rotation.



X 2201

Fig. 7—Stator As A Fluid Lever




X 2202

Fig. 8—Flow Direction is Reversed By The Stator Vanes

Now that the stream of oil is moving in the same direction but at a greater velocity, it enters the pump smoothly (Fig. 8). Its velocity is added to that developed in the pump so that the total velocity at the pump exits has been increased.


This regenerating action is the key to multiplying torque in a torque converter.

To change the direction of oil flow, the stator must be stationary during the increase in torque.



WHILE TORQUE IS INCREASING -
MORE VORTEX FLOW -
PUMP IS TURNING FASTER

X 2203



WHILE TORQUE IS DECREASING -
MORE ROTARY FLOW -
PUMP AND TURBINE REACH
SAME SPEED

However, once the pump and turbine are turning at the same speed it would create resistance. Therefore, the stator is sometimes mounted on a freewheel clutch so that it can turn in one direction only (once torque stops increasing). (In other torque converters, the stator may be fixed to the converter case.)

DECREASING THE TORQUE

Torque is increased as long as the engine is accelerating to get the machine under way. But as the engine speeds up, the turbine also speeds up, which causes the vortex flow of oil in the converter to decrease. At the same time, the rotary flow increases.

Vortex flow keeps on changing to rotary flow (Fig. 9) until the pump and turbine are "locked up" and all torque increase stops.

The torque converter now acts as a simple fluid coupling, sending the same torque it receives on to the drive wheels.

The torque converter is able to automatically reduce or increase torque in infinitely small steps to match the needs of the machine and its driver. This has the same effect as shifting speeds in a gear transmission except that it is done smoothly and automatically while "on the go."

Fig. 9—How Vortex Flow Changes To Rotary Flow As Torque Is Reduced

VARIATIONS ON TORQUE CONVERTERS


The chart below shows some of the variation in the number of elements used in several torque converters.

Torque Converter Elements	Design A	Design B	Design C	Design D
Pump	2	1	1	1
Stator	2	1	2	1
Turbine	1	2	1	1

The design of a torque converter must match the engine torque and road speed for each application. In off-the-road machinery, units are matched to horsepower (kilowatts) ranging from 40 to 600 (30-450). But the basic principles we've covered apply to all.

TORQUE CONVERTER TRANSMISSIONS

The torque converter is but one part of the complete transmission (Fig. 10).



X 2204

Fig. 10—Complete Torque Converter Transmission

Here are the major components:

- Converter Section
- Range Gear Section
- Final Drive Section
- Hydraulic Control System


Let's look at each part and see what it does for the complete transmission.

CONVERTER SECTION

We have looked at torque converters with three elements—one pump, one turbine, and one stator.

Now we will examine a *twin-turbine* model (Fig. 11) which has one pump and one stator, but two turbines (first and second).

The first turbine is shown in blue, while the second is shown in red.



Each turbine is connected to its individual output gear set. In reality, two converters have been combined into one. The first (blue) turbine is connected to its output shaft by a freewheel clutch.

Here is how the two turbines work together:

When torque demand is high, the freewheel clutch is engaged and the first turbine, assisted by the second turbine, drives the gears. When the machine speeds up, torque demand drops. Then the second turbine takes over the entire load and the freewheel clutch disengages the first turbine.

As a result, the first turbine provides *high torque and low speed*, (for starting up and loading) while the second turbine provides *higher speed with lower torque* (for travel).

A combining gear set directs torque from the first and second turbine (or the second turbine only) to the range gear section.

RANGE GEAR SECTION

Since torque is reduced and increased automatically in the torque converter, only a few gear sets are normally required in the transmission.

However, as the torque converter rotates in only one direction, it is necessary to have a reverse gear. In some applications, it is also desirable to have low and high range gears as shown in Fig. 11.

Simple planetary gear sets meet the needs of extra gear ranges and lends themselves to hydraulic control.

NOTE: Planetary gear sets and their control by hydraulic clutches are explained in Chapter 4.

FINAL DRIVE SECTION

The final drive section includes the transfer drive gear, transfer driven gear and output shaft (Fig. 11). The output shaft provides for one or for two outputs from the same common shaft. Two outputs can be used to propel a four-wheel drive machine as shown in Figs. 11 and 15.

Note also that by adding the transfer gear and one clutch (high range) in Fig. 11, another forward speed range can be obtained.




Fig. 11—Twin-Turbine Torque Converter

HYDRAULIC CONTROL SYSTEM

The hydraulic control system uses oil to do these jobs:

- Oil flow lubricates and cools the parts
- Oil pressure engages the clutches
- Oil velocity drives the turbines

Let's use the hydraulic controls for the twin-turbine converter we have just described to see how a typical system works.

There are four basic circuits as shown in Fig. 12:

- 1) Oil Pump and Filter Circuit (shown by blue lines).
- 2) Main-Pressure Regulator Valve and Converter-In Circuit (shown by red lines).
- 3) Converter-Out, Cooler, and Lubrication Circuit (shown by dotted blue lines).
- 4) Selector Control Valve Circuit (shown by dotted red lines).

Let's build up the system and explain each circuit.




Fig. 12—Hydraulic Control System For Torque Converter Transmission

Oil Pump And Filter Circuit

Oil is drawn from the transmission reservoir by the oil pump as shown in Fig. 12. The pump delivers its entire output to a full-flow oil filter for cleaning. From the oil filter, the oil supply is sent to the main-pressure circuit.

Main Pressure Regulator Valve and Converter-In Circuit

The main pressure regulator valve provides pressure for the planetary clutch packs, directs oil to the selector control valve, and supplies pressure oil into the torque converter. A converter pressure regulator valve in the converter-in line limits the oil pressure there.

Converter-Out, Cooler, and Lubrication Circuit

The torque converter is continuously filled with oil during operation. Rotation of the converter pump imparts energy to the oil which, in turn, drives the turbines. The oil then flows between the stator vanes which redirect it to the pump.

Oil flowing out of the converter is directed into the oil cooler as shown in Fig. 12. The cooler is a heat exchanger in which the oil flows through water- or air-cooled passages.

From the cooler, oil flows to all passages and outlets in the lubrication circuit (dotted blue lines). A lubrication valve between the cooler and lubrication system returns all excess oil to the transmission reservoir.

Selector Valve Circuit

Pressure oil from the main-pressure regulator valve flows into the selector valve bore and surrounds the valve in the area of the detent notches. From this area, main pressure oil is available for operating the low, high, and reverse range planetary clutches (see dotted red lines).

Moving the selector valve allows oil to charge the selected clutch line and to engage that clutch.

This completes the four basic control circuits in our torque converter transmission.

NOTE: For details on hydraulic components, see the FOS "Hydraulics" manual.


SUMMARY: FEATURES OF TORQUE CONVERTERS

1. Multiply torque
2. Provide infinite speed ranges
3. Shift smoothly and automatically
4. Cushion shock loads on drive lines
5. Help to dampen vibrations

TROUBLE SHOOTING


INTRODUCTION

Oil circulates at high velocity within the torque converter and any foreign material it carries will rapidly wear down the edges and pit the turbine vanes (Fig. 13), changing their effective shape.



X 2207

Fig. 13—Turbines For Twin-Turbine Torque Converter



X 2208

Fig. 14—Pump For Torque Converter

Vane damage will also cause the turbines to become unbalanced. In addition, dirty oil will damage bearings and seals.

Some torque converters contain parts made of lightweight aluminum alloys (Fig. 14). Converter housings are usually made of cast aluminum.

Be sure to handle all converter parts carefully to prevent nicking, scratching, and denting.

Parts which fit together closely but with operating clearance will stick if damaged only slightly. Parts which depend upon smooth surfaces for sealing may leak if scratched.

All these parts should be carefully handled and protected during removal, cleaning, inspection, and installation.

Use these rules to help prevent failures:

1. Be sure the oil is kept clean.
2. Service the system at proper intervals.
3. Repair it only if you are qualified.
4. Use all special tools recommended.
5. See the machine Technical Manual for details.

PRELIMINARY INSPECTION

The operator and serviceman can use his eyes, ears, and even his nose to head off trouble before serious damage is done. Here's how:

Look *Check oil levels.* Refer to the operator's manual.

Check gauges. When starting, running or stopping, watch the gauges; they tell the story in terms of pressure and temperature.

Inspect for leaks. Leaks, crimped oil lines, and clogged filters — all affect the converter output.

Examine the oil. Look for water, dirt, and particles from the converter and the clutch plates.

Listen *Unusual noises.* Listen for squealing from a stuck valve, or grinding or grating sounds from inside the converter.

Smell *Overheating.* A strong odor of overheated oil is a major trouble sign. Find the cause at once.

Because one trouble can have the same symptoms as another, only good instruments in the hands of trained servicemen can detect the difference.

Once trouble has been detected in the field, check out the unit with the proper testing tools.

TROUBLE SHOOTING PROBLEMS

The trouble shooting given here will cover four common areas of trouble:

1. *Overheating*
2. *Noise*
3. *Leaks*
4. *Machine Response*

Let's examine each kind of trouble.

1. Overheating

Overheating is a major problem in converter operation. It is affected by the design, the type of work, the operator, the air temperature, and the condition of the unit.

Overheating can cause a loss of power and can damage seals and gaskets and warp metal parts.

A converter may overheat if the *work is heavy*—not always, but heavier work will generally mean more heat.

If the converter is *undersized* for the normal work of the machine, it will operate at low efficiency and will tend to overheat. The operator can usually relieve the load on the converter by operating in a lower gear, or by reducing the load.

Whenever you receive complaints that a converter in a machine is overheating, try to find out by watching or by questions whether the correct gears and work methods are being used.

Air in the converter will also cause overheating. Torque converters can work properly only if they are filled with fluid. Air mixed with the oil will cause poor performance, overheating, and possibly serious damage.

Air may enter the system:

- (1) If the fluid in the reserve tank (if used) is low enough to permit the charging pump to suck air.
- (2) If a moderately low level of oil permits sucking of air while the machine is working on steep slopes.
- (3) If there is a leak in the suction line pump gaskets or O-rings (suction leaks may be too small to show up by outside leaking of oil).
- (4) If the oil or filters are changed or when the lines are opened for any reason.

SUMMARY: OVERHEATING

Let's recap the major causes of overheating in the torque converter.

First, overheating is not only a major problem, it is also a major symptom.

Although normal operating temperatures can be exceeded very rapidly, a machine using a torque converter matched to the job should not exceed its normal temperature when properly used.

Second, the cause of overheating may be found in one or more areas outside of the converter.

Before deciding that the converter is the cause of overheating, check these possibilities:

- (a) Air in fluid system.




Fig. 15—Torque Converter Transmission In Four-Wheel Drive Machine

(b) Lack of cooling—plugged cooler core, low coolant level, defective water pump (water-cooled systems only).

(c) Low fluid level—clogged filter, excessive leakage past converter seals, restricted oil line, defective oil pump.

(d) Slipping clutches in planetary gear sets.

Third, failure of the converter may cause the overheating. Worn edges and pits on vanes of pump, stator, or turbines will reduce their efficiency.

2. Noise

Unlike overheating, which can be tested, noise is hard to explain to another person.

A new operator or serviceman may never hear a noise directly related to a converter failure.

Yet, an unusual noise heard by an experienced operator or serviceman may be the first sign of damage in the converter.

Noise from a converter malfunction may be a whining or growling and may be steady or intermittent.

Worn or dry bearings often produce a hissing noise that will develop into a bumping or thudding sound when they completely fail.

Other sources of noise are: Worn gears, worn or bent shafts, excessive shaft endplay, shafts misaligned with the engine, and worn freewheel clutches. All these noises mean a possible converter failure.

A mechanic's stethoscope is a valuable aid for isolating noises in the converter.

3. Leaks

Converter leaks can be one of two types:

- *Internal leaks*
- *External leaks*

INTERNAL LEAKS

By internal leaks we mean those *within* the converter.

As we learned earlier, the converter uses large amounts of oil at high velocity.

If oil is lost from the converter housing by leaks in the pump, turbine, or stator, a loss of power or erratic operation will occur.

Leaks may be caused by the wrong torque on converter bolts.

On some converters, the housing which covers the converter can be removed to determine if a leak has occurred in the converter. Check by starting the engine and operating the transmission until the oil leak shows up.

If leaks form around the converter cover, check the tightness of the cover bolts with a torque wrench. If this fails to correct the leak, disassemble the cover, check the machine surfaces of the cover and flywheel, and install a new gasket.

EXTERNAL LEAKS

By external leaks we mean those occurring outside the converter but still affecting its operation.

These include leaks at cooler lines, filter lines, and pressure or temperature gauge fittings.

Visually check all fittings and oil lines for leakage.

4. Machine Response

Normally a malfunction in the converter will affect the machine's response to load and speed changes.

A machine which lacks power and acceleration at low speed may have a turbine freewheel clutch failure.

Changes in hydraulic pressure, flow, and temperature also affect the performance of the converter, and thus affect the machine's performance.

If you picture the converter as in Fig. 7 (a flow of oil from a nozzle) it is easy to see how heavy cold oil, low pressure, or low flow will affect a response.

TESTING THE TORQUE CONVERTER

As in trouble shooting, *testing* is most effective when the engine, converter, and gear train are regarded as a unit, one part affecting the other.




Fig. 16—Pressure And Temperature Check Points On A Typical Torque Converter Transmission

Fig. 16 shows the points where pressures and temperature may be tested on a *typical* torque converter.

Before testing, several checks should be made.

BEFORE TESTING

1. Check the fluid level. Be sure it is not *above* or *below* the required level.
2. Start the engine and warm the engine and transmission to operating temperature.
3. Shift into each gear and operate for a minimum of 15 seconds, checking the selector valve detent positions against the related positions on the shift indicator (if equipped).
4. *Never allow the transmission to heat up beyond the maximum operating temperature.*

TESTING PRESSURE AND TEMPERATURE

Attach the necessary temperature and pressure gauges to the converter. Be sure that all tests are performed as required by the machine Technical Manual.

For example, tests made on the typical unit in Fig. 16 are as follows:

- (1) Main Pressure (at full throttle—no load).
- (2) Converter-Out Pressure (at full throttle—no load and at full throttle stall in high range).
- (3) Lubrication Pressure (at full throttle—no load).
- (4) Converter-Out Temperature (during normal operating conditions).

TRANSMISSION STALL TEST

IMPORTANT: Be sure to consult the machine Technical Manual before conducting a stall test. Some manufacturers do not recommend this test.

The stall test tells whether or not the engine, torque converter, and transmission are performing satisfactorily as a unit.

The test is made while the output shaft is braked and the engine is running at full throttle.

Refer to the engine-converter matched performance curve to find the acceptable speed at stall (see the Technical Manual).

Procedure

1. With the transmission warmed up, connect an accurate tachometer to the engine.
2. Block the machine securely and shift to the desired range.
3. Accelerate the engine to full throttle.
4. After reaching a stabilized engine speed, record the engine speed.

IMPORTANT: Because of rapid heating of the oil, never hold the machine stalled for more than a few seconds at one time.

Results

If the engine and transmission are failing, it will show up when the actual engine speed in the stall test is compared to the normal speed in the engine-converter chart.

Allow for variations in the test speed due to climate, altitude, engine accessory loads, and power input at converter, all of which affect the stall test results.

TEST YOURSELF

QUESTIONS

1. (Fill in the blanks.) A _____ can only transmit torque, while a _____ can multiply the torque it receives.
 2. What part in a torque converter directs the fluid back to the pump?
 3. (Fill in the blanks.) Once torque demand is reduced in the converter, the pump and turbine "lock up" and _____ flow is changed to _____ flow.
 4. True or false? "The stator will turn in either direction."
 5. True or false? "Only one turbine can be used in a single torque converter."
 6. Match each item below with the best match at the right.

a. Oil flow	1. Drives the turbines
b. Oil velocity	2. Engages the planetary clutches
c. Oil pressure	3. Lubricates and cools
- (Answers on page 9 in back of text.)

DIFFERENTIALS / CHAPTER 7



Fig. 1—Differential In Complete Power Train

INTRODUCTION

The *differential* does two jobs:

- Transmits power "around the corner" to the drive axles.
- Allows each drive wheel to rotate at a different speed and still propel its own load.

The ring gear and bevel gears direct the power to the axles, while the bevel pinions give the differential action (Fig. 2).

We saw in Chapter 1 how the differential works. Let's review it briefly here.



OPERATION

When the machine is moving straight ahead, *both wheels are free to rotate* as shown in Fig. 2.

Engine power comes in on the pinion gear and rotates the ring gear. The four bevel pinions and the two bevel gears are carried around by the ring gear and all gears rotate as one unit. Each axle receives the same rotation and so each wheel turns at the same speed.

When the machine turns a sharp corner, only *one wheel is free to rotate* as shown in Fig. 2.

Again engine power comes in on the pinion gear and rotates the ring gear, carrying the bevel pinions around with it. However, the right-hand axle is held stationary and so the bevel pinions are forced to rotate on their own axis and "walk around" the right-hand bevel gear.



BOTH WHEELS FREE TO ROTATE



ONE WHEEL FREE TO ROTATE

Fig. 2—Differential In Operation

Since the bevel pinions are in constant mesh with both bevel gears, the left-hand bevel gear is forced to rotate because it is subjected to the turning force of the ring gear which is transmitted through the bevel pinions.

During one revolution of the ring gear, the left-hand gear makes two revolutions—one with the ring gear and another as the bevel pinions “walk around” the other bevel gear.

As a result, when the drive wheels have unequal resistance applied to them, the wheel with the least resistance turns more revolutions. As one wheel turns faster, the other turns slower by the same amount. However, both wheels still propel their own loads—but at different speeds.

Differential action can be a disadvantage when the wheels slip. For example, when a farm tractor is plowing, one wheel may lose resistance on slick ground and start spinning while the other wheel holds. Then the driving power is limited by the “wasted” power sent to the wheel that slips.

To prevent this loss of power, *differential locks* are often used, as we'll see now.

DIFFERENTIAL LOCKS

A *differential lock* directs power equally to both wheels by locking out the differential. This prevents the usual loss of traction when one wheel is slipping.

Three types of differential locks are used:

- **Mechanical**
- **Hydraulic**
- **Automatic (No-Spin)**

Let's see how each lock operates.




Fig. 3—Mechanical Differential Lock On Farm Tractor

MECHANICAL LOCKS

The simplest differential lock is the *mechanical* one shown in Fig. 3.

When the operator moves the upper lever, the fork rotates and slides the collar to the right. This engages the differential housing splines to the collar. Since the collar is already on the axle splines, both the axle and the housing are forced to rotate as a unit. This in turn prevents the bevel gear on the axle from turning and so locks the differential.




Fig. 4—Hydraulic Differential Lock On Farm Tractor

When the drive wheels again have equal traction, the lock disengages automatically. This happens because the collar is spring-loaded and releases once the torsional forces are gone.

This lock can be engaged "on the go." However, it should always be disengaged before turning the machine.

HYDRAULIC LOCK

The *hydraulic lock* (Fig. 4) uses pressure oil to lock out the differential.

When the operator depresses the pedal, the valve allows pressure oil to flow to the differential. The oil presses the piston against the disk clutch, com-

pressing it against the housing. Since the disks are splined to the bevel gear and the plates are tanged to the housing, this locks up the bevel pinions and prevents differential action.

This lock can also be engaged "on the go".

When the operator releases the pedal, the valve cuts off oil pressure to the piston, allowing springs to return it, freeing the disk clutch. The differential then operates normally.

The pedal on this unit is linked to the tractor's brake pedals. This is a safety release and unlocks the differential whenever the brake pedals are used, preventing the danger of turning the tractor sharply with the differential lock still engaged.

AUTOMATIC (NO-SPIN) LOCK





Fig. 5—Automatic (No-Spin) Differential Lock During A Left Turn

The *automatic (no-spin) lock* (Fig. 5) is different in that it is normally *engaged* and still allows for relative motion between the wheels on a corner.

A speed-sensitive differential control, when engaged, prevents one wheel from spinning when it loses traction and thereby depriving the other wheel of full driving power.

The no-spin unit is located inside the differential housing and replaces the bevel gears, bevel pinions, and their shafts.



X6698

FOS-40

Litho in U.S.A.

In Fig. 5, both axles are splined to the *side gears* of the no-spin unit—one on each side. The side gears in turn are splined to the *driven clutches*.

When driving straight ahead, the clutch teeth of the *spider*, and the driven clutches are fully engaged, and the spider drives the driven clutches. The whole system then rotates as a solid unit. The parts are held engaged by springs (Fig. 6).

When the machine is turned to the left the right driven clutch rotates faster to make the turn, through the overrunning action of the right wheel. The teeth on the right holdout ring slide up on the teeth of the center cam, forcing the teeth of the right driven clutch to disengage from the spider teeth (Fig. 7). Meanwhile, the left driven clutch is held engaged to the center cam by resistance of the slower left wheel.

As the turn is completed and the overrunning motion stops, the speed of the spider and the right driven clutch become the same again. There is a slight reversal of torque which causes the holdout ring to move back into phase with the teeth on the driven clutch, engaging all teeth again.


The whole mechanism then returns to the fully locked position until another turn.

The no-spin unit does not allow the inside wheel on a turn to slow down—only the outside wheel to speed up. For this reason, it cannot be used on machines with a great difference in wheel speeds on a turn. In a tight turn, these machines would not decelerate to a safe speed.

ADJUSTMENT OF DIFFERENTIALS

The ring gear and pinion in the differential are normally adjusted for bearing **preload** and gear **backlash**.

Chapter 1 has a story on "Adjusting The Gear Train." It explains the effects of wrong adjustment and gives an example of ring gear and pinion adjustment for a differential unit.



X6699




Fig. 8—Automatic (No-Spin) Differential Lock In Exploded View

TROUBLE SHOOTING

Here is a guide to the common failures of differentials and the possible causes.

1. NOISE IN DIFFERENTIAL AT ALL TIMES

- Incorrect adjustment of ring gear and pinion.*
- Ring gear or pinion damaged.*
- Damaged bearings on pinion shaft.*
- Damaged bearings in differential housing.*

2. DIFFERENTIAL NOT WORKING FREELY ON TURNS

- Damaged or galled bearing surfaces between bevel gears and differential housing.*
- Damaged or galled bearing surfaces between bevel pinions and differential housing.*
- Damage or galling between bevel pinions and their shafts.*

3. MECHANICAL DIFFERENTIAL LOCK DOESN'T HOLD

- Linkage between engaging lever and shifting collar broken or improperly adjusted.*
- Shifting collar broken or missing.*

4. HYDRAULIC DIFFERENTIAL LOCK DOESN'T HOLD

- Too-low oil pressure.*
- Blown oil seals or gasket.*
- Failed control valve.*

TEST YOURSELF QUESTIONS

- What two jobs does a differential do?
- What are differential locks for?
- Name the three types of differential locks.
- Why is the hydraulic lock sometimes linked to the brake pedals?
- Which type of differential lock is normally engaged?
- True or false? "The no-spin differential allows one wheel to turn slower and the other faster than ring gear speed."

(Answers on page 10 in back of text.)

FINAL DRIVES / CHAPTER 8




Fig. 1—Final Drives In Modern Tractor

INTRODUCTION

The final drive is the last phase of the power train. It gives the final reduction in speed and increase in torque to the drive wheels.

Used on most large machines, the final drives are mounted near the drive wheels (Fig. 1).

By reducing speeds, the final drives lower the stress and simplify the transmission, since extra gears and shafts can be eliminated.

Most final drives must support the weight of the machine as well as withstanding torque and shock loads.

TYPES OF FINAL DRIVES

There are four major types of final drive systems:


- **Straight Axle**
- **Pinion**
- **Planetary**
- **Chain**

Each of these four drives have their advantages. All but the first give a speed reduction.


Let's look at each one in detail.

STRAIGHT AXLE DRIVES

The straight axle drive is the least complex of all final drives. It is commonly used in automobiles and light-duty trucks where no extra gear reduction for heavy loads and pulling power is required.



RIGID AXLE SHAFT



FLEXIBLE AXLE SHAFT

Fig. 2—Straight Axle Drives — Two Types

The drive wheels in a straight axle receive their power directly from the differential. For each revolution of the differential, the axle shaft and wheels make a revolution, giving a direct drive.

The drive axle in any final drive system is known as a "live" axle since it transmits the engine torque as well as supporting part of the machine weight. A "dead" axle on the other hand is one which only supports the machine, such as the front wheel axles of an automobile.

There are two types of straight axle construction:

- **Rigid Axle Shaft**
- **Flexible Axle Shaft**

The RIGID AXLE SHAFT (Fig. 2) is connected to the differential output by a splined coupling and is usually enclosed in an axle housing. The axle housing forms an integral part of the differential housing, making one long housing from drive wheel to drive wheel.

The FLEXIBLE AXLE SHAFT (Fig. 2) is used when the drive wheels are independently suspended.

The axles are connected to the differential by universal joints. This type of axle is sometimes referred to as a "swing axle". The drive wheel in this case is free to move vertically without affecting the position of the differential and transmission. Flexible axles are commonly found in compact automobiles and especially those with engines located in the rear.

FLOATING AXLE SHAFTS IN RIGID DRIVES

Two kinds of floating axles are being used today:

- 1) *Full-Floating Axles*
- 2) *Semifloating Axles*

They differ in whether or not they have to carry the weight of the vehicle in addition to turning the wheels.

Full-Floating Axle






Fig. 3—Full-Floating Axle Shaft

The full-floating axle (Fig. 3) is used in many heavy-duty trucks. Each drive wheel is carried on the outer end of the axle housing on a pair of tapered roller or ball bearings. The bearings are positioned outside the axle housing. In this way the axle housing takes the full weight of the vehicle and absorbs all stresses or end thrust caused by turning, skidding, etc. The axle shaft then only transmits the torque from the engine and so "floats" in the axle housing. The shaft is connected to the drive wheel through a bolted flange and the axle shaft can be removed or serviced without removing the drive wheel.



X 2184 TAPERED ROLLER BEARINGS AND SHAFT



X 2185 BALL BEARINGS AND FLANGED SHAFT

Fig. 4—Semifloating Axle Shafts—Two Types

Semifloating Axles

Semifloating axle shafts (Fig. 4) float in the differential in the same way as full-floating axles. The main difference is at the outer ends of the axle housing. Here a single bearing assembly is positioned between the axle shaft and axle housing (Fig. 4). Therefore, the shaft supports the weight of the vehicle as well as transmitting the engine torque. The axle shafts must now take all stresses caused by turning, skidding, etc.

Two types of wheel bearings are used in semifloating axles—either tapered roller bearings or ball bearings (Fig. 4).

When tapered roller bearings are used, an adjustment for axle shaft endplay is provided. This is done with shims or an adjusting nut at one end of the axle housing. In order to transmit shaft end thrust equally to the bearings at both ends of the axle housing, a thrust bloc, or spacer is located between the inner ends of the two axle shafts within the differential carrier.

Semifloating axles are commonly used in automobiles and light trucks. The outer ends of the shaft may be flanged or tapered as shown in Fig. 4. When the shaft is tapered, the wheel hub is keyed to the shaft and locked in place with a nut.

PINION DRIVES

A spur gear and pinion are used for the final gear reduction on many tractors and self-propelled machines. This enables the differential to transmit power at higher speeds and lower torque.

There are two types of pinion and gear reductions:


- Pinion drive located within differential case.
- Pinion drive located on outer ends of final drives.

Each has a purpose and some advantages, as we'll see now.

PINION DRIVE WITHIN DIFFERENTIAL CASE

The advantages of having the gear reduction directly driven from the differential are:

- 1) All gears are enclosed within the differential-transmission case. This is a more compact unit and only one lubrication system is needed.
- 2) The final drive is in a straight line, permitting a straight axle shaft. On farm tractors this is a big advantage, since a straight axle provides a large range of wheel tread adjustment for operating in various row-crop spacings.



X 2186

Fig. 5—Pinion Gear Reduction Within Differential Case

Power is transmitted to the drive wheels through pinion gears which are connected to the differential output. The pinions mesh with the larger final drive gears which in turn rotate the axle shaft (Fig. 5).

The axle shaft is carried on two tapered bearings, while the final drive gear is splined to the inner

end of the shaft. The bearings are positioned internally at both ends of the shaft between the axle housing and shaft. Bearing adjustment is usually made with an adjusting nut. However, some final drives may be equipped with a shim adjustment.

The axle supports the weight of the tractor and absorbs end thrust, as well as transmitting the engine torque.

PINION DRIVE ON OUTER ENDS OF FINAL DRIVE




Fig. 6—Pinion Gear Reduction On Outer Ends Of Final Drives

Placing the pinion and gear reduction drive at the outer end of the final drive gives more clearance under the axle. The gears are contained in a separate case or housing (Fig. 6) and have their own oil reservoir. Power flow is shown by the red arrows.

This system is popular for good crop clearance in farm tractors and other machines.

On most farm tractors, the drive shaft is enclosed in a housing which is attached to the differential case. In turn the gear reduction housing is attached to the end of the drive shaft housing, forming the final drive assembly. This final drive construction is sometimes called a "drop axle housing". In this case, the entire final drive assembly carries the weight of the tractor.

PLANETARY DRIVES

The planetary gear reduction system is smaller and more compact than the pinion type. Planetary systems are also more durable under heavy loads since torque loads are spread more evenly over several gears.

The use of planetary gear systems is becoming more common on farm tractors, industrial machines, and trucks as engine horsepower and pulling loads are increased.

The planetary gear set may be located next to the differential (Fig. 7) or at the outer ends of the final drive (Fig. 8). Both types—inboard and outboard—operate the same, as described below.




Fig. 7—Final Drive With Planetary Gears Next To Differential (Inboard Type)




Fig. 8—Final Drive With Planetary Gears At Outer Ends (Outboard Type)

OPERATION

The planetary gear reduction system receives engine power from the differential through the final drive shaft and sun gear. The sun gear is an integral part of the final drive shaft and so turns with the shaft. The sun gear meshes with the planet pinions which are mounted in the planet pinion carrier.

As the sun gear turns, it forces the planet pinions to "walk around" the inside of the ring gear as shown by the arrows. The planet pinion carrier is forced to rotate in the same direction as the sun gear, thus delivering engine power to the drive wheels *but at a reduced speed and an increased torque*.

CONSTRUCTION OF PARTS

Let's look at the construction of the planetary systems shown in Figs. 7 and 8.

Planetary Mounted Next To Differential (Fig. 7)

With this planetary, a straight, in-line axle is achieved. This permits a large range of wheel tread adjustments on farm tractors for various widths of crop rows. In addition, all gears are located in one compact housing.

The axle shaft is carried on two tapered bearings with the inner end of the shaft splined to the planet carrier (Fig. 7). The bearings are positioned internally at both ends between the axle housing and shaft.

With this type of axle, the axle shaft supports the weight of the tractor and absorbs end thrust, as well as transmitting engine torque.

Planetary At Outer Ends Of Final Drives (Fig. 8)

When the planetary is located at the outer ends of the final drive, the final drive system is enclosed

in one rigid housing (Fig. 8). That is, the differential housing, both axle housings, and the planetary gear housings (shown) are connected to form a one-piece construction.

The axle shaft in this system is the *full-floating* type which was described earlier. The only difference is that the planetary carrier drives the wheel hub instead of a flanged end of the axle shaft.

CHAIN FINAL DRIVES

The chain final drive system (Fig. 9) provides a greater clearance under the axle than any other system. An example of this is in high-clearance self-propelled sprayers which must operate in high, standing crops.




Fig. 9—Chain Final Drive System

The disadvantage of a chain drive is its tendency to loosen due to wear and stretching. Wear can be held to a minimum by having the chain operate in an oil bath. In most cases, provisions are made to take up the chain slack.

In Fig. 9, an eccentric bearing is provided in the axle housing so that the chain slack can be taken up by rotating the bearing housing. In some tractors, the entire axle housing can be moved for chain adjustment.

Another method of adjusting the chain is the use of a tightener sprocket on the slack side of the

chain. However, when the machine is reversed, extra force is exerted to the slack side of the chain and through the tightener sprocket.

For details on roller chains, see Chapter 10.

MAINTENANCE OF FINAL DRIVES

The reliability of any final drive depends upon good maintenance, operating at rated load, and proper repair once a failure has occurred.

Watch these key points when diagnosing final drive failures:

- (1) Excessive drive shaft endplay
- (2) Overheating
- (3) Lack of lubrication

EXCESSIVE DRIVE SHAFT ENDPLAY

Excessive drive shaft endplay is normally caused by loose shaft bearings. However, it can be created by:

- (a) Foreign material in the lubricant which will wear bearings rapidly;
- (b) Overloading the machine either by weight or engine torque;
- (c) Poorly adjusted bearings at the time of assembly.

A continuous noise or knock is a good sign of loose or damaged bearings. On machines with semifloating axles, such as automobiles, the knocking noise can be heard in the differential case, since the ends of the axle shaft are rapping the spacer block. Readjustment of the bearings that are worn or damaged will not provide a satisfactory repair. Instead, replace the bearings.

Compare the roller ends of a new tapered bearing with a worn bearing. Worn bearing rollers have no shoulder compared to a new bearing—replace them.

OVERHEATING

Many final drives are damaged simply by overheating. This is caused by not maintaining the lubricant at the proper level or by using the wrong type of lubricant.

Galling, pitting, or scoring on the surface of a part indicates the lack of lubricating film and that overheating has occurred.

Overloading and abuse of the machine will also cause overheating. Excessive loads cause deflection in the final drive assembly and concentrate stresses and friction in one area.

LACK OF LUBRICATION

Loss of lubricant through worn and broken oil seals and gaskets may cause severe damage to the final drive. While some bearings are automatically lubricated by oil creeping along the drive shaft from the differential, others are sealed off and require separate lubrication.

When installing a new oil seal, make sure it is flexible or pliable in the area where the seal fits around the shaft. Soak the seal in oil before installing it.

ADJUSTING FINAL DRIVES

To prevent premature failures, adjust the final drives properly. This includes adjusting the axle bearings—either preloading or allowing a specified endplay.

ADJUSTING AXLE BEARINGS

Loose gears or bearings that are too tight or too loose will break down prematurely, regardless of their strength and design.


Bearings must be adjusted to the manufacturer's specifications. Some designs require the bearings to be preloaded, while others require a slight amount of shaft endplay.

Preloading Bearings

When the manufacturer's instructions call for preloading the bearings, bearings must be placed under slight tension. In some cases, this is done by SLIGHT overtightening of the bearing adjusting nut, while in other designs it is done with shims. Preload is normally measured in inch-pounds of rolling or rotating torque (NOT starting torque).

Some torque specifications will include frictional drag such as oil seals, gears, etc. in the final drive. If it is not included, measure the rolling torque while the axle shaft still has a slight amount of endplay, and add this torque reading to the specified torque. Then make the necessary bearing preload adjustment. Also, when new bearings are installed, a greater amount of torque will be required. Always make the preload adjustment in small increments until the proper preload is obtained.


There are several methods of measuring rolling torque.



R 13330

Fig. 10—Checking Bearing Preload With A Torque Wrench

One method is to use a special tool or adapter with a torque wrench (Fig. 10). This gives a direct reading on the wrench.



R 13330

Fig. 11—Checking Bearing Preload With Pull Scale

Another method of checking the preload torque is by means of a cord and pull scale (Fig. 11). The preload is figured by multiplying the radius (distance from the center of the drive shaft to a point on the circumference from which the cord is pulled) by the reading on the pound scale.

For example: Assume the radius is 4 inches (100 mm) and the reading on the scale is 7 pounds (31 N). Multiply 4 inches (100) by 7 pounds (31) and you will have 28 inch-pounds (3.1 N·m) of rolling torque ($100 \times 31 = 3100 \text{ N} \cdot \text{mm} = 3.1 \text{ N} \cdot \text{m}$).

Adjusting For Endplay

Some types of drive axles call for the axle shaft to have a slight amount of endplay. This means that the shaft when properly adjusted must be free to move endways within the limits specified. The end movement in most cases is between 0.001 and 0.010 inch (0.025 and 0.25 mm).




Fig. 12—Checking Final Drive Shaft Endplay
With A Dial Indicator

To obtain the proper endplay, shims or an adjusting nut are provided. Measure the endplay with a dial indicator (Fig. 12).

TEST YOURSELF

QUESTIONS

1. What are the four major types of final drive systems?


TEST YOURSELF

QUESTIONS

1. What are the four major types of final drive systems?
2. Which one does *not* give a speed reduction?
3. What is the difference between a "live" and "dead" axle?
4. True or false? "In a semifloating axle, the weight of the machine is not carried on the axle shaft."
5. Name one advantage of the planetary final drive over the other three types.
6. What is the main advantage of the chain final drive? The main disadvantage?

(Answers on page 10 in back of text.)

POWER TAKE-OFFS / CHAPTER 9



X2118

Fig. 1—Power Take-Off (PTO) For Modern Tractor

The power take-off (PTO) is an attachment in the power train of a machine. It drives auxiliary equipment.

TYPES OF PTO'S


There are three basic types of PTO's:

- **Transmission-Driven**
- **Continuous-Running**
- **Independent**

The three types are compared in Fig. 2.


TRANSMISSION-DRIVEN PTO's operate only when the engine clutch is engaged. They stop whenever the clutch is disengaged (stopping machine travel).

CONTINUOUS-RUNNING PTO units have two clutches—one for the transmission and one for the PTO. Both clutches are operated by one control. The first half of the control travel operates the transmission clutch, while the second half operates the PTO clutch. Therefore, the PTO can be operated with the transmission disengaged (machine travel stopped). However, the transmission cannot be engaged again while the PTO is operating.




X3314

Fig. 2—Three Types Of Power Take-Offs (PTO'S)



X2120

PTO OPERATING AT 1000 RPM



PTO OPERATING AT 540 RPM

Fig. 3—Operation Of Power Take-Off (Dual Speed Type)

INDEPENDENT PTO's have their own clutch controls completely separate from the engine clutch and transmission. This means that the PTO can operate while the machine travel is stopped and also that the PTO can be disengaged and engaged while the machine is in motion (not possible with continuous-running PTO's).

OPERATION OF PTO

Most PTO's are gear-driven from the transmission and send power through a shaft to the PTO outlet where the driven equipment is coupled.

Let's look at the operation of a typical PTO.

One PTO (Fig. 3) offers two speeds—540 rpm and 1000 rpm.

To get these speeds, two different stub shafts are used as we'll explain now.

OPERATION AT 1000 RPM

Operation at 1000 rpm is shown at left in Fig. 3.

The 1000 rpm stub shaft is installed in the PTO outlet so the splines engage with the splines on the inside of the PTO shaft. Engine power is transmitted directly through to the PTO stub shaft.

The engine is set at a certain speed (such as 2100 rpm) to get the speed of 1000 rpm at the PTO.


OPERATION AT 540 RPM

Operation at 540 rpm is shown at right in Fig. 3.

A different stub shaft is installed in the PTO outlet for 540 rpm operation. This shaft engages a new set of splines inside the PTO drive gears, so power is transmitted through the upper idler gears as shown by arrows. The speed is reduced to 540 rpm by the gear ratios.

PTO DRIVES

Once the power leaves the PTO outlet, it must be transmitted to the driven equipment. This is the job of the PTO **drive** (Fig. 4).



X7800

Fig. 4—PTO Drive

The PTO drive must be flexible for most equipment, especially if it is pulled by the driving ma-

chine. For these PTO drives, two major parts are needed:

- 1) *Universal Joints*
- 2) *Drive Shaft*


Let's look at each part in detail.

UNIVERSAL JOINTS

A universal joint is necessary to join two rotating shafts in different planes (Fig. 4).


The most common type is the Cardon or **Hooke joint** (Fig. 5).

This joint consists of two U-shaped yokes fastened to the ends of the two shafts to be connected. Inside these yokes is a cross-shaped journal which holds the yokes together and allows each yoke to bend, or pivot, with respect to the other. This allows one shaft to drive the other at angles up to 30 degrees out of alignment.



X2182

Fig. 5—Universal Joint (Hooke Type)



X2123

Fig. 6—Universal Joint (Bendix-Weiss Type)

Another type of universal joint is used to transmit a smoother torque when less power is needed. This type of universal joint is the **Bendix-Weiss** (Fig. 6). This type of joint has four large balls to transmit the rotary force, with a small ball as a spacer.

The Hooke universal joint gives a whipping motion as the shaft rotates. The amount of whipping depends on how much the shafts are out of alignment. The Bendix-Weiss joint transmits rotary motion at a constant rate, but this joint is more expensive and has less strength than the Hooke type.

Most farm and industrial machines use the Hooke type of U-joint.

DRIVE SHAFTS

There are two basic types of drive shafts:

- *Solid shaft*
- *Telescoping shaft*

The difference is that one shaft has a flexible length while the other does not.

Solid Shafts


The solid shaft has a fixed length and a universal joint at each end. The distance between the two joints is always fixed. This type of drive is used when power is to be transmitted from one fixed plane to another.

Telescoping Shaft

The telescoping shaft has a sliding element and can have either two or three universal joints.

The telescoping shaft with *two* universal joints has one at the machine end and another at the equipment end (Fig. 7). Telescoping occurs between these two points at the slip joint.

The telescoping shaft with *three* universal joints has one solid PTO shaft (on a mount), one telescoping shaft, and three universal joints. This gives the flexibility of the two-joint type, yet allows for the change in hitch angle when equipment is converted to transport position.




X2124

Fig. 7—Telescoping PTO Shaft

STANDARDS FOR PTO DRIVES

ASAE-SAE Tractor Standards

The American Society of Agricultural Engineers (ASAE) along with the Society of Automotive Engineers (SAE) have worked for years to establish standards for tractor and implement manufacturers. These standards help in changing equipment from one tractor to another.



X2125

Fig. 8—Location Of PTO Shaft And Drawbar Hitch On Farm Tractor (ASAE-SAE Standards)

The recommended location of the drawbar hitch point in relation to the PTO shaft for equipment drawn behind a tractor is shown in Fig. 8.

In addition, the lateral location of the PTO shaft should be within 3 inches of the tractor centerline, and the hitch point should be directly under the extended centerline of the PTO shaft.

The PTO shafts of tractors have also been standardized. The shafts have either six splines and rotate at 540 rpm, or twenty-one splines and rotate at 1000 rpm (Fig. 9).




Fig. 9—PTO Shafts—Two Types

All PTO shafts rotate clockwise when viewed from the rear of the tractor.

PTO Shielding Standards

The tractor PTO shaft and the equipment drive shaft must be covered at all times.


The tractor PTO shaft shield is provided by the tractor manufacturer, while the equipment drive shaft shielding is provided by the equipment manufacturer.

The ASAE and SAE have standards by which manufacturers can build master shields for their PTO shafts.

The equipment drive line has two basic types of shields:

- 1) *The tunnel shield*
- 2) *The spinner shield*

The tunnel shield is merely an inverted U-shaped piece of steel which covers the moving parts.



X2127

Fig. 10—Spinner Shield For PTO Drive Shaft

The spinner shield (Fig. 10) is a cylinder-shaped piece which surrounds the shaft with a bell housing on each end to cover the U-joints.

The spinner shield rotates with the shaft except when contact is made with a foreign object. When this happens, the spinner shield stops rotating and allows the shaft to rotate freely inside the shield.




Fig. 11—PTO Shaft Guard And Master Shield

SERVICING THE PTO DRIVE

The service life you get from your PTO drive depends on the service you give it.

Lubricate the drive line in three areas:

- The telescoping drive shafts
- The bearings
- The universal joints

The lubrication intervals will vary with the field or job conditions. Consult the machine operator's manual.

SAFETY RULES FOR PTO'S

Safety is a prime factor in equipment design.

Here are safety rules for working on machines equipped with PTO's.

1. Keep PTO guards and shields in place even when the PTO is not operating.
2. Always disconnect the PTO when not in use.
3. Never engage the PTO while the machine engine is shut off.
4. Keep hands, feet, and clothing away from PTO parts.
5. Be sure your clothing is relatively tight and belted. Loose clothing can become caught in moving PTO parts.
6. Never operate PTO shafts at extreme angles.
7. Never ride, or permit others to ride, on the drawbar of the tractor.
8. Never hook 540 rpm equipment to a 1000 rpm PTO or vice-versa.
9. Be sure PTO spinner shields rotate freely at all times. Disengage all power and shut off tractor engine before checking spinner shields.
10. Always be sure PTO drive shaft is properly secured to the machine's PTO shaft.
11. Do not service, lubricate, or perform other work on a machine without first disengaging the machine PTO and shutting off the engine.




Fig. 12—Failures Of U-Joint Journals

TROUBLE SHOOTING OF PTO'S

Problem	Possible Cause
1. Machine vibrates excessively while operating	PTO shaft is not properly aligned
2. Twisted PTO shaft	Overload on PTO shaft Improper hitch setting
3. PTO shafts not telescoping properly	Worn bearings Spinner shields or shaft rusted from poor lubrication
4. Brinelling of U-joint journal (Fig. 12)	Excessive metal fatigue Poor heat treatment
5. Galling of U-joint journal cross ends (Fig. 12)	Drive shaft rpm too high
6. Journal cross end and cups chipping	U-joint capacity too low for required hours and angle
7. Abrasive corrosion on PTO shaft	Extreme low angle operation

TEST YOURSELF QUESTIONS

1. Match the three items at left below with the correct definition at right.

- | | |
|----------------------------|---|
| a. Independent PTO | 1. Operates only when main engine clutch is engaged, stops when disengaged. |
| b. Continuous-running PTO | 2. Completely separate from main engine clutch. |
| c. Transmission-driven PTO | 3. Can be operated even though main power train is disengaged. |

2. How can you tell two PTO stub shafts—540 and 1000 rpm—apart?

3. True or false? "Never engage the PTO while the machine engine is shut off."

(Answers on page 10 in back of text.)

SPECIAL DRIVES / CHAPTER 10




Fig. 1—Three Kinds Of Drives

In this chapter, we will cover these special drives not included in other chapters of this manual:

- Belt Drives
- Chain Drives
- Gear Drives

Refer to Fundamentals of Service — Belts and Chains for more information on these subjects.

Fig. 1 shows these three drives in operation.

We will also look at reciprocating drives and at safety devices like slip clutches, jump clutches, and shear pins.

BELT DRIVES

Belt drives are *frictional* drives. They transmit power by contact between the belt and the driving

and driven pulley. Belts should have a firm but not a sticky grip on the pulleys. One pulley in any belt drive should be adjustable.

The ability of belts to transmit power depends on:

1. Tension holding the belt to the pulleys.
2. Friction between belt and pulleys.
3. Arc of contact (or "wrap") between belt and pulleys.
4. Speed of belt (higher speeds cut tension and contact).

Belts are normally used to transmit power between two parallel shafts but they can also be used in a variety of other ways (Fig. 3).




Fig. 2—Belt Drive

ADVANTAGES OF BELT DRIVES

1. Easy to design
2. Inexpensive
3. Absorb shock
4. Easy to install
5. Easy to service
6. Permit simple power cutoff

DISADVANTAGES OF BELT DRIVES

1. Do not last as long as some drives
2. Will not carry as heavy a load
3. Cannot be used where exact timing is required (unless a special tooth-type belt is used)

TYPES OF BELTS

Belts are of three basic types:

- Flat Belts
- V-Belts
- Round Belts

Belts may be constructed of leather, fabric, rubber, rayon, neoprene, hemp rope, thin flat steel, wire, and combinations of these materials.

Flat Belts

Flat belts are used most where the pulleys are far apart. Use of flat belts has decreased because most machines today have built-in drives. Their most common use is in drives where high power is needed for a separate machine. *Examples:* old-time threshers, sawmills.




Fig. 3—Forms Of Belt Drives




Fig. 4—Types Of Belts

Flat belts are also used where the belt itself performs the work, such as on conveyors and draper belts.

A movable idler may be used to provide clutch action. When clutching, flat belts release more completely than V-belts in grooved sheaves. Some flat belts are designed with a center bulge to help keep the belt on the pulley. This is because centrifugal force tends to throw the belt outward so that it climbs to the widest diameter of the pulley and stays there.

Perfect alignment of pulleys and belt is a must for good operation.

Tension should be no more than needed to transmit the load with the least slippage. However, tension is normally greater than for V-belts.

Flat belts are less expensive than V-belts and usually last longer because their shape reduces friction, which causes fatigue. However, flat belts need much more care and maintenance.

V-Belts

V-belts are the most common means of driving light loads between short-range pulleys. The pulleys (or sheaves) have high, steep flanges so that the belt cannot run off. The driving friction is entirely on the sides of the belt and is very effective because of the wedging action of the belt taper. V-belts are small in cross-section to reduce friction and heating. They have a greater load capacity at high speeds than do flat belts. V-belt tension is not nearly as great compared to flat belts, and V-belts can be operated with slack on top or bottom.




Fig. 5—V-Belt Drive Using Multiple Belts

Two or more belts are used when more power must be transmitted than one belt can withstand. These belts work in parallel grooves in the same pulley (Fig. 5). The belts must be the same size or the tighter one will carry too much of the load, resulting in strain, slippage, and rapid wear.


ROUND BELTS

Round belts are usually made of solid rubber or rubber with cords. These belts are normally made for relatively light loads, such as for sewing machines and movie projectors. However, larger round belts are sometimes used on farm equipment.

VARIABLE-SPEED BELT DRIVES

This drive allows you to change the speed ratios between the driving and driven pulleys. It is based on the principle that large pulleys turn slower than small pulleys when driven by the same belt.

So the variable speed is obtained by changing the diameter of the pulley or pulleys.



X2087

Fig. 6—Variable-Speed Belt Drive

The pulleys are made up of two halves. By moving the halves together, the driven pulley becomes "larger" since the belt now rides higher in the pulley slot (Fig. 6).

When the pulley halves are pulled apart, the driven pulley becomes "smaller" again and turns at a faster rate.

When the pulley sizes are changed, the belt tension also changes. So there must be a means of "taking up the slack". This may be done in any of these ways:

- 1) Moving the pulleys closer together or farther apart.
- 2) Using an idler on the belt which responds to tension or slackening.
- 3) Using two pulleys of variable-pitch. The pulleys are synchronized so that when one changes its size, the other changes to offset it.

Variable speed drives can be controlled manually or automatically.

MAINTENANCE OF BELT DRIVES

Most maintenance will be for V-belt drives, since this is the most common belt drive today.

Care Of Belts

1. Store belts in a cool, dry place. Coil long belts in natural loops when storing them on pegs.




Fig. 7—Never Force A Belt Onto A Pulley

2. Relieve tension on belt drives when not in operation.

3. Never force a belt onto a pulley (Fig. 7). Forcing will result in injured cords and premature belt failure.

4. Most drives permit easy belt installation through movable pulleys or idlers; if not, remove pulley for proper installation.

SIGNS OF IMPROPER BELT INSTALLATION

- Belt stretched beyond take-up
- Belt fails rapidly for no visible reason
- Belt turns over
- Belt cut on bottom

Belt **slip** is the slight loss of speed between the drive and driven pulleys of any belt drive.

Belt **creep** is the slight stretching of the belt itself as it runs over the pulleys (Fig. 8).

Creeping occurs as follows:

When the belt is under load, there is a tight and a slack side to the belt. The tight side stretches, while the slack side contracts.




Fig. 8—Belt Creeping (Drive Pulley Shown)

At the *drive* pulley (shown), the section of belt passing onto the pulley is longer than that passing off, while at the *driven* pulley the section of belt passing onto the pulley is shorter.

This change takes place in the belt while it is on the pulley, and is known as *creep*. It should not be confused with *slip*, which is movement of the belt in relation to the pulley.

BELT ALIGNMENT

Pulley misalignment with flat and round belt drives will cause the belt to run off the pulleys.

Improper pulley alignment with V-belt drives is not quite as evident (Fig. 9), but can cause uneven belt wear, belt rollover, cord stretch, or breakage due to the load being carried on one side of belt.

Checking alignment of pulleys is shown in Fig. 10. Place the straightedge or cord to touch pulleys at arrows. The shafts must be parallel. Then rotate each pulley and note whether the contact of either pulley with the straightedge is disturbed. If so, a shaft is bent or a pulley is wobbling.




Fig. 9—Pulleys Not Aligned Can Damage The V-Belt

BELT TENSION

Tension of flat belts must be greater than that of V-belts but not tighter than necessary to avoid slippage.

Too little tension will cause slippage or slip-and-grab, causing the belt to break. If the belt does not break, slip will cause excessive cover wear, burned spots, and overheating.

Too much tension will cause belt heating and excessive stretch as well as damage to drive components such as pulleys and shafts. The extra tightness will also place a heavier load on the bearings.

Normally, belts should not be re-tensioned until slippage occurs or the drive works improperly from lack of tension.

Remember that V-belts should ride on the sides of the pulleys, not on the bottom of the groove.



Fig. 10—Checking Alignment Of Belt Pulleys




Fig. 11—Checking Belt Tension

Proper belt tension means springiness when hit by the hand but not to the extent of a rubber band vibration (Fig. 11). Normally the belt should not deflect more than one thickness when pushed by hand.

Tension on a new belt should be rechecked after the first hour and watched during the first 24 hours of operation. This is when the initial seating and stretch occurs.

For exact tension on belts, refer to the machine operator's manual.

BELT PROBLEMS WITH OIL AND GREASE

There are certain dressings that may be applied to flat belts, usually leather, to increase belt efficiency.

But generally, **all belts should be kept free of oil, grease, and fuel.** Oil and grease cause belts to become soft and to slip. Belts are designed to withstand some exposure to oil or grease, but if detected, the belt should be cleaned with a cloth soaked in solvent.

HEATING PROBLEMS WITH BELTS

Belts operating in temperatures of less than 120°F (49°C) are not usually affected by heat. But at hotter temperatures, the belt may harden, causing it to crack and stretch. Be sure to ventilate the belt properly by keeping shields and screens clean. Also be sure that belt isn't slipping, which causes heat.

MATCHING OF BELTS

If one belt in a set breaks, **replace all belts in that set.** The older belts have worn sides, and initial stretch is gone, causing the entire load to be carried by the new belt.

Never use belts manufactured by different companies in the same set. Length and stretch tolerances are different for each company.

Worn pulleys or misaligned shafts can give the appearance of mismatched belts and should be checked before installing a new set of belts.

FAILURES OF BELTS

For details on failures of belts, see the Fundamentals of Service — Belts and Chains or FOS — Identification of Parts Failures.

CARE OF PULLEYS AND SHEAVES

Wear In Sheave Grooves





Fig. 12—Proper Position Of V-Belt in Standard Sheave

Generally, when a new belt seats more than 1/16 inch (1.6 mm) below the top of the sheave groove, the sheave is worn out. Fig. 12 shows the normal position of a V-belt in a good pulley sheave, while under load and while at rest.



X2094

Fig. 13—Sheave Grooves "Dished Out" By Wear

When a sheave groove is worn as much as 1/32 inch (0.8 mm), the sheave should be repaired, regrooved, or replaced. Fig. 13 shows a pulley with the sheaves "dished out" by wear.

Sheave grooves wear rapidly when exposed to abrasive dust, and they should be cleaned frequently.


Sheave groove wear may result from corrosion, or moisture and chemicals in the air, especially if the drives are idle for long periods.

Shiny Sheave Groove Bottoms

A shiny sheave groove bottom is a sign that the belt or sheave, or both, are badly worn and the belt is bottoming in the groove. Look at the smaller sheave first, since this is where the wear usually appears first.

Possible causes may be a worn sheave or the wrong belt.

Wobbling Sheaves



X2095

Fig. 14—Wobbling Sheave

A wobbling sheave means short belt life, but it can be readily spotted (Fig. 14).

Sheave wobble may be caused by:

1. Bent shaft or sheave.
2. Improper sheave installation on shaft.
3. Worn or damaged shaft bearings.

Damaged Sheaves

Cast-iron sheaves may become chipped, or pressed steel sheaves may bend (Fig. 15). Both cause short belt life.


Replace damaged sheaves at once.

TROUBLE SHOOTING OF BELT DRIVES

Following is a summary of trouble signs and possible causes of belt drive failures.

CHIPPED

BENT



X2096

Fig. 15—Damaged Sheaves

Trouble	Possible Cause
Belts turn over in sheaves	1. Misalignment of sheaves and shafts. 2. Worn sheave grooves. 3. Misalignment of flat idler sheave. 4. Excessive belt vibration due to improper tension. 5. Belt cord damage from wrong installation.
Belt squeaks or screeches	1. Too-high starting load, causing belt to slip because of improper tension. 2. Overload, causing belt to slip because of improper tension.
Belt chirps	1. Movement of belt on flat idler or pulley (not harmful).
Belt stretched beyond take-up	1. Drive operated under too much tension. 2. Wrong belt or poor storage in damp area.
Belt breaks prematurely	1. Foreign material in sheaves. 2. Shock or extreme overload. 3. Belt damaged during installation.
Belt has short life	1. Worn sheaves. 2. Oil or grease on belt.

3. High temperatures.
4. Belt cover wear, caused by guard or guide interference.
5. Excessive belt slippage.
6. Poor storage of belts.

CHAIN DRIVES





Fig. 16—Chain Drive

Chain drives are similar to belt drives except that they are less flexible but more powerful. They also eliminate the slippage that belt drives may give.

PRINCIPLES OF CHAIN DRIVES

1. Chain drives are used to transmit power from one rotating shaft to another.
2. Chain drives consist of one or more sprockets and an endless chain.
3. The links of the chain mesh with the teeth of the sprockets and maintain a positive speed ratio between the driving and driven sprockets.
4. Sprockets connected to the same side of a chain revolve in the same direction. If connected on reverse sides, they revolve in opposite directions.
5. Sprockets for roller chain drives must not be smaller than ten teeth to avoid excessive wear.
6. If the chain has an even number of pitches (spaces between links), the sprockets have an odd number of teeth, and vice versa. This prevents a single pitch from contacting the same tooth each time, causing uneven wear and vibration.



X2098

Fig. 17—Parts Of A Chain Drive

7. A small sprocket causes sharper bending and more wear.
8. Short links bend less and should be used on smaller sprockets.
9. Chains may be installed in single or multiple strands, depending on the load.
10. Chains must be adjusted from time to time by moving one of the main sprockets or the idler sprocket.
11. Chain drives should have the slack side on the bottom if possible.
12. Idlers should be on the slack side of the chain.

ADVANTAGES OF CHAIN DRIVES

- Chain drives are efficient and do not slip.
- They are fairly flexible and compact.
- Chain drives are reasonably inexpensive.
- Chains keep a fixed speed ratio without slipping.
- They can withstand heat and dirt and are not affected by the weather if properly lubricated.
- Chain drives can carry heavier loads than belts.

DISADVANTAGES OF CHAIN DRIVES

1. Chain drives are fairly noisy.
2. Chains usually require frequent lubrication.
3. Most chains will accept very little misalignment.
4. Chains cannot normally be used where the drive must slip. (There are exceptions.)




Fig. 18—Three Types Of Chains

TYPES OF CHAINS

Chains are available in three types:

- Plain or Detachable Link Chain
- Roller Chain
- Silent Chain

Fig. 18 shows the three types of chains.

Plain or Detachable Link Chain

Plain chains are a series of formed links, either open or closed, which can be detached. Larger plain chains are of pintle construction. Plain chains are used in low-speed applications, such as conveyors or drags. Open plain chains are used for light loads, while the closed pintle chains are used for heavier loads.

Roller Chains

Roller chain is made up of alternate roller links and pin links with pins. The bushings are free to turn.

Roller chain is a good way to carry heavy loads at low speeds between shafts that are far apart.

Standard roller chain is made up of alternate roller links and pin links (Fig. 19). Roller links have two roller link plates, two bushings, and two rollers, while pin links have two pin link plates and two pins. Pins are usually in the form of rivets with cotter pins for connecting, although the complete chain may be joined by removable pins.

The side plate of the roller chain determines the pitch (or angle) of the chain. Double pitch or extended pitch roller chain has the same parts as the standard-pitch chain, but the side plates have twice the pitch. Double pitch chains are lighter in weight and less expensive.




Fig. 19—Roller Chain

Silent Chains

Silent chain is a series of flat metal links, with a tooth shape at each end, connected by pins to form a flexible, continuous chain (Fig. 20).

The sprockets are similar to gears in appearance and design. Silent chain is quieter and has less vibration than roller chain and can be run at a higher speed. Its links are small in proportion to its strength so it can be used on smaller sprockets. Some silent chains are made with links having teeth on both sides so that over-and-under serpentine drives can be used.




Fig. 20—Silent Chain

INSTALLING CHAINS




Fig. 21—Aligning Shafts On A Chain Drive Using A Machinist's Level

1. Align The Shafts—Level each shaft with machinist's level on shaft, or across teeth if multiple width sprockets are used. Check shafts to see if they are parallel using a feeler bar (Fig. 21). The distance between shafts on both sides should be equal. Then bolt the bearings securely.




Fig. 22—Aligning The Sprockets

2. Align The Sprockets—Check the axial alignment of the sprockets with a straight edge applied to finished surfaces on the sides of the sprocket (Fig. 22). When aligned, tighten the hub set screws.



Fig. 23—Installing The Chain

3. Install The Chain—Remove connector link and wrap the chain around sprockets, bringing the free ends together on one sprocket. Install connector link (Fig. 22), being sure to tap chain pin links back so that fasteners come up snugly against the outside of the connecting link plate.

This helps in three ways:

- a) *Designed clearances between link plates across the chain are maintained and oil can get down in between link plates.*
- b) *Joints will be able to flex freely for a smoother chain action.*
- c) *Chain fasteners will last longer.*

Offset links should be avoided if possible, but if necessary, use an offset link with press-fit pins.

TENSION ON CHAINS

Adjust the shaft centers for proper chain tension.

For horizontal and inclined drives, the chain sag should be about $\frac{1}{4}$ inch per foot between shaft centers (with one side of chain taut). Vertical drives and those subject to shock loading or reversal of rotation should be adjusted so that both spans of chain are almost taut. For drives on fixed centers, chain tension can be controlled with an adjustable chain tightener, either an idler sprocket or a shoe.




Fig. 24—Checking Tension On Chain

To determine the amount of sag, pull one side of the chain taut, allowing all the excess chain to accumulate in the opposite span.

Place a straight edge over the slack span and pull the chain down at the center (Fig. 24). Measure the amount of sag from the top of the chain to the underside of the straight edge.

If necessary, adjust the shaft centers to provide the recommended amount of sag for proper chain tension.

Stretched Chains

When the shaft or chain tensioner has reached maximum adjustment and the chain begins to ride on the tips of the sprocket teeth (Fig. 25) it may have reached the end of its useful life.

However, if the chain still fits properly when wrapped on the largest sprocket, remove one or two links and reset the shafts or tensioner in their original position. Then adjust to provide proper tension.

LUBRICATION OF CHAIN DRIVES

The importance of lubrication increases with higher chain speeds.

Lubrication will do three basic things for chain life:

- 1) *Reduce wear.*
- 2) *Protect against corrosion.*
- 3) *Prevent galling or seizing of pins and bushings.*

Types Of Lubrication

MANUAL LUBRICATION—Oil is applied with a brush or spout can, preferably once every eight

hours of operation and under all conditions. Do this while the chain is still warm. Apply oil again before oil discolors between joints.

DRIP LUBRICATION—Oil drops are directed between the link plate edges from a drip lubricator. Oiling should be sufficient to prevent discoloration of oil between joints.

BATH OR DISK LUBRICATION—With bath lubrication, the lower strand of chain runs through a sump of oil in the drive housing. The oil level should reach the pitch line of the chain at its lowest operating level. With disk lubrication, the chain operates above the oil level and a rotating disk picks up oil from the sump and deposits it onto the chain by means of a trough or collector plate.

OIL STREAM LUBRICATION—The lubricant is usually supplied by a pump that sprays oil onto the chain through nozzles. The stream should be directed to the lower, inside strand of chain. Excess will run off and return to pump. Oil should be changed periodically.

Properly lubricated chains will not show brownish color at the joints and the connecting link pins will be brightly polished.

REPAIRING CHAIN DRIVES

1. To separate a roller chain, drive out the two pins of the link with alternate strokes, taking care not to damage adjacent links. If the pins have a head, grind them off before trying to remove. A chain-breaking tool is a quick, efficient method of removing links.
2. Sprocket life may be prolonged by reversing the sprockets, if the design permits. Be careful to check alignment.
3. Never insert a new link in a chain that has been elongated by wear. The new link will have a shorter pitch, causing shock when engaging the sprocket. This will soon destroy the chain.
4. Do not install a new chain on badly worn sprockets (Fig. 25). More damage will occur to the chain in a few hours than under years of normal use.

CLEANING OF CHAINS

Periodic cleaning is good economy under even the best operating conditions. Steps for chain cleaning are:

1. Remove chain from sprockets.
2. Wash chain in diesel fuel.
3. Drain fuel and soak chain in oil.
4. Hang chain to drain off excess lubricant.

STORING OF CHAINS AND SPROCKETS

Remove chain from sprockets, clean them, and coat with heavy grease. Then wrap chain in heavy grease-resistant paper and store in a dry area.

Sprockets may be left on shaft and coated with heavy protective grease.

Before using the drive again, thoroughly clean grease from the chains and sprockets, and re-lubricate the chain.




Fig. 25—Problems With Chain Drives

TROUBLE SHOOTING OF CHAIN DRIVES

Trouble	Possible Cause
Excessive noise	1. Misalignment of sprockets
	2. Wrong tension
	3. Lack of lubrication
	4. Loose casings or bearings
	5. Chain or sprocket worn out
	6. Chain pitch too large

Wear on side bars, link plates, and sides of sprocket teeth

1. Misalignment

Chain climbing sprockets

1. Wrong chain or poor chain
2. Chain worn out
3. Lack of chain wrap on sprocket
4. Too much chain slack
5. Material build-up in sprocket tooth pockets
6. Worn sprockets

Broken pins, bushings, or rollers

1. Chain runs too fast
2. Heavy slack or sudden loads
3. Material build-up in sprocket tooth pockets
4. Lack of lubrication
5. Chain or sprocket corrosion
6. Wrong chain or worn sprockets

Chain clings to sprocket

1. Wrong chain or worn sprockets
2. Heavy or tacky lubricant
3. Excessive chain slack
4. Material build-up in sprocket tooth pockets

Chain whips

1. Too much slack in chain
2. High, pulsating loads
3. Stiff chain joints
4. Uneven wear on chain

Chain gets stiff

1. Lack of lubrication, resulting in wear
2. Corrosion
3. Excessive overloads
4. Material build-up in chain joint
5. Peening of side plate edges
6. Misalignment

Broken sprocket teeth

1. Obstruction or foreign material
2. Excessive shock loads
3. Chain climbing sprocket teeth

Chain fasteners fail

1. Vibration
2. Obstructions striking fasteners
3. Fasteners improperly installed

Drive runs too hot

1. Chain running too fast
2. Lack of lubrication
3. Chain immersed too deep in oil bath
4. Chain or shafts rubbing against obstruction

GEAR DRIVES

Gears are the most common way to transmit power for heavier loads. With gears in mesh, all slippage is gone. Even the linkage of the chain is eliminated, giving more power potential.

OPERATION

Chapter 1 of this manual covers the basic gear types and their uses. Refer to that chapter for the basics of gear drive operation.

MAINTENANCE

The problems of *gear wear* and *backlash* are also explained in Chapter 1.

LUBRICATION

Gear lubricants range from simple mineral oils to complex formulas containing many ingredients.

For the type of oil to use, consult the manufacturer's operator's manual.




Fig. 26—Gear Drive

Common gear lubricants are:

SPUR GEARS—may use a good grade of petroleum oil—but not always.

BEVEL GEARS—may use an extreme-pressure (E.P.) lubricant.

WORM GEARS—may use an SCL lubricant, which offers even greater lubricant qualities.

Methods Of Lubricating Gears

Enclosed gearing is usually lubricated by the gears moving through a sump of oil and may have additional run-off troughs to lubricate the upper gears. The lubricant should be changed per the manufacturer's recommendations.

Open gears can be lubricated by:

- 1) Splash pan which the gears run through.
- 2) Hand lubrication by brushing or squirting (Fig. 27).
- 3) Automatic lubrication by a drip oiler.




Fig. 27—Lubricating Of Open Gears—Three Ways

TROUBLE SHOOTING OF GEAR DRIVES

<i>Trouble</i>	<i>Possible Cause</i>
Fins around edge of teeth	1. Too much backlash 2. Heavy, continuous loading 3. Intermittent overloading 4. Gears not hardened
Gear teeth appear burned from overheating	1. Too little backlash 2. Overspeeding 3. Overloading 4. Lack of lubrication
Gear teeth are scored	1. Lack of proper lubrication 2. Excessive speeds 3. Overloading 4. Too little backlash
Abrasions or fine tooth scratches	1. Dirt, grit, or metal particles in gears

Interference marks on tooth edges

1. Improper manufacturing
2. Faulty assembly

Pitting of gear teeth

1. Excessive loading

Gouging near bottom of teeth

1. Too little backlash

Teeth broken

1. Too much backlash
2. Shock impact or overload

RECIPROCATING DRIVES

Reciprocating drives change a *rotary* motion to a *linear* motion. The source of rotary motion could be the drives already discussed (belt, chain, gear) or the hydraulic or electrical devices.

A reciprocating mechanism is not actually a drive but is a supplement or helper for the drive.


Two uses of reciprocating drives: mowing cutter bars and plungerheads on hay balers.

Reciprocating drives are of four basic types:

- Crankwheel and lever
- Crankarm and lever
- Off-center crankarm
- Cam

Let's look at each one.

CRANKWHEEL AND LEVER DRIVE




X2109

Fig. 28—Crankwheel and Pitman Lever Driving Mower Blade

The crankwheel and lever principle works from rotary motion (the crankwheel) with the lever or pitman attached off-center (Fig. 28). As the crankwheel turns, the pitman moves forward and back. One revolution of the crankwheel gives two strokes on the pitman. The mowing cutter bar uses this principle as shown.

Variations On Crankwheel And Lever Principle


A crankwheel and lever, with a sway bar drive, helps eliminate the up-and-down motion of the drive and reduces slapping and vibration (Fig. 29). As the pitman moves to the left (A), the knife is driven to the right. As the pitman moves to the right (B), the knife is driven to the left.



X2111

Fig. 30—Twin Wheel Drive Operating Mowing Cutter Bar

The *twin wheel drive* helps reduce vibration by having two crankwheels and short pitmans which operate in opposition to each other (Fig. 30).



X2110





Fig. 29—Crankwheel And Lever With Swaybar Drive

CRANKARM AND LEVER DRIVE


X2112

Fig. 31—Crankarm And Lever Drive For Hay Baler Plungerhead
A crankarm and lever drive is similar to a crank-wheel and lever drive, except the crankarm takes the place of the crankwheel (Fig. 31).

Most reciprocating drives are counterbalanced to offset the inertia of the sudden changes in direction. This may be a counterweight, a dual drive, or a flywheel. The direction of the counterbalance is always the opposite of the pitman or lever.

OFF-CENTER CRANKARM DRIVE

The off-center crankarm drive is often called the *wobble shaft* or bent shaft drive (Fig. 32). As the shaft turns, the vertical motion is absorbed by a hinged yoke, while the horizontal motion is used for the back-and-forth motion.



X2113

Fig. 32—Off-Center Crankarm Drive (Wobble Shaft)
For Mower Cutterbar

A counterbalance is often used; however, the device can be used without a counterbalance if the weight of the machine is much greater than the force that must be driven. For example: It can be used as a sickle drive on a hay windrower because the sickle weight is very small in relation to the platform weight. But a counterweight must be used on a basic field mower because its weight is mainly in the cutter bar and drive.

CAM DRIVES

Cam drives are often used in a direct reciprocating motion (Fig. 33). Their action may also involve complicated or delayed motions. However, they always return to a starting point or reciprocate. Cam drives may use a spring load, gravity, or a track to return them to their starting positions as shown in Fig. 33.




Fig. 33—Cam Drives

MAINTENANCE OF RECIPROCATING DRIVES

Lubrication is the key to good operation of all mechanical drives. Any moving part or parts making contact with another part should be well lubricated.

- 1) Bearings should be kept lubricated and checked for wear or damage periodically.
- 2) Cam tracks or cam surfaces require greasing for smooth operation and minimum wear.
- 3) Hinged areas need lubrication.
- 4) Enclosed drives should have oil level checked periodically.
- 5) Above all, refer to the machine operator's manual for proper lubrication.

TROUBLE SHOOTING OF RECIPROCATING DRIVES

Trouble usually starts in some place other than the reciprocating drive itself. Safety devices are usually built into the drive in some way to protect it. For this reason, belts are often used to drive reciprocating devices because the belt will slip and protect the drive in case of an obstruction. For the same reason, a wooden pitman stick which will break is often used on a mower.

Dirt contamination can be the cause of faulty operation of cams and crank drives and can lead to excessive wear. For this reason:

- Clean drives periodically
- Keep shields in place

Drive *alignment* is a must for proper reciprocation. Coordination is also needed between the power source, reciprocating drive, and work element.

This may mean:

- 1) Adjusting pitman length or length of stroke.
- 2) Adjusting cam track or follower.
- 3) Aligning lever and work element.

OVERLOAD RELEASE MECHANISMS FOR POWER TRAINS

In many modern machines one power source supplies many work functions. Each function has a different power requirement for its own work load.

Although it might take only 15 percent of total power to perform a certain function on a machine,

more power is available, so a torque limiting factor or overload release mechanism is placed in the powerline to prevent damage in case an obstruction enters the machine.

Overload release mechanisms perform two functions:

- 1) *Relieve shock on the power source.*
- 2) *Protect the machine part doing the work.*

Overload mechanisms are of three major types:

- Slip Clutches
- Jump Clutches
- Shear Pins

Let's look at each one.

SLIP CLUTCHES




Fig. 34—Slip Clutch

Slip clutches work by friction (Fig. 34). The drive line is separated at the slip clutch, but linked together by means of clutch facings and spring tension.

During an obstruction, the friction force is overcome and the clutch slips, preventing damage to the machine and power line.

Tension can be either adjustable or non-adjustable and is supplied by springs or spring washers.

JUMP CLUTCHES




Fig. 35—Jump Clutch

The jump clutch (Fig. 35) does the same job as the slip clutch, although it is not as widely used. The power line connection is joined by a two-piece ratchet. One piece supplies the power, while the other receives and transmits power to the power line. The ratchet is held together by spring tension, which is adjustable.

In case of overload, the spring tension is overcome and the ratchet slips, disengaging the power train to protect it.

SHEAR PINS

Shear pins (Fig. 36) work on the stress principle. A pin or bolt will break if too much force is exerted on it. Size and hardness of pin varies according to the stress needs of the power train.

Again, the power train is actually two pieces, with a shear pin connecting them. In case of overload, the pin shears and disconnects the powerline.

Shear pins are simple and relatively inexpensive, and so are widely used. The major disadvantage




Fig. 36—Shear Pin In Power Driveline

is that each time a pin is sheared the operation is stopped and the pin must be replaced.

MAINTENANCE OF OVERLOAD MECHANISMS

Lubrication

Lubrication is generally simple in an overload mechanism. Remember these points:

- 1) A light coating of oil can be used to keep clutch faces from sticking.
- 2) Too much oil on clutch faces reduces friction and causes slipping.
- 3) Spring tension for safety mechanisms may require light lubrication.
- 4) Shafts that are actually separated, but run inside a connecting shaft, should be lubricated to inhibit rust and corrosion that may prevent disengagement of the powerline.

General Maintenance

Specifications for overload *release* mechanism adjustment and setting should be closely followed and can be found in the machine operator's manual.

Many slip clutches and jump clutches are adjusted.

Be sure to replace shear pins with the exact duplicates. Refer to the machine parts catalog. Many times a shear pin is in the form of a bolt, and the bolt strength and size should be closely checked before installation.

TROUBLE SHOOTING OF OVERLOAD MECHANISMS

<i>Trouble</i>	<i>Possible Cause</i>	
Slip clutch continually slips	1. Too little spring tension, Belleville washer worn out 2. Oiled or glazed clutch facings 3. Improper assembly 4. Failure of the working element	Shear pin continually shears 5. Internal shaft frozen to external shaft
Slip clutch will not slip	1. Facings have become stuck 2. Too much spring tension 3. Improper assembly	Shear pin will not shear 1. Wrong shear pin or bolt 2. Working element not functioning 3. Drive overloaded
Jump clutch continually jumps	1. Too little spring tension 2. Ratchet worn out 3. Ratchet surface is slick from lubricant 4. Dirt build-up not permitting complete contact between ratchet teeth 5. Working element not functioning 6. Drive overloaded	
Jump clutch will not jump	1. Too much spring tension 2. Spring bottomed out 3. Ratchet frozen due to rust or corrosion 4. Dirt preventing operation of spring release or ratchet	

TEST YOURSELF QUESTIONS

1. What are the three major kinds of special drives?
2. Which one is a friction drive?
3. How do the pulleys change belt speed in a variable speed drive?
4. True or false? "If one belt breaks in a multiple set, you need not replace all the belts."
5. Should the idler be on the tight or slack side of the chain?
6. Reciprocating drives change a _____ motion into a _____ motion.

(Answers on page 10 in back of text.)

DEFINITIONS OF TERMS AND SYMBOLS

A

ABRASION—Wearing or rubbing away of a part.

ALIGNMENT—An adjustment to a line or to bring into a line.

ANTI-CLOCKWISE ROTATION—Rotating the opposite direction of the hands on a clock. The same as counter-clockwise rotation.

ANTI-FRICTION BEARING—A bearing constructed with balls, rollers or the like between the journal and the bearing surface to provide rolling instead of sliding friction.

ASAE—American Society of Agricultural Engineers.

ASME—American Society of Mechanical Engineers.

AXIAL—Parallel to the shaft or bearing bore.

AXLE—The shaft or shafts of a machine upon which the wheels are mounted.

AUTOMATIC TRANSMISSION—A transmission in which gear or ratio changes are self-activated.

B

BACKLASH—The clearance or "play" between two parts, such as meshed gears.

BALL BEARING—An anti-friction bearing consisting of a hardened inner and outer race with hardened steel balls which roll between the two races.

BDC—Bottom dead center.

BEARING—The supporting part which reduces friction between a stationary and rotating part.

BEVEL SPUR GEAR—Gear that has teeth with a straight center-line cut on a cone.

BONDED LINING—A method of cementing brake linings to shoes or bands which eliminates the necessity of rivets.

BRAZE—To join two pieces of metal with the use of a comparatively high melting point material. An example is to join two pieces of steel by using brass or bronze as a solder.

BREAK-IN—The process of wearing-in to a desirable fit between the surfaces of two new or re-conditioned parts.

BROACH—To finish the surface of metal by pushing or pulling a multiple-edge cutting tool over or through it.

BURNISH—To smooth or polish by the use of a sliding tool under pressure.

BUSHING—A removable liner for a bearing.

C

CARRIER—An object that bears, cradles, moves, or transports some other object or objects.

CASE-HARDEN—To harden the surface of steel.

CASTELLATE—Formed to resemble a castle battlement, as in a castellated nut.

CENTER OF GRAVITY—The point at which a mass of matter balances. For example, the center of gravity of a wheel is the center of the wheel hub.

CENTRIFUGAL FORCE—A force which tends to move a body away from its center of rotation. Example: whirling a weight attached to a string.

CHAMFER—A bevel or taper at the edge of a hole or a gear tooth.

CHASE—To straighten up or repair damaged threads.

CHILLED IRON—Cast iron on which the surface has been hardened.

CLEARANCE—The space allowed between two parts, such as between a journal and a bearing.

CLUTCH—A device for connecting and disconnecting the engine from the transmission or for a similar purpose in other units.

COEFFICIENT OF FRICTION—The ratio of the force resisting motion between two surfaces in contact to the force holding the two surfaces in contact.

COMPOUND—A mixture of two or more ingredients.

CONCENTRIC—Two or more circles, having a common center.

CONSTANT MESH TRANSMISSION—A transmission in which the gears are engaged at all times, and shifts are made by sliding collars, clutches or other means to connect the gears to the output shaft.

CONTRACTION—A reduction in mass or dimension; the opposite of expansion.

CORRODE—To eat away gradually as if by gnawing, especially by chemical action, such as rust.

COUNTERBORE—To enlarge a hole to a given depth.

COUNTER-CLOCKWISE ROTATION—Rotating the opposite direction of the hands on a clock.

COUNTERSHAFT—An intermediate shaft which receives motion from a main shaft and transmits it to a working part. Sometimes called a lay shaft.

COUNTERSINK—To cut or form a depression to allow the head of a screw to go below the surface.

COUPLING—A connecting means for transferring movement from one part to another; may be mechanical, hydraulic or electrical.

D

DEAD AXLE—An axle that only supports the machine and does not transmit power.

DEFLECTION—Bending or movement away from normal due to loading.

DENSITY—Compactness; relative mass of matter in a given volume.

DIAGNOSIS—A systematic study of a machine or machine parts to determine the cause of improper performance or failure.

DIAL INDICATOR—A type of measuring instrument where the readings are indicated on a dial rather than on a thimble as on a micrometer.

DIFFERENTIAL GEAR—The gear system which permits one drive wheel to turn faster than the other.

DIRECT DRIVE—Direct engagement between the engine and driveshaft where the engine crankshaft and the driveshaft turn at the same rpm.

DISTORTION—A warpage or change in form from the original shape.

DOUBLE REDUCTION AXLE—A drive axle construction in which two sets of reduction gears are used for extreme reduction of the gear ratio.

DOWEL PIN—A pin inserted in matching holes in two parts to maintain those parts in fixed relation one to another.

DRIVE LINE—The universal joints, drive shaft and other parts connecting the transmission with the driving axles.

DROP FORGING—A piece of steel shaped between dies while hot.

DUAL REDUCTION AXLE—A drive axle construction with two sets of pinions and gears, either of which can be used.

E

ECCENTRIC—One circle within another circle wherein both circles do not have the same center. An example of this is a cam on a camshaft.

ENDPLAY—The amount of axial or end-to-end movement in a shaft due to clearance in the bearings.

F

FEELER GAUGE—A metal strip or blade finished accurately with regard to thickness used for measuring the clearance between two parts; such gauges ordinarily come in a set of different blades graduated in thickness by increments of 0.001 inch.

FILLET—A rounded filling between two parts joined at an angle.

FIT—The contact between two machined surfaces.

FLANGE—A projecting rim or collar on an object for keeping it in place.

FLUID DRIVE—A drive in which there is no mechanical connection between the input and output shafts, and power is transmitted by moving oil. (See Chapter 6 on Torque Converters.)

FOOT POUND (or lbs. ft.)—This is a measure of the amount of energy or work required to lift 1 pound a distance of 1 foot.

FREE-WHEELING CLUTCH—A mechanical device which will engage the driving member to impart motion to a driven member in one direction but not the other. Also known as an "overrunning clutch."

G

GEAR—A cylinder- or cone-shaped part having teeth on one surface which mate with and engage the teeth of another part which is not concentric with it.

GEAR RATIO—The ratio of the number of teeth on the larger gear to the number of teeth on the smaller gear.

GRIND—To finish or polish a surface by means of an abrasive wheel.

H

HEAT TREATMENT—Heating, followed by fast cooling, to provide a required hardness or metal structure.

HEEL—The outside or larger half of the gear tooth.

HELICAL—Shapes like a coil spring or a screw thread.

HELICAL GEAR—Gears with the teeth cut at an angle to the axis of the gear.

HERRINGBONE GEAR—A pair of helical gears designed to operate together in which the angle of the pair of gears forms a V.

HUB—The central part of a wheel or gear.

HYDRAULIC PRESSURE—Pressure exerted through the medium of a liquid.

HYPOID GEAR—A gear that is similar in appearance to spiral bevel gear, but the teeth are cut so that the gears match in a position where the shaft centerlines do not meet.

I

ID—Inside Diameter.

IMPELLER—The pump or driving member in a torque converter.

INPUT SHAFT—The shaft carrying the driving gear by which the power is applied, as to the transmission.

INTEGRAL—The whole made up of parts.

J

JOURNAL—A bearing within which a shaft operates.

K

KEY—A small block inserted between the shaft and hub to prevent circumferential movement.

KEYWAY—A groove or slot cut to permit the insertion of a key.

KNURL—To indent or roughen a finished surface.

L

LAPPING—The process of fitting one surface to another by rubbing them together with an abrasive material between the two surfaces.

LINKAGE—Any series of rods, yokes, and levers, etc., used to transmit motion from one unit to another.

LIVE AXLE—The shaft through which the power travels from the drive axle gears to the driving wheels.

LOST MOTION—Motion between a driving part and a driven part which does not cause actuation of the driven part. Also see Backlash.

LOW SPEED—The gearing which produces the highest torque and lowest speed of the wheels at a given engine speed.

M

MISALIGNMENT—When bearings are not on the same centerline within good functional or working limits.

MULTIPLE DISK—A clutch having a number of driving and driven disks as compared to a single plate clutch.

N

NEEDLE BEARING—An anti-friction bearing using a great number of long, small-diameter rollers; also known as a quill-type bearing.

O

OD—Outside diameter.

OSCILLATE—To swing back and forth like a pendulum.

OUTPUT SHAFT—The shaft or gear which delivers the power from a device, such as a transmission.

OVERDRIVE—Any arrangement of gearing which produces more revolutions of the driven shaft than of the driving shaft.

OVERRUN COUPLING—A free-wheeling device to permit rotation in one direction but not in the other.

P

PEEN—To stretch or clinch over by pounding with the rounded end of a hammer.

PINION—The smaller of two meshing gears.

PINION CARRIER—The mounting or bracket which retains the bearings supporting a pinion shaft.

PLANETARY GEAR SET—A system of gearing which is modeled after the solar system. A pinion is surrounded by an internal ring gear and planet gears are in mesh between the ring gear and pinion around which all revolves.

PLANET CARRIER—In a planetary gear system, the carrier or bracket in a planetary system which contains the shafts upon which the pinions or planet gears turn.

PLANET GEARS—The gears in a planetary gear set which connect the sun gear to the ring gear.

POWER SHIFT TRANSMISSION—A transmission in which gear changes are selected manually but are power actuated; no master clutch is involved.

PRELOAD—A load within the bearing, either purposely built in, or resulting from adjustment.

PRESS FIT—Mounting with interference, i.e., bore of bearing is smaller than OD of shaft, or OD of bearing is larger than bore of housing, or both.

PUMP—A device which produces motion in a liquid. In a torque converter, the driving member (also see "Impeller").

R

RACE—A channel in the inner or outer ring of an anti-friction bearing in which the balls or rollers roll.

RADIAL—Perpendicular to the shaft or bearing bore.

RADIAL CLEARANCE (Radial displacement) — Clearance within the bearing and between balls and races perpendicular to the shaft.

RADIAL LOAD—A force perpendicular to the axis of rotation.

RATIO—The relation or proportion that one number bears to another.

FOS—40 (Jun—69) Litho in U.S.A.

REACTOR—See "Stator".

REAM—To finish a hole accurately with a rotating fluted tool.

RECIPROCATING—A back-and-forth movement, such as the action of a piston in a cylinder.

RING GEAR—A gear which surrounds or rings the sun and planet gears in a planetary system. Also the name given to the spiral bevel gear in a differential.

RIVET—A headed pin used for uniting two or more pieces by passing the shank through a hole in each piece, and securing it by forming a head on the opposite end.

ROLLER BEARING—An inner and outer race upon which hardened steel rollers operate.

RPM—Revolutions per minute.

S

SAE—Society of Automotive Engineers.

SCORE—A scratch, ridge or groove marring a finished surface.

SEAT—A surface, usually machined, upon which another part rests or seats; for example, the surface upon which a valve face rests.

SEPARATORS—A component in an anti-friction bearing which keeps the rolling components apart.

SHIM—Thin sheets used as spacers between two parts, such as the two halves of a journal bearing.

SHRINK-FIT—Where the shaft or part is slightly larger than the hole in which it is to be inserted. The outer part is heated above its normal operating temperature or the inner part chilled below its normal operating temperature or both and assembled in this condition; upon cooling an exceptionally tight fit is obtained.

SLIDING-FIT—Where sufficient clearance has been allowed between the shaft and journal to allow free-running without overheating.

SLIDING GEAR TRANSMISSION—A transmission in which gears are moved on their shafts to change gear ratios.

SLIP-IN BEARING—A liner made to extremely accurate measurements which can be used for replacement purposes without additional fitting.

SPIRAL BEVEL GEAR—A ring gear and pinion wherein the mating teeth are curved and placed at an angle with the pinion shaft.

SPIRAL GEAR—A gear with teeth cut according to a mathematical curve on a cone. Spiral bevel gears that are not parallel have center lines that intersect.

SPLINE—Splines are multiple keys in the general form of internal and external gear teeth, used to prevent relative rotation of cylindrically-fitted parts.

SPUR GEAR—Gears cut on a cylinder and the teeth are straight and parallel to the axis.

SQ. FT.—Square feet.

SQ. IN.—Square inch.

STALL CONDITION—A condition in a torque converter when the driving element (pump) is turning and the driven element (turbine) is stopped. Stall produces maximum vortex flow (see Chapter 6 on Torque Converters).

STATOR—In a torque converter, the third member (in addition to turbine and pump) which changes direction fluid under certain operating conditions.

STRESS—The force to which a material, mechanism, or component is subjected.

SUN GEAR—The central gear in a planetary gear system around which the rest of the gears rotate.

SYNCHROMESH TRANSMISSION—Transmission gearing which aids the meshing of two gears or shift collars by matching their speed before engaging them.

SYNCHRONIZE—To cause two events to occur at the same time. For example, to bring two gears to the same speed before they are meshed.

T

TAP—To cut threads in a hole with a tapered, fluted, threaded tool.

TEMPER—To change the physical characteristics of a metal by applying heat.

TENSION—Effort which elongates or "stretches" a material.

THRUST LOAD—A load which pushes or reacts through the bearing in a direction parallel to the shaft.

TOLERANCE—A permissible variation between the two extremes of a specification or dimension.

TORQUE—A twisting motion, usually measured in ft-lbs.

TORQUE CONVERTER—A turbine device utilizing a rotary pump, one or more reactors (stators) and a driven circular turbine or vane whereby power is transmitted from a driving to a driven member by hydraulic action. It provides varying drive ratios; with a speed reduction, it increases torque.

TORQUE WRENCH—A special wrench with a built-in indicator to measure the applied force.

TORUS SECTION—The confines of a flow circuit in a radial plane in a torque converter or fluid coupler.

TRANSAXLE—Type of construction in which the transmission and differential are combined in one unit.

TRANSMISSION—An assembly of gears, or other elements which gives variations in speed or direction between the input and output shafts.

TROUBLE SHOOTING—A process of diagnosing the source of the trouble or troubles through observation and testing.

TUNE-UP—A process of accurate and careful adjustments to obtain the best performance.

TURBINE—A rotary device for obtaining mechanical power from a pressurized flow of gases or liquids.

TURBULENCE—A disturbed or irregular motion of fluids or gases.

V

VANES—Any plate, blade or the like attached to an axis and moved by air or a liquid.

VORTEX—A whirling movement or mass of liquid or air.

W

WORM GEAR—A gear with teeth that resemble a thread on a bolt. It is meshed with a gear that has teeth similar to a helical tooth except that it is dishd to allow more contact.

INDEX

A		Page				Page	
Axles, general	1-5, 8-2			Clutches, band-type	2-7		
Axles, hydrostatic drive	5-5			Clutches, cone-type	2-9		
B				Clutches, disk-type	2-2		
Backlash, gear	1-14, 1-20			Clutches, expanding shoe	2-10		
Band-type clutches	2-7			Clutches, hydraulic	2-10		
Bearing loads	1-18			Clutches, jump	10-18		
Bearings	1-17			Clutches, magnetic	2-9		
Bearings, ball	1-18			Clutches, overrunning	2-7		
Bearings, needle	1-19			Clutches, plate-type	2-3		
Bearings, roller	1-19			Clutches, pneumatic	2-10		
Belt alignment	10-5			Clutches, slip	2-11, 10-17		
Belt drives	10-1			Clutches, trouble shooting of	2-17		
Belt drives, maintenance of	10-4			Collar shift transmissions	3-3		
Belt drives, trouble shooting of	10-7			Cone-type clutches	2-9		
Belt drives, variable-speed	10-3			Controls, hydraulic	6-7		
Belt friction	1-7			Controls, shift	3-10		
Belt tension	10-5			Countershaft transmissions	4-2		
Belts, V-	10-3			Crankarm and lever drives	10-16		
Bevel gears, plain	1-10			Crankwheel and lever drives	10-15		
Bevel gears, spiral	1-10			D			
C				Dampeners, clutch	2-15		
Cam drives	10-16			Differentials	1-4, 7-1		
Chain drives	10-8			Differential, trouble shooting of	7-5		
Chain drives, lubrication of	10-11			Disk clutch, dry-type	2-2		
Chain drives, trouble shooting of	10-12			Disk clutch, wet-type	2-2		
Chain final drives	8-6			Disk-type clutches	2-2		
Chains, plain	10-9			Double planet pinion	1-13		
Chains, roller	10-9			Drive, crankarm and lever	10-16		
Chains, silent	10-9			Drive, crankwheel and lever	10-15		
Chains, tension on	10-10			Drive, final	1-5, 8-1		
Clutch controls	2-11			Drive, off-center crankarm	10-16		
Clutch dampeners	2-15			Drives, belt	10-1		
Clutch disk maintenance	2-16			Drives, cam	10-16		
Clutch disks, plate-type clutches	2-5			Drives, chain	10-8		
Clutch, dry-type disk	2-2			Drives, chain	8-6		
Clutch maintenance	2-17			Drives, fluid	1-7		
Clutch operating mechanisms	2-11			Drives, friction	1-6		
Clutch plate maintenance	2-16			Drives, gear	10-13		
Clutch release bearing maintenance	2-17			Drives, hydrostatic	5-1		
Clutch, roller-type overrunning	2-8			Drives, pinion	8-3		
Clutch shafts	2-6			Drives, planetary	8-4		
Clutch, wet-type disk	2-2			Drives, reciprocating	10-14		
Clutches	1-2, 2-1			Drives, shafts	9-4		
				Drives, special	10-1		
				Drives, straight axle	8-2		

E	Page
Electrical clutch controls	2-13
Endplay, gear shaft	1-20
Expanding shoe clutches	2-10

F

Final drives, chain	8-6
Final drives, gear	1-5, 8-1
Fluid couplings	6-1
Fluid drives	1-7
Fluids	1-6, 1-8
Flywheel	2-4
Flywheel maintenance	2-16
Free travel, clutch	2-6
Friction, belt	1-7
Friction drives	1-6
Friction, theory of	1-6, 1-8
Friction, wheel	1-6

G

Gear backlash	1-14, 1-20
Gear drives	10-13
Gear drives, trouble shooting of	10-14
Gear ratio	1-9
Gear ring	1-12
Gear, shaft endplay	1-20
Gear, sun	1-12
Gear train, adjusting	1-20
Gear train, preloading	1-20
Gear wear	1-14
Gears	1-3, 1-6, 1-8
Gears, helical cut	1-9
Gears, helical spur	1-10
Gears, herringbone	1-10
Gears, hypoid	1-10
Gears, plain bevel	1-10
Gears, planetary	1-10, 1-12
Gears, planet pinion	1-12
Gears, rack and pinion	1-12
Gears, spiral bevel	1-10
Gears, straight cut	1-9
Gears, straight spur	1-10
Gears, types of	1-9
Gears, worm	1-10

H	Page
Helical spur gears	1-10
Herringbone gears	1-10
Hydraulic assist transmissions	4-1
Hydraulic assist transmissions, trouble shooting of	4-11
Hydraulic clutch controls	2-12
Hydraulic clutches	2-10
Hydraulic controls	6-7
Hydraulic lock, differential	7-3
Hydraulic shift controls	4-9
Hydrostatic drive axles	5-5
Hydrostatic drives	5-1, 6-1
Hydrostatic drives, maintenance of	5-6
Hydrostatic drives, operation of	5-6
Hydrostatic drives, theory of	5-2
Hydrostatic drives, trouble shooting of	5-7
Hydrostatic transmissions	5-1
Hypoid gears	1-10

I

Intermediate plate, plate-type clutches	2-5
---	-----

J

Jump clutches	10-18
---------------------	-------

L

Lubrication, dry-type clutches	2-2
Lubrication, chain drives	10-11
Lubrication, plate-type clutches	2-6
Lubrication, wet-type disk clutch	2-3

M

Magnetic clutches	2-9
Mechanical clutch controls	2-11
Mechanical locks, differential	7-2
Mechanical transmissions	3-1

O

Off-center crankarm drive	10-16
Overdrives	4-2
Overrunning clutch, cam or sprag-type	2-8
Overrunning clutch, roller-type	2-8
Overrunning clutch, spring-type	2-9
Overrunning clutches	2-7, 2-8
Overrunning clutches, service of	2-9

P	Page	S (Cont.)	Page
PTO	9-1	Swashplate, hydrostatic drive	5-1
PTO drives, standards for	9-5	Synchromesh transmissions	3-5
PTO's, trouble shooting of	9-7		
Pinion drives	8-3	T	
Pinions, ring gear and	1-4	Tension on chains	10-10
Pins, shear	10-18	Torque	1-8
Plain bevel gears	1-10	Torque converter, testing of	6-11
Plain chains	10-9	Torque converter, trouble shooting of	6-5
Planetary drives	8-4	Torque converters	6-1
Planetary gears	1-10, 1-12	Train, power	1-1
Planetary transmissions	4-3	Transmissions, collar shift	3-3
Planet pinion carrier, driven	1-13	Transmissions, countershaft	4-2
Planet pinion, double	1-13	Transmissions, hydraulic assist	4-1
Planet pinion gears	1-12	Transmissions, hydrostatic, etc.	5-1
Plate-type clutches	2-3	Transmissions, mechanical	3-1
Plate-type clutches, servicing of	2-6	Transmissions, planetary	4-3
Pneumatic clutches	2-10	Transmissions, sliding gear	3-1
Power take-offs	9-1	Transmissions, synchromesh	3-5
Power train, basic operation	1-2	Transmissions, theory of	1-2
Power trains, theory of	1-1	Transmissions, torque converter	6-6
Power transmissions	1-6 4-1	Trouble shooting, differential	7-5
Preloading of gear trains	1-20	Trouble shooting, hydraulic assist transmissions	4-11
Pressure plate assembly, clutch	2-4	Trouble shooting belt drives	10-7
		Trouble shooting, chain drives	10-12
R		Trouble shooting clutches	2-17
Rack and pinion gears	1-12	Trouble shooting, gear drives	10-14
Ratio, gear	1-9	Trouble shooting, hydrostatic drives	5-7
Reciprocating drives	10-14	Trouble shooting, PTO's	9-7
Reverser unit	4-2	Trouble shooting, reciprocating drives	10-17
Ring gear	1-12	Trouble shooting, safety mechanisms	10-18
Ring gear and pinion	1-4	Trouble shooting, torque converters	6-5
Roller chains	10-9	Trouble shooting, transmission	3-12
S		U	
Safety mechanisms	10-18	Underdrives	4-2
Shaft, clutch	2-6	Universal joints	9-3
Shear pins	10-18		
Shift controls	3-10	V	
Shift controls, hydraulic	4-9	V-belts	10-3
Silent chains	10-9	Variable-speed belt drives	10-3
Sliding gear transmissions	3-1		
Slip clutches	2-11, 10-17	W	
Special drives	10-1	Wear, gear	1-14
Speed	1-9	Wet-type disk clutch	2-2
Spiral bevel gears	1-10	Wheel friction	1-6
Spur gears, helical	1-10	Worm gears	1-10
Spur gears, straight	1-10		
Standards for PTO drives	9-5		
Straight axle drives	8-2		
Straight spur gears	1-10		
Sun gear	1-12		
Sun gear, driven	1-12		

ANSWERS TO TEST YOURSELF QUESTIONS

ANSWERS TO CHAPTER 1 QUESTIONS

1. a — 2; b — 3; c — 1.
2. Gear B has traveled $\frac{1}{2}$ revolution.
3. False. To reduce speeds, a small gear drives a larger one.
4. Reducing gear speeds will **increase** the twisting force or torque.
5. True.
6. Friction, gear, fluids.
7. **Friction** — wheels, belts, clutches, etc. **Gears** — transmissions, chains, etc. **Fluids** — water wheel, torque converter, fluid drive, etc.
8. Any one of these: Operate more quietly, wear less rapidly, have greater tooth strength.
9. 1. Reduce friction; 2. Support a shaft.
10. Preloaded.
11. Endplay.
12. Backlash.

ANSWERS TO CHAPTER 2 QUESTIONS

1. Any four of these: Disk, plate, band, overrun-ning, cone expanding shoe.
2. Wet and dry.
3. Any two of these: Long wearing, heat resistant, allow little slippage.
4. The flexible disk has springs around its hub.
5. First blank "**engage**". Second blank "**free wheel**".
6. False — Overcenter linkage locks both while engaged and disengaged.
7. False.
8. **Both** grabbing and slipping (No. 3).

ANSWERS TO CHAPTER 3 QUESTIONS

1. Sliding gear, collar shift, and synchromesh.
2. True.
3. The collar shift transmission usually runs quieter than a sliding gear type. (This is because it can use helical — instead of spur-tooth gears.)
4. Synchromesh.

5. The countershaft serves to transmit and vary the power flow between the input and output shafts.
6. Helical.
7. A chamfer is a rounded area or bevel or the edge of gear teeth, etc. (It helps to make gears mesh easier when they are shifted.)

ANSWERS TO CHAPTER 4 QUESTIONS

1. First blanks — "hydraulic clutches". Second blanks — "gear train."
2. Countershaft and planetary.
3. **Underdrive** means that the output shaft turns **slower** than the input, while **overdrive** means that the output turns **faster** than the input.
4. Sun gear, planet pinions (and carrier), and ring gear.
5. True.
6. The ratio is 1 to 1 (a direct drive).
7. 1) Lubricates (and cools), 2) engages the clutches and brakes.

ANSWERS TO CHAPTER 5 QUESTIONS

1. First blank — "low". Second blank — "high".
2. Torque converter uses fluids at **high** speeds but relatively **low** pressures.
3. **Pump and motor**.
4. Variable.
5. The charge pump **makes** up for oil lost from the closed circuit between the pump and motor.

ANSWERS TO CHAPTER 6 QUESTIONS

1. First two blanks — "fluid coupling". Second two blanks — "torque converter".
2. The stator.
3. First blank — "vortex". Second blank — "rotary".
4. False.
5. False.
6. a — 3; b — 1; c — 2.

ANSWERS TO CHAPTER 7 QUESTIONS

1. Transmits power "around the corner" and allows each wheel to rotate at a different speed.
2. They lock out differential action to prevent a loss of power when one wheel slips.
3. Mechanical, hydraulic, automatic.
4. To prevent the danger of turning the machine with the differential lock engaged.
5. The automatic (no-spin) type.
6. False. The faster wheel turns faster than ring gear speeds, but the slower wheel turns the same as the ring gear.

ANSWERS TO CHAPTER 8 QUESTIONS

1. Straight axle, pinion, planetary, chain.
2. Straight axle.
3. A *live* axle transmits the torque as well as supporting part of the machine's weight. The *dead* axle only supports the machine.
4. False.
5. Either of these answers: More compact; more durable.
6. The main advantage: Allows for high clearance under the axle. The main disadvantage: Tends to loosen at the chain.

ANSWERS TO CHAPTER 9 QUESTIONS

1. a — 2; b — 3; c — 1.
2. They have a different number of splines (540 has six splines, while 1000 has twenty-one splines).
3. True.

ANSWERS TO CHAPTER 10 QUESTIONS

1. Belt, chain, gear.
2. Belt.
3. The two halves of the pulley move closer together or farther apart to move the belt in or out.
4. False.
5. On the slack side.
6. First blank — "rotary". Second blank — "linear" or "straight".

FOSS

**Fundamentals
of Service**

Power Trains



**Transparency
Masters**



CE084545




POWER TRAINS — THE BASIC PARTS






HOW A CLUTCH WORKS





ONLY ONE DISK IS TURNING




BOTH DISKS ARE TURNING



CLUTCH IN OPERATION





CLUTCH DISENGAGED



CLUTCH ENGAGED




HOW TRANSMISSION SELECTS A SPEED




**SMALL GEAR ALWAYS
TURNS FASTER**



HOW THE TRANSMISSION SHIFTS GEARS




LOW GEAR



SECOND GEAR




TRANSMISSION SELECTS REVERSE GEAR






TRANSMISSION RING GEAR AND PINION





HOW THE DIFFERENTIAL WORKS




BOTH WHEELS FREE TO ROTATE


ONE WHEEL FREE




THREE WAYS OF TRANSMITTING POWER



FRICTION





GEARS



FLUIDS




HOW TORQUE VARIES WITH LEVERS



**FULCRUM CLOSER TO OBJECT =
MORE TORQUE FOR LEVER
BUT LEVER MUST MOVE FARTHER**




HOW TORQUE VARIES WITH GEARS



**LARGE GEAR
DRIVING SMALL
GEAR =
MORE SPEED
BUT LESS TORQUE**

156




**SMALL GEAR
DRIVING LARGER
GEAR =
LESS SPEED
BUT MORE TORQUE**

157




GEAR RATIOS

RATIO 1 TO 1




**SPEED
100 RPM**

RATIO 2 TO 1




**SPEED
50 RPM**






TYPES OF GEAR TEETH

**STRAIGHT
CUT**




**HELICAL
CUT**







TYPES OF GEARS




STRAIGHT SPUR




HELICAL SPUR




HERRINGBONE




PLAIN BEVEL




SPIRAL BEVEL




HYPOID



PLANETARY




WORM



RACK AND PINION




PLANETARY GEARS



172




PLANETARY WHEN SUN GEAR IS DRIVEN






PLANETARY WHEN CARRIER IS DRIVEN






DOUBLE PLANET PINION SET






BACKLASH IN GEARS







BEARINGS



**BALL
BEARING**




**ROLLER
BEARING**



**NEEDLE
BEARING**




LOAD FORCES ON BEARINGS






ADJUSTING RING GEAR AND PINION






SUMMARY: BASIC POWER TRAIN






WHAT CLUTCH DOES






DRY-TYPE DISK CLUTCH (STANDARD)






DRY-TYPE DISK CLUTCH (HEAVY-DUTY)









BAND-TYPE CLUTCHES







BASIC OVERRUNNING CLUTCH






TWO TYPES OF OVERRUNNING CLUTCHES






CONE-TYPE CLUTCH






EXPANDING SHOE CLUTCHES




MECHANICAL TYPE



CENTRIFUGAL TYPE




MECHANICAL LINKAGE FOR CLUTCH







OVER-CENTER LINKAGE FOR CLUTCH



**RELEASED
(LOCKED)**



ON-CENTER




**OVER-CENTER
(LOCKED)**

**LOCKS CLUTCH WHILE
ENGAGED OR DISENGAGED**




HYDRAULIC CLUTCH CONTROL






ELECTRICAL CLUTCH — DIRECT-ACTION




ELECTRICAL CLUTCH — INDIRECT-ACTION

DRY POWDER
NOT ENERGIZED



DE-MAGNETIZED
(CLUTCH DISENGAGED)


DRY POWDER
ENERGIZED



MAGNETIZED
(CLUTCH ENGAGED)




SLIDING GEAR TRANS. - SHAFTS PARALLEL





SLIDING GEAR TRANS. — SHAFTS IN LINE




COUNTERSHAFT

FIRST GEAR SHOWN

216




COLLAR SHIFT TRANSMISSION



**GEARS ARE IN
CONSTANT MESH.
IN NEUTRAL, THEY ARE
FREE-RUNNING, WHEN
SHIFTED, THEY ARE LOCKED
TO SHAFTS BY COLLARS.**




COLLAR SHIFT TRANSMISSION





BLOCK-TYPE SYNCHRONIZER




221

**SYNCHRONIZERS EQUALIZE SPEED OF
MATING GEARS BEFORE THEY ENGAGE**

222



BLOCK-TYPE SYNCHRONIZER (1)




223

224

Ⓐ SYNCHRONIZER IN NEUTRAL POSITION BEFORE SHIFT



OPERATION OF BLOCK SYNCHRONIZER (2)



225


(B)

**DURING SYNCHRONIZATION—BLOCKING RING
AND GEAR SHOULDER CONTACTING**

226




OPERATION OF BLOCK SYNCHRONIZER (3)



© SHIFT COMPLETED—COLLAR LOCKS
DRIVEN GEAR TO HUB AND SHAFT




DISK-AND-PLATE-TYPE SYNCHRONIZER






DISK-AND-PLATE-TYPE SYNCHRONIZER






PLAIN-TYPE SYNCHRONIZER (1)



MOVING TOWARD ENGAGEMENT




PLAIN-TYPE SYNCHRONIZER (2)






PIN-TYPE SYNCHRONIZER





SYNCHROMESH TRANS. — OPERATION





239

240

POWER FLOW FOR SECOND GEAR SHOWN




DIRECT-TYPE SHIFTERS






LOCKING OF DIRECT SHIFTERS






CAM-TYPE SHIFTERS





HYDRAULIC ASSIST TRANSMISSION



CLUTCH ENGAGED


Oil Pushes Piston Against Disks and Plates, Clamping Them and Joining Input Power From Drum To Hub and Output Shaft

CLUTCH DISENGAGED

Oil Is Released and Piston Moves Away, Freeing Disks From Plates. Power Flow Is Stopped.




COUNTERSHAFT TRANSMISSION (1) (HIGH-LOW SPEED UNIT)






COUNTERSHAFT TRANSMISSION (2) (HIGH-LOW SPEED UNIT)






COUNTERSHAFT TRANSMISSION (3) (REVERSER UNIT)







COUNTERSHAFT TRANSMISSION (4) (REVERSER UNIT)






PLANETARY TRANSMISSION — BASIC PARTS






SIMPLE PLANETARY TRANSMISSION (HIGH-LOW UNIT WITH RING GEAR)



HIGH SPEED (DIRECT DRIVE) SHOWN




SIMPLE PLANETARY TRANSMISSION (HIGH-LOW UNIT WITHOUT RING GEAR)






COMPOUND PLANETARY TRANSMISSION (1) (TWELVE-SPEED UNIT)






COMPOUND PLANETARY TRANSMISSION (2)






COMPOUND PLANETARY TRANSMISSION (3)



257




COMPOUND PLANETARY TRANSMISSION (4)






COMPOUND PLANETARY TRANSMISSION (5) (SECOND PLANETARY ADDED)






COMPOUND PLANETARY TRANSMISSION (6)





COMPOUND PLANETARY TRANSMISSION (7)






COMPOUND PLANETARY TRANSMISSION (8)

1st Fwd.	C1		B1				C3
2nd Fwd.	C1			B2			C3
3rd Fwd.		C2	B1				C3
4th Fwd.		C2		B2			C3
5th Fwd.		C2	B1			B4	
6th Fwd.		C2		B2		B4	
7th Fwd.	C1	C2					C3
8th Fwd.	C1	C2				B4	
1st Rev.	C1		B1		B3		
2nd Rev.	C1			B2	B3		
3rd Rev.		C2	B1		B3		
4th Rev.		C2		B2	B3		

**ENGAGEMENT OF CLUTCHES (C)
AND BRAKES (B) IN EACH SPEED**




HYDRAULIC TRANS. SHIFT CONTROLS






HYDROSTATIC DRIVES






TYPES OF HYDRAULIC TRANSMISSIONS




HYDRODYNAMIC =
Low Pressure + High Velocity




HYDROSTATIC =
High Pressure + Low Velocity



THEORY OF HYDROSTATIC DRIVES




TWO CYLINDERS CONNECTED



TWO CONNECTED CYLINDERS WITH SWASHPLATE




VARIABLE PUMP DRIVING FIXED MOTOR





PARTS OF HYDROSTATIC DRIVE




CONTROL OF HYDROSTATIC OPERATION:

- Rate of oil flow—gives the speed
- Direction of oil flow—gives the direction
- Pressure of oil—gives the power



TYPES OF HYDROSTATIC DRIVES (1)




② VARIABLE DISPLACEMENT PUMP-FIXED DISPLACEMENT MOTOR

① FIXED DISPLACEMENT PUMP-FIXED DISPLACEMENT MOTOR



TYPES OF HYDROSTATIC DRIVES (2)






③ **FIXED DISPL. PUMP —
VARIABLE MOTOR**

④ **VARIABLE PUMP —
VARIABLE MOTOR**




REVERSING — VARIABLE HYDROSTATICS






NEUTRAL — HYDROSTATIC DRIVE






FORWARD — HYDROSTATIC DRIVE






REVERSE — HYDROSTATIC DRIVE




HYDROSTATIC DRIVE AXLE






PRINCIPLES OF FLUID COUPLING




**HYDROSTATIC
DRIVE =**
High Pressure +
Low Velocity

**TORQUE
CONVERTER =**
Low Pressure +
High Velocity







OPERATION OF A FLUID COUPLING




A
FLUID
COUPLING



B
FLUID LIES
LEVEL IN BOWL




C
BOWL IS SPUN
AND FLUID
SPILLS OUT



D
TORQUE IS
TRANSMITTED TO
UPPER BOWL BY
FORCE OF FLUID




PARTS OF A TORQUE CONVERTER






OIL FLOW IN CONVERTER






OIL FLOW IN TORQUE CONVERTER





STATOR AS A FLUID LEVER




314

315




VORTEX AND ROTARY FLOWS COMPARED



WHILE TORQUE INCREASING —
MORE VORTEX FLOW —
PUMP TURNING FASTER

316




WHILE TORQUE DECREASING —
MORE ROTARY FLOW —
PUMP-TURBINE SAME SPEED

317




TWIN-TURBINE TORQUE CONVERTER






CONTROL — TORQUE CONVERTER






DIFFERENTIALS — HOW THEY WORK




BOTH WHEELS FREE TO ROTATE



ONE WHEEL FREE TO ROTATE



AUTOMATIC DIFFERENTIAL LOCK





1—Differential Housing Cover
2—Side Gear (2 Used)
3—Spring (2 Used)
4—Spring Retainer (2 Used)

5—Driven Clutch (2 Used)
6—Cam Holdout Ring (2 Used)
7—Snap Ring
8—Spider

9—Stop
10—Center Cam
11—Ring Gear
12—Differential Housing




STRAIGHT AXLE DRIVES






FULL-FLOATING AXLE SHAFT






SEMIFLOATING AXLE SHAFTS



**TAPERED ROLLER
BEARINGS AND SHAFT**

330




**BALL BEARINGS
AND FLANGED SHAFT**

331



PINION DRIVE FOR AXLE (WITHIN DIFFERENTIAL CASE)




332

333




PINION DRIVE FOR AXLE (ON OUTER ENDS OF FINAL DRIVES)






PLANETARY FINAL DRIVES (INBOARD TYPE)






TYPES OF PTO'S





TWO-SPEED PTO (1)




340

341

PTO OPERATING AT 1000 RPM



TWO-SPEED PTO (2)




342

PTO OPERATING AT 540 RPM

343





PTO DRIVE





UNIVERSAL JOINT




346

347

BENDIX-WEISS TYPE



STANDARDS FOR PTO DRIVES





SAFETY RULES FOR PTO'S

SAFETY RULES FOR PTO'S

Safety is a prime factor in equipment design.

Here are safety rules for working on machines equipped with PTO's.

1. *Keep PTO guards and shields in place even when the PTO is not operating.*
2. *Always disconnect the PTO when not in use.*
3. *Never engage the PTO while the machine engine is shut off.*
4. *Keep hands, feet, and clothing away from PTO parts.*
5. *Be sure your clothing is relatively tight and belted. Loose clothing can become caught in moving PTO parts.*

6. *Never operate PTO shafts at extreme angles.*

7. *Never ride, or permit others to ride, on the drawbar of the tractor.*

8. *Never hook 540 rpm equipment to a 1000 rpm PTO or vice-versa.*


9. *Be sure PTO spinner shields rotate freely at all times. Disengage all power and shut off tractor engine before checking spinner shields.*

10. *Always be sure PTO drive shaft is properly secured to the machine's PTO shaft.*

11. *Do not service, lubricate, or perform other work on a machine without first disengaging the machine PTO and shutting off the engine.*




THREE TYPE OF DRIVES






FORMS OF BELT DRIVES



OPEN




CROSSED



MULE




TURNED




SERPENTINE




TYPES OF BELTS



FLAT BELT




V-BELT



ROUND BELT



VARIABLE-SPEED BELT DRIVE




FASTER SPEED
Pulley Halves Are
Apart And Belt
Rides Deep.

SLOWER SPEED
Pulley Halves Move
Together And
Belt Rides High.




BELT CREEPING






BELT PULLEYS NOT ALIGNED




362



363




CHECKING ALIGNMENT OF BELT PULLEYS



CORD MUST TOUCH SHEAVES AT ARROWS




CHECKING BELT TENSION






PROPER POSITION — BELT IN SHEAVE





WOBBLING SHEAVE




370

371



PARTS OF A CHAIN DRIVE




372


373




THREE TYPES OF CHAINS



PLAIN CHAIN



ROLLER CHAIN



SILENT CHAIN




ROLLER CHAIN


Side Bar



Bushing




Roller



Side Bar

(a) ROLLER LINK

Pin




(b) PIN LINK




(c) LINKS ASSEMBLED



PROBLEMS WITH CHAIN DRIVES






378 **STRETCHED CHAIN**



379 **TOOTH WEAR**





LUBRICATION OF OPEN GEARS







RECIPROCATING DRIVES (1)






RECIPROCATING DRIVES (2)



385




RECIPROCATING DRIVES (3)






RECIPROCATING DRIVES (4)

ON RETURN
STROKE,
PITMAN MOVES
BACK TO LEFT






RECIPROCATING DRIVES (5)







RECIPROCATING DRIVES (6)



GRAVITY CAM





SPRING-LOADED CAM



TRACK-AND-FOLLOWER CAM




SLIP CLUTCH






JUMP CLUTCHES




DISENGAGED



ENGAGED



SHEAR PIN



These masters are selected from key illustrations in the matching FOS Manual. They are intended for use with the manual. A discussion of each illustration is found in the manual under the corresponding chapter and figure number. Use the colored illustrations in the manual as a guide for accenting the important parts on your transparencies.

The masters have two purposes: (1) for making transparencies for use on the overhead projector and (2) for making worksheets for students.

Worksheets may be prepared by blocking out the labels before duplicating. Each student can learn by labeling and coloring important parts and by attempting to explain the operating principles where they apply. Then he may keep the worksheet for review and future reference, if the teacher desires.